



YFZ450S

SERVICE MANUAL

EBS00001

**YFZ450S
SERVICE MANUAL
©2003 by Yamaha Motor Corporation, U.S.A.
First Edition, May 2003
All rights reserved.
Any reproduction or unauthorized use
without the written permission of
Yamaha Motor Corporation, U.S.A.
is expressly prohibited.
Printed in U.S.A.
LIT-11616-17-11**

NOTICE

This manual was produced by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual, so it is assumed that anyone who uses this book to perform maintenance and repairs on Yamaha machine has a basic understanding of the mechanical ideas and the procedures of machine repair. Repairs attempted by anyone without this knowledge are likely to render the machine unsafe and unfit for use.

Yamaha Motor Company, Ltd. is continually striving to improve all its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

NOTE:

Designs and specifications are subject to change without notice.

IMPORTANT INFORMATION

Particularly important information is distinguished in this manual by the following notations.



The Safety Alert Symbol means ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!



Failure to follow WARNING instructions could result in severe injury or death to the machine operator, a bystander or a person checking or repairing the machine.

CAUTION:

A CAUTION indicates special precautions that must be taken to avoid damage to the machine.

NOTE:

A NOTE provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

MANUAL ORGANIZATION

This manual consists of chapters for the main categories of subjects. (See “symbols”)

1st title ①: This is the title of the chapter with its symbol in the upper right corner of each page.

2nd title ②: This title indicates the section of the chapter and only appears on the first page of each section. It is located in the upper left corner of the page.

3rd title ③: This title indicates a sub-section that is followed by step-by-step procedures accompanied by corresponding illustrations.

EXPLODED DIAGRAMS

To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section.

1. An easy-to-see exploded diagram ④ is provided for removal and disassembly jobs.
2. Numbers ⑤ are given in the order of the jobs in the exploded diagram. A number that is enclosed by a circle indicates a disassembly step.
3. An explanation of jobs and notes is presented in an easy-to-read way by the use of symbol marks ⑥. The meanings of the symbol marks are given on the next page.
4. A job instruction chart ⑦ accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.
5. For jobs requiring more information, the step-by-step format supplements ⑧ are given in addition to the exploded diagram and the job instruction chart.

② CLUTCH ① ENG

EXPLODED DIAGRAM

CLUTCH

④

⑤

⑥

⑦

| Order | Job/Part | Q'ty | Remarks |
|----------------------------|----------------|------|---|
| Removing the clutch | | | |
| | Engine oil | | Remove the parts in the order listed. |
| | Clutch cable | | Drain. |
| | | | Refer to "LEADS, CABLES AND HOSES". |
| 1 | Clutch cover | 1 | Refer to "REMOVING THE CLUTCH" and "INSTALLING THE CLUTCH". |
| 2 | Gasket | 2 | |
| 3 | Dowel pin | 1 | |
| 4 | Clutch spring | 6 | |
| 5 | Pressure plate | 1 | Refer to "INSTALLING THE CLUTCH". |
| 6 | Push rod 1 | 1 | |
| 7 | Circlip | 1 | |
| 8 | Plain washer | 1 | |
| 9 | Bearing | 1 | |
| 10 | Ball | 1 | |

CLUTCH ENG

REMOVING THE CLUTCH

1. Remove:

- clutch cover ①

NOTE:
Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.

2. Straighten the lock washer tab.

3. Loosen:

- clutch boss nut ①

NOTE:
While holding the clutch boss ② with the universal clutch holder ③, loosen the clutch boss nut.

Universal clutch holder
P/N, YM-91042, 90890-04086

CHECKING THE FRICTION PLATES
The following procedure applies to all of the friction plates.

1. Check:

- friction plate 1
- friction plate 2

Damage/wear → Replace the friction plates as a set.

2. Measure:

- friction plate 1 thickness
- friction plate 2 thickness

























Out of specification → Replace the friction plates as a set.

NOTE:
Measure the friction plate at four places.

Friction plate 1 thickness
2.9 - 3.1 mm (0.114 - 0.122 in)
Limit: 2.8 mm (0.110 in)

Friction plate 2 thickness
2.9 - 3.1 mm (0.114 - 0.122 in)
Limit: 2.8 mm (0.110 in)

4 - 48 4 - 50

| | | |
|---|---|---|
| ① GEN INFO  | ② SPEC  | |
| ③ CHK ADJ  | ④ ENG  | |
| ⑤ COOL  | ⑥ CARB  | |
| ⑦ CHAS  | ⑧ ELEC  | |
| ⑨ TRBL SHTG  | ⑩  | |
| ⑪  | ⑫  | |
| ⑬  | ⑭  | |
| ⑮  | ⑯  | ⑰  |
| ⑱  | ⑲  | ⑳  |
| ㉑  | ㉒  | ㉓  |
| ㉔  | ㉕ New | |

EBS00006

SYMBOLS

The following symbols are not relevant to every machine.

Symbols ① to ⑨ indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic checks and adjustments
- ④ Engine
- ⑤ Cooling system
- ⑥ Carburetor
- ⑦ Chassis
- ⑧ Electrical
- ⑨ Troubleshooting

Symbols ⑩ to ⑰ indicate the following

- ⑩ Serviceable with engine mounted
- ⑪ Filling fluid
- ⑫ Lubricant
- ⑬ Special tool
- ⑭ Torque
- ⑮ Wear limit, clearance
- ⑯ Engine speed
- ⑰ Electrical data (Ω , V, A)










Symbols ⑱ to ㉔ in the exploded diagrams indicate the types of lubricants and lubrication points.

- ⑱ Apply engine oil
- ⑲ Apply gear oil
- ㉑ Apply molybdenum disulfide oil
- ㉒ Apply wheel bearing grease
- ㉓ Apply lithium-soap-based grease
- ㉔ Apply molybdenum disulfide grease

Symbols ㉔ to ㉕ in the exploded diagrams indicate where to apply a locking agent ㉔ and when to install a new part ㉕.

- ㉔ Apply the locking agent (LOCTITE®)
- ㉕ Replace

TABLE OF CONTENTS

| | |
|---------------------------------|---|
| GENERAL INFORMATION |  |
| | GEN INFO 1 |
| SPECIFICATIONS |  |
| | SPEC 2 |
| PERIODIC CHECKS AND ADJUSTMENTS |  |
| | CHK ADJ 3 |
| ENGINE |  |
| | ENG 4 |
| COOLING SYSTEM |  |
| | COOL 5 |
| CARBURETOR |  |
| | CARB 6 |
| CHASSIS |  |
| | CHAS 7 |
| ELECTRICAL |  |
| | ELEC 8 |
| TROUBLESHOOTING |  |
| | TRBL SHTG 9 |

CHAPTER 1

GENERAL INFORMATION

| | |
|--|-----|
| MACHINE IDENTIFICATION | 1-1 |
| VEHICLE IDENTIFICATION NUMBER | 1-1 |
| MODEL LABEL..... | 1-1 |
| IMPORTANT INFORMATION | 1-2 |
| PREPARATION FOR REMOVAL AND DISASSEMBLY..... | 1-2 |
| REPLACEMENT PARTS..... | 1-2 |
| GASKETS, OIL SEALS AND O-RINGS | 1-2 |
| LOCK WASHERS/PLATES AND COTTER PINS | 1-3 |
| BEARINGS AND OIL SEALS | 1-3 |
| CIRCLIPS | 1-3 |
| CHECKING THE CONNECTIONS..... | 1-4 |
| SPECIAL TOOLS | 1-5 |

CHAPTER 2

SPECIFICATIONS

| | |
|---|------|
| GENERAL SPECIFICATIONS | 2-1 |
| ENGINE SPECIFICATIONS | 2-4 |
| CHASSIS SPECIFICATIONS | 2-12 |
| ELECTRICAL SPECIFICATIONS | 2-14 |
| TIGHTENING TORQUES | 2-16 |
| ENGINE TIGHTENING TORQUES | 2-16 |
| CHASSIS TIGHTENING TORQUES | 2-19 |
| HOW TO USE THE CONVERSION TABLE | 2-21 |
| GENERAL TIGHTENING TORQUE SPECIFICATIONS | 2-21 |
| LUBRICATION POINTS AND LUBRICANT TYPES | 2-22 |
| ENGINE..... | 2-22 |
| COOLANT FLOW DIAGRAMS | 2-24 |
| OIL FLOW DIAGRAMS | 2-26 |
| CABLE ROUTING | 2-28 |

CHAPTER 3

PERIODIC CHECKS AND ADJUSTMENTS

| | |
|--|-------------|
| INTRODUCTION..... | 3-1 |
| PERIODIC MAINTENANCE/LUBRICATION | 3-1 |
| SEAT, FENDERS AND FUEL TANK | 3-3 |
| SEAT, FUEL TANK COVER AND SIDE COVERS | 3-3 |
| FOOT PROTECTORS AND ENGINE SKID PLATE | 3-4 |
| HEADLIGHTS AND FRONT FENDER..... | 3-5 |
| REAR FENDER..... | 3-6 |
| FUEL TANK..... | 3-7 |
| ENGINE | 3-8 |
| ADJUSTING THE VALVE CLEARANCE | 3-8 |
| ADJUSTING THE ENGINE IDLING SPEED | 3-13 |
| ADJUSTING THE THROTTLE LEVER FREE PLAY | 3-14 |
| ADJUSTING THE SPEED LIMITER..... | 3-16 |
| CHECKING THE SPARK PLUG | 3-17 |
| CHECKING THE IGNITION TIMING..... | 3-18 |
| CHECKING THE ENGINE OIL LEVEL..... | 3-19 |
| CHANGING THE ENGINE OIL | 3-21 |
| ADJUSTING THE CLUTCH CABLE..... | 3-24 |
| CLEANING THE AIR FILTER ELEMENT..... | 3-26 |
| CHECKING THE COOLANT LEVEL..... | 3-28 |
| CHANGING THE COOLANT..... | 3-28 |
| CHECKING THE COOLANT TEMPERATURE WARNING LIGHT | 3-32 |
| CLEANING THE SPARK ARRESTER | 3-33 |
| CHASSIS | 3-34 |
| ADJUSTING THE FRONT BRAKE | 3-34 |
| ADJUSTING THE BRAKE LEVER | 3-34 |
| ADJUSTING THE REAR BRAKE..... | 3-34 |
| ADJUSTING THE PARKING BRAKE..... | 3-35 |
| CHECKING THE BRAKE FLUID LEVEL..... | 3-36 |
| CHECKING THE FRONT BRAKE PADS | 3-37 |
| CHECKING THE REAR BRAKE PADS | 3-38 |
| ADJUSTING THE REAR BRAKE LIGHT SWITCH | 3-39 |
| CHECKING THE BRAKE HOSES..... | 3-39 |
| BLEEDING THE HYDRAULIC BRAKE SYSTEM | 3-40 |
| ADJUSTING THE SHIFT PEDAL..... | 3-42 |
| ADJUSTING THE DRIVE CHAIN SLACK | 3-43 |
| CHECKING THE STEERING SYSTEM | 3-44 |
| ADJUSTING THE TOE-IN..... | 3-45 |
| CHECKING THE FRONT AND REAR SHOCK ABSORBERS | 3-46 |
| ADJUSTING THE FRONT SHOCK ABSORBERS | 3-47 |
| ADJUSTING THE REAR SHOCK ABSORBER | 3-49 |
| CHECKING THE TIRES..... | 3-53 |

| | |
|---|------|
| CHECKING THE WHEELS | 3-55 |
| CHECKING AND LUBRICATING THE CABLES | 3-55 |
| LUBRICATING THE LEVERS AND PEDALS | 3-56 |
| ELECTRICAL SYSTEM | 3-57 |
| CHECKING AND CHARGING THE BATTERY | 3-57 |
| CHECKING THE FUSES | 3-64 |
| ADJUSTING THE HEADLIGHT BEAM | 3-65 |
| REPLACING A HEADLIGHT BULB | 3-66 |

CHAPTER 4

ENGINE

| | |
|---|------|
| ENGINE REMOVAL | 4-1 |
| MUFFLER AND EXHAUST PIPE | 4-1 |
| INSTALLING THE EXHAUST PIPE AND MUFFLER..... | 4-2 |
| LEADS, CABLES AND HOSES | 4-4 |
| ENGINE MOUNTING BOLTS | 4-6 |
| INSTALLING THE ENGINE..... | 4-8 |
| CAMSHAFTS | 4-9 |
| CYLINDER HEAD COVER..... | 4-9 |
| CAMSHAFTS | 4-10 |
| REMOVING THE CAMSHAFTS..... | 4-11 |
| CHECKING THE CAMSHAFTS | 4-12 |
| CHECKING THE CAMSHAFT SPROCKETS | 4-14 |
| CHECKING THE DECOMPRESSION SYSTEM..... | 4-14 |
| CHECKING THE TIMING CHAIN GUIDE | 4-14 |
| CHECKING THE TIMING CHAIN TENSIONER..... | 4-15 |
| INSTALLING THE CAMSHAFTS | 4-15 |
| CYLINDER HEAD | 4-18 |
| REMOVING THE CYLINDER HEAD..... | 4-20 |
| CHECKING THE CYLINDER HEAD | 4-20 |
| CHECKING THE OIL DELIVERY PIPE..... | 4-21 |
| CHECKING THE TIMING CHAIN GUIDE | 4-21 |
| INSTALLING THE CYLINDER HEAD | 4-21 |
| VALVES AND VALVE SPRINGS | 4-24 |
| REMOVING THE VALVES AND VALVE SPRINGS | 4-26 |
| CHECKING THE VALVES AND VALVE SPRINGS | 4-27 |
| CHECKING THE VALVE LIFTERS | 4-32 |
| INSTALLING THE VALVES AND VALVE SPRINGS | 4-32 |

| | |
|--|------|
| CYLINDER AND PISTON | 4-34 |
| REMOVING THE PISTON | 4-35 |
| CHECKING THE CYLINDER AND PISTON | 4-35 |
| CHECKING THE PISTON RINGS..... | 4-37 |
| CHECKING THE PISTON PIN | 4-38 |
| INSTALLING THE PISTON | 4-40 |
| INSTALLING THE CYLINDER | 4-41 |
| A.C. MAGNETO | 4-42 |
| REMOVING THE A.C. MAGNETO ROTOR..... | 4-44 |
| CHECKING THE STATOR COIL AND PICKUP COIL | 4-44 |
| CHECKING THE STARTER CLUTCH | 4-45 |
| CHECKING THE TORQUE LIMITER..... | 4-46 |
| INSTALLING THE A.C. MAGNETO ROTOR | 4-46 |
| CLUTCH | 4-48 |
| REMOVING THE CLUTCH | 4-50 |
| CHECKING THE FRICTION PLATES..... | 4-50 |
| CHECKING THE CLUTCH PLATES | 4-51 |
| CHECKING THE CLUTCH SPRINGS..... | 4-51 |
| CHECKING THE CLUTCH HOUSING | 4-51 |
| CHECKING THE CLUTCH BOSS..... | 4-52 |
| CHECKING THE PRESSURE PLATE | 4-52 |
| CHECKING THE PUSH RODS | 4-52 |
| CHECKING THE PUSH LEVER..... | 4-52 |
| CHECKING THE PRIMARY DRIVEN GEAR | 4-52 |
| INSTALLING THE CLUTCH..... | 4-53 |
| BALANCER | 4-55 |
| REMOVING THE BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR | 4-56 |
| CHECKING THE PRIMARY DRIVE GEAR, BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR | 4-56 |
| CHECKING THE BALANCER..... | 4-56 |
| INSTALLING THE BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR | 4-57 |
| OIL PUMP | 4-58 |
| CHECKING THE OIL PUMP | 4-60 |
| SHIFT SHAFT | 4-61 |
| CHECKING THE SHIFT SHAFT | 4-63 |
| CHECKING THE STOPPER LEVER | 4-63 |
| CHECKING THE SHIFT GUIDE AND SHIFT LEVER..... | 4-63 |
| CHECKING THE SHIFT DRUM SEGMENT | 4-63 |
| INSTALLING THE SHIFT LEVER | 4-63 |
| INSTALLING THE SHIFT SHAFT | 4-64 |

| | |
|---|------|
| CRANKCASE | 4-65 |
| OIL SEAL AND BEARING | 4-67 |
| SEPARATING THE CRANKCASE | 4-68 |
| CHECKING THE OIL STRAINER AND OIL DELIVERY PIPE 2 | 4-68 |
| CHECKING THE TIMING CHAIN AND GUIDE | 4-69 |
| CHECKING THE BEARINGS AND OIL SEALS | 4-69 |
| CHECKING THE CRANKCASE | 4-69 |
| ASSEMBLING THE CRANKCASE | 4-70 |
| CRANKSHAFT | 4-72 |
| REMOVING THE CRANKSHAFT | 4-73 |
| CHECKING THE CRANKSHAFT | 4-73 |
| INSTALLING THE CRANKSHAFT | 4-74 |
| TRANSMISSION | 4-75 |
| MAIN AXLE | 4-76 |
| DRIVE AXLE | 4-77 |
| CHECKING THE SHIFT FORKS | 4-78 |
| CHECKING THE SHIFT DRUM | 4-78 |
| CHECKING THE TRANSMISSION | 4-78 |
| ASSEMBLING THE MAIN AXLE AND DRIVE AXLE | 4-79 |
| INSTALLING THE TRANSMISSION | 4-80 |

CHAPTER 5

COOLING SYSTEM

| | |
|-------------------------------|-----|
| RADIATOR | 5-1 |
| CHECKING THE RADIATOR | 5-3 |
| INSTALLING THE RADIATOR | 5-4 |
| WATER PUMP | 5-5 |
| CHECKING THE WATER PUMP | 5-7 |

CHAPTER 6

CARBURETOR

| | |
|---|-----|
| CARBURETOR | 6-1 |
| DISASSEMBLING THE CARBURETOR | 6-5 |
| CHECKING THE CARBURETOR | 6-5 |
| ASSEMBLING THE CARBURETOR | 6-7 |
| ADJUSTING THE ACCELERATOR PUMP TIMING | 6-8 |
| INSTALLING THE CARBURETOR JOINT | 6-8 |
| INSTALLING THE CARBURETOR | 6-9 |
| CHECKING AND ADJUSTING THE THROTTLE POSITION SENSOR ... | 6-9 |

CHAPTER 7

CHASSIS

| | |
|--|-------------|
| FRONT AND REAR WHEELS | 7-1 |
| FRONT WHEELS | 7-1 |
| REAR WHEELS | 7-3 |
| CHECKING THE WHEELS | 7-4 |
| CHECKING THE WHEEL HUBS | 7-4 |
| CHECKING THE BRAKE DISCS | 7-5 |
| INSTALLING THE FRONT WHEEL HUB BEARINGS | 7-6 |
| INSTALLING THE FRONT BRAKE DISCS | 7-6 |
| INSTALLING THE FRONT WHEELS | 7-6 |
| INSTALLING THE WHEEL HUBS | 7-7 |
| | |
| REAR AXLE AND REAR AXLE HUB | 7-8 |
| REMOVING THE REAR AXLE | 7-10 |
| CHECKING THE REAR AXLE | 7-11 |
| CHECKING THE DRIVEN SPROCKET | 7-11 |
| CHECKING THE BRAKE DISC | 7-11 |
| INSTALLING THE DRIVEN SPROCKET | 7-12 |
| INSTALLING THE REAR AXLE | 7-12 |
| | |
| FRONT AND REAR BRAKES | 7-13 |
| FRONT BRAKE PADS | 7-13 |
| REAR BRAKE PADS | 7-14 |
| REPLACING THE FRONT BRAKE PADS | 7-15 |
| REPLACING THE REAR BRAKE PADS | 7-17 |
| FRONT BRAKE MASTER CYLINDER | 7-19 |
| REAR BRAKE MASTER CYLINDER | 7-21 |
| CHECKING THE MASTER CYLINDERS | 7-24 |
| ASSEMBLING THE FRONT BRAKE MASTER CYLINDER | 7-25 |
| ASSEMBLING THE REAR BRAKE MASTER CYLINDER | 7-25 |
| INSTALLING THE FRONT BRAKE MASTER CYLINDER | 7-26 |
| INSTALLING THE REAR BRAKE MASTER CYLINDER | 7-27 |
| FRONT BRAKE CALIPERS | 7-29 |
| REAR BRAKE CALIPER | 7-31 |
| REMOVING THE PARKING BRAKE CABLE | 7-34 |
| DISASSEMBLING THE FRONT AND REAR BRAKE CALIPERS | 7-34 |
| CHECKING THE FRONT AND REAR BRAKE CALIPERS | 7-35 |
| ASSEMBLING THE FRONT BRAKE CALIPERS | 7-36 |
| ASSEMBLING THE REAR BRAKE CALIPER | 7-36 |
| INSTALLING THE FRONT BRAKE CALIPERS | 7-38 |
| INSTALLING THE REAR BRAKE CALIPER | 7-39 |
| | |
| STEERING SYSTEM | 7-41 |
| HANDLEBAR | 7-41 |
| REMOVING THE FRONT BRAKE LIGHT SWITCH AND CLUTCH SWITCH | 7-43 |
| REMOVING THE HANDLEBAR GRIPS | 7-43 |
| CHECKING THE HANDLEBAR | 7-43 |

| | |
|---|----------|
| INSTALLING THE HANDLEBAR | 7-44 |
| INSTALLING THE HANDLEBAR GRIPS | 7-44 |
| INSTALLING THE CLUTCH LEVER | 7-45 |
| INSTALLING THE BRAKE MASTER CYLINDER | 7-45 |
| STEERING STEM | 7-46 |
| REMOVING THE BEARING RETAINER | 7-48 |
| CHECKING THE STEERING STEM | 7-48 |
| INSTALLING THE BEARING RETAINER | 7-48 |
| INSTALLING THE STEERING STEM | 7-48 |
| INSTALLING THE LOCK WASHER | 7-49 |
| INSTALLING THE PITMAN ARM | 7-49 |
| TIE-RODS AND STEERING KNUCKLES | 7-50 |
| REMOVING THE STEERING KNUCKLES | 7-51 |
| CHECKING THE TIE-RODS | 7-51 |
| CHECKING THE STEERING KNUCKLES | 7-51 |
| INSTALLING THE TIE-RODS | 7-51 |
| FRONT ARMS AND FRONT SHOCK ABSORBER ASSEMBLIES | 7-52 |
| REMOVING THE FRONT ARMS | 7-54 |
| CHECKING THE FRONT ARMS | 7-54 |
| HANDLING THE FRONT SHOCK ABSORBER AND GAS CYLINDER | 7-54 |
| DISPOSING OF A FRONT SHOCK ABSORBER AND GAS CYLINDER | 7-55 |
| CHECKING THE FRONT SHOCK ABSORBERS | 7-55 |
| CHECKING THE BALL JOINTS | 7-56 |
| INSTALLING THE FRONT ARMS | 7-57 |
| REAR SHOCK ABSORBER AND RELAY ARM | 7-58 |
| HANDLING THE REAR SHOCK ABSORBER AND GAS CYLINDER | 7-60 |
| DISPOSING OF A REAR SHOCK ABSORBER AND GAS CYLINDER | 7-60 |
| REMOVING THE REAR SHOCK ABSORBER | 7-61 |
| CHECKING THE REAR SHOCK ABSORBER | 7-61 |
| CHECKING THE RELAY ARM AND CONNECTING ARM | 7-61 |
| INSTALLING THE RELAY ARM AND CONNECTING ARM | 7-62 |
| INSTALLING THE REAR SHOCK ABSORBER | 7-62 |
| SWINGARM AND DRIVE CHAIN | 7-63 |
| REMOVING THE SWINGARM | 7-65 |
| CHECKING THE SWINGARM | 7-65 |
| CHECKING THE DRIVE CHAIN | 7-67 |
| INSTALLING THE SWINGARM | 7-68 |
| INSTALLING THE DRIVE SPROCKET | 7-69 |

CHAPTER 8


ELECTRICAL

| | |
|---|-------------|
| ELECTRICAL COMPONENTS..... | 8-1 |
| CHECKING SWITCH CONTINUITY..... | 8-2 |
| CHECKING THE SWITCHES..... | 8-4 |
| CHECKING THE BULBS AND BULB SOCKETS | 8-6 |
| TYPES OF BULBS | 8-6 |
| CHECKING THE CONDITION OF THE BULBS | 8-6 |
| CHECKING THE CONDITION OF THE BULB SOCKETS | 8-8 |
| IGNITION SYSTEM | 8-9 |
| CIRCUIT DIAGRAM | 8-9 |
| THROTTLE OVERRIDE SYSTEM (T.O.R.S.) OPERATION | 8-10 |
| TROUBLESHOOTING | 8-11 |
| CHECKING THE THROTTLE OVERRIDE SYSTEM..... | 8-14 |
| ELECTRIC STARTING SYSTEM..... | 8-16 |
| CIRCUIT DIAGRAM | 8-16 |
| STARTING CIRCUIT CUT-OFF SYSTEM OPERATION | 8-17 |
| TROUBLESHOOTING | 8-18 |
| STARTER MOTOR..... | 8-22 |
| CHECKING THE STARTER MOTOR | 8-24 |
| ASSEMBLING THE STARTER MOTOR..... | 8-25 |
| CHARGING SYSTEM..... | 8-26 |
| CIRCUIT DIAGRAM | 8-26 |
| TROUBLESHOOTING | 8-27 |
| LIGHTING SYSTEM | 8-29 |
| CIRCUIT DIAGRAM | 8-29 |
| TROUBLESHOOTING | 8-30 |
| CHECKING THE LIGHTING SYSTEM..... | 8-31 |
| SIGNAL SYSTEM..... | 8-33 |
| CIRCUIT DIAGRAM | 8-33 |
| TROUBLESHOOTING | 8-34 |
| CHECKING THE SIGNALING SYSTEM | 8-35 |
| COOLING SYSTEM..... | 8-39 |
| CIRCUIT DIAGRAM | 8-39 |
| TROUBLESHOOTING | 8-40 |

CHAPTER 9

TROUBLESHOOTING

| | |
|--|----------------|
| STARTING FAILURE/HARD STARTING | 9-1 |
| FUEL SYSTEM..... | 9-1 |
| ELECTRICAL SYSTEM..... | 9-1 |
| COMPRESSION SYSTEM..... | 9-2 |
| POOR IDLE SPEED PERFORMANCE | 9-2 |
| POOR IDLE SPEED PERFORMANCE | 9-2 |
| POOR MEDIUM AND HIGH-SPEED PERFORMANCE..... | 9-2 |
| POOR MEDIUM AND HIGH-SPEED PERFORMANCE | 9-2 |
| FAULTY GEAR SHIFTING..... | 9-3 |
| HARD SHIFTING..... | 9-3 |
| SHIFT PEDAL DOES NOT MOVE | 9-3 |
| JUMPS OUT GEAR..... | 9-3 |
| CLUTCH SLIPPING/Dragging..... | 9-3 |
| CLUTCH SLIPPING | 9-3 |
| CLUTCH DRAGGING | 9-3 |
| OVERHEATING..... | 9-4 |
| OVERHEATING | 9-4 |
| FAULTY BRAKE | 9-4 |
| POOR BRAKING EFFECT | 9-4 |
| SHOCK ABSORBER MALFUNCTION | 9-4 |
| MALFUNCTION..... | 9-4 |
| UNSTABLE HANDLING..... | 9-5 |
| UNSTABLE HANDLING | 9-5 |
| LIGHTING SYSTEM | 9-5 |
| HEADLIGHT DOES NOT COME ON | 9-5 |
| TAIL/BRAKE LIGHT DOES NOT LIGHT | 9-5 |
| BULB BURNT OUT | 9-5 |
| TAIL/BRAKE LIGHT BULB BURNT OUT | 9-5 |




EBS00009

GENERAL INFORMATION MACHINE IDENTIFICATION

EBS00010

VEHICLE IDENTIFICATION NUMBER

The vehicle identification number ① is stamped into the left side of the frame.



EBS00011

MODEL LABEL

The model label ① is affixed to the air filter case cover. This information will be needed to order spare parts.

EBS00013

IMPORTANT INFORMATION PREPARATION FOR REMOVAL AND DISASSEMBLY

1. Before removal and disassembly remove all dirt, mud, dust and foreign material.
2. Use only the proper tools and cleaning equipment.
Refer to "SPECIAL TOOLS".
3. When disassembling always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.
4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
5. Keep all parts away from any source of fire.

EBS00014


REPLACEMENT PARTS

1. Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.

EBS00015

GASKETS, OIL SEALS AND O-RINGS


1. When overhauling the engine, replace all gaskets, seals and O-rings. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. During reassembly properly oil all mating parts and bearings, and lubricate the oil seal lips with grease.



EBS00016

LOCK WASHERS/PLATES AND COTTER PINS

After removal, replace all lock washers/plates ① and cotter pins. After the bolt or nut has been tightened to specification, bend the lock tabs along a flat of the bolt or nut.



EBS00017


BEARINGS AND OIL SEALS

Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals, lubricate the oil seal lips with a light coat of lithium-soap-based grease. Oil bearings liberally when installing, if appropriate.


① Oil seal

CAUTION:

Do not spin the bearing with compressed air because this will damage the bearing surfaces.



① Bearing





EBS00018

CIRCLIPS

Before reassembly, check all circlips carefully and replace damaged or distorted circlips. Always replace piston pin clips after one use. When installing a circlip ①, make sure the sharp-edged corner ② is positioned opposite the thrust ③ that the circlip receives.

④ Shaft



EBS00019

CHECKING THE CONNECTIONS

Check the leads, couplers, and connectors for stains, rust, moisture, etc.

1. Disconnect:

- lead
- coupler
- connector

2. Check:

- lead
- coupler
- connector

Moisture → Dry with an air blower.

Rust/stains → Connect and disconnect several times.

3. Check:

- all connections

Loose connection → Connect properly.

NOTE:



If the pin ① on the terminal is flattened, bend it up.

4. Connect:

- lead
- coupler
- connector

NOTE:

Make sure all connections are tight.



5. Check:

- continuity (with the pocket tester)



Pocket tester
P/N. YU-03112-C, 90890-03112

NOTE:

- If there is no continuity, clean the terminals.
- When checking the wire harness, perform steps (1) to (3).
- As a quick remedy, use a contact revitalizer available at most part stores.

EBS00021

SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools; this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools may differ by shape and part number from country to country. In such a case, two types are provided.







When placing an order, refer to the list provided below to avoid any mistakes.









For US and CDN









P/N. YM-, YU-, YS-, YK-, ACC-

Except for US and CDN

P/N. 90890-

| Tool No. | Tool name/Function | Illustration |
|---|--|---|
| 90890-01135 YU-01135-A | Crankcase separating tool This tool is used to separate the crankcase. |  |
| Pot 90890-01274 Bolt 90890-01275 | Crankshaft installer pot Crankshaft installer bolt These tools are used to install the crankshaft. |  |
| YU-90050 | Crankshaft installer set These tools are used to install the crankshaft. |  |
| Adapter 90890-01278 YM-90063 Spacer 90890-04081 YM-91044 | Adapter Spacer (crankshaft installer) These tools are used to install the crankshaft. |  |
| 90890-01304 YU-01304 | Piston pin puller This tool is used to remove the piston pin. |  |
| 90890-01325 YU-24460-01 | Radiator cap tester This tool is used to check the cooling system. |  |

| Tool No. | Tool name/Function | Illustration |
|---------------------------|---|---|
| 90890-01352 YU-33984 | Radiator cap tester adapter This tool is used to check the cooling system. |  |
| 90890-01327 YM-01327 | Damper rod holder (30 mm) This tool is needed to loosen and tighten the steering stem bearing retainer. |  |
| 90890-01443 YU-33975 | Steering nut wrench This tool is needed to loosen and tighten the front shock absorber and rear shock absorber locknuts. |  |
| 90890-01474 YM-01474 | Ball joint remover/installer set These tools are used to removing or installing the ball joints. |  |
| 90890-01480 YM-01480 | Ball joint remover/installer attachment set These tools are used to removing or installing the ball joints. |  |
| 90890-01701 YS-01880-A | Sheave holder This tool is needed to hold the A.C. magneto rotor when loosen or tighten the A.C. magneto rotor nut. |  |
| 90890-03112 YU-03112-C | Pocket tester This instrument is needed for checking the electrical system. |  |
| 90890-03141 YM-33277-A | Timing light This tool is necessary for checking ignition timing. |  |

| Tool No. | Tool name/Function | Illustration |
|--|--|---|
| Compressor 90890-04019 YM-04019 Attachment 90890-04114 YM-04114 | Valve spring compressor Valve spring compressor attachment This tool is needed to remove and install the valve assemblies. |  |
| 90890-04086 YM-91042 | Universal clutch holder This tool is needed to hold the clutch carrier when removing or installing the carrier nut. |  |
| 90890-04097 YM-04097 90890-04116 YM-04116 | Valve guide remover (ø 5) Valve guide remover (ø 4.5) This tool is needed to remove and install the valve guides. |  |
| 90890-04098 YM-04098 90890-04117 YM-04117 | Valve guide installer (ø 5) Valve guide installer (ø 4.5) This tool is needed to install the valve guides. |  |
| 90890-04099 YM-04099 90890-04118 YM-04118 | Valve guide reamer (ø 5) Valve guide reamer (ø 4.5) This tool is needed to rebore the new valve guides. |  |
| 90890-04101 | Valve lapper This tool is needed to remove and install the valve lifters. |  |
| 90890-04142 YM-04142 | Rotor puller These tools are needed to remove the A.C. magneto rotor. |  |
| 90890-06588 | PTT wrench 46 This tool is needed to loosen or tighten the rear axle nut. |  |



| Tool No. | Tool name/Function | Illustration |
|---|---|--------------|
| YM-37134 | Axle nut wrench (46 mm) This tool is needed to loosen or tighten the rear axle nut. | |
| 90890-06754 | Ignition checker This instrument is necessary for checking the ignition system components. | |
| YM-34487 | Dynamic spark tester This instrument is necessary for checking the ignition system components. | |
| Bond 90890-85505 Sealant ACC-11001-05-01 | Yamaha bond No. 1215 Sealant (Quick Gasket®) This sealant (bond) is used on crankcase mating surfaces, etc. | |



EBS01001

SPECIFICATIONS

GENERAL SPECIFICATIONS

| Item | Standard |
|---|---------------------------------------|
| Model code | 5TG1 |
| Dimensions | |
| Overall length | 1,840 mm (72.4 in) |
| Overall width | 1,170 mm (46.1 in) |
| Overall height | 1,090 mm (42.9 in) |
| Seat height | 800 mm (31.5 in) |
| Wheelbase | 1,280 mm (50.4 in) |
| Minimum ground clearance | 255 mm (10.04 in) |
| Minimum turning radius | 3,500 mm (137.8 in) |
| Basic weight | |
| With oil and full fuel tank | 169 kg (373 lb) |
| Engine | |
| Engine type | Liquid-cooled 4-stroke, DOHC |
| Cylinder arrangement | Forward-inclined single cylinder |
| Displacement | 439 cm ³ (26.79 cu in) |
| Bore × stroke | 95.0 × 62.0 mm (3.74 × 2.44 in) |
| Compression ratio | 11.9:1 |
| Starting system | Electric starter |
| Lubrication system | Dry sump |
| Oil type or grade | |
| Engine oil | API service SE, SF, SG type or higher |
| <p>The chart shows temperature ranges in Fahrenheit (0° to 130°) and Celsius (-20° to 50°). SAE 5W30 is recommended for temperatures down to -20°F (-28°C). YAMALUBE4 (10W30) or SAE 10W30 is recommended for temperatures from -10°F (-23°C) to 110°F (43°C). YAMALUBE4 (20W40) or SAE 20W40 is recommended for temperatures from 0°F (-18°C) to 130°F (56°C).</p> | |
| Oil capacity | |
| Engine oil | |
| Periodic oil change | 1.75 L (1.54 Imp qt, 1.85 US qt) |
| With oil filter replacement | 1.85 L (1.63 Imp qt, 1.96 US qt) |
| Total amount | 1.95 L (1.72 Imp qt, 2.06 US qt) |
| Radiator capacity (including all routes) | 1.3 L (1.14 Imp qt, 1.37 US qt) |
| Air filter | Wet type element |
| Fuel | |
| Type | Premium unleaded gasoline only |
| Fuel tank capacity | 10.0 L (2.20 Imp gal, 2.64 US gal) |
| Fuel reserve amount | 1.9 L (0.42 Imp gal, 0.50 US gal) |



| Item | Standard |
|---|--|
| Carburetor | |
| Type/quantity | 5TG1 00 × 1 |
| Manufacturer | KEIHIN |
| Spark plug | |
| Type/manufacturer | CR8E/NGK |
| Spark plug gap | 0.7 ~ 0.8 mm (0.028 ~ 0.031 in) |
| Clutch type | Wet, multiple disc |
| Transmission | |
| Primary reduction system | Spur gear |
| Primary reduction ratio | 62/22 (2.818) |
| Secondary reduction system | Chain drive |
| Secondary reduction ratio | 38/14 (2.714) |
| Transmission type | Constant mesh, 5-speed |
| Operation | Left foot operation |
| Gear ratio | |
| 1st gear | 29/12 (2.416) |
| 2nd gear | 27/14 (1.928) |
| 3rd gear | 25/16 (1.562) |
| 4th gear | 23/18 (1.277) |
| 5th gear | 21/20 (1.050) |
| Chassis | |
| Frame type | Steel tube frame |
| Caster angle | 5° |
| Camber angle | -1.5° |
| Kingpin angle | 15.4° |
| Kingpin offset | 1.0 mm (0.04 in) |
| Trail | 21.0 mm (0.83 in) |
| Tread (STD) front | 950 mm (37.40 in) |
| rear | 900 mm (35.43 in) |
| Toe-in (with tires touching the ground) | 2 ~ 12 mm (0.08 ~ 0.47 in) |
| Tire | |
| Type | Tubeless |
| Size front | AT21 × 7-10 |
| rear | AT20 × 10-9 |
| Manufacturer front | DUNLOP |
| rear | DUNLOP |
| Type front | KT331A Radial |
| rear | KT355 Radial |
| Tire pressure (cold tire) | |
| Maximum load* | 100 kg (220 lb) |
| Off-road riding front | 30 kPa (0.30 kg/cm ² , 4.4 psi) |
| rear | 35 kPa (0.35 kg/cm ² , 5.0 psi) |
| *Load in total weight of cargo, rider and accessories | |

GENERAL SPECIFICATIONS

SPEC






| Item | Standard |
|--|----------------------------|
| Brake | |
| Front brake | Dual disc brake |
| type | Right hand operation |
| operation | |
| Rear brake | Single disc brake |
| type | Right foot operation |
| operation | |
| Suspension | |
| Front suspension | Double wishbone |
| Rear suspension | Swingarm (link suspension) |
| Shock absorber | |
| Front shock absorber | Coil spring/gas-oil damper |
| Rear shock absorber | Coil spring/gas-oil damper |
| Wheel travel | |
| Front wheel travel | 230 mm (9.06 in) |
| Rear wheel travel | 256 mm (10.08 in) |
| Electrical | |
| Ignition system | DC-C.D.I. |
| Generator system | A.C. magneto |
| Battery type | GT7B-4 |
| Battery capacity | 12 V 12 Ah |
| Headlight type | Krypton bulb |
| Bulb voltage/wattage × quantity | |
| Headlight | 12 V 30 W/30 W × 2 |
| Tail/brake light | 12 V 5 W/21 W × 1 |
| Indicator and warning lights | |
| Neutral | 12 V 1.7 W × 1 |
| Coolant temperature | 12 V 1.7 W × 1 |



EBS01002



ENGINE SPECIFICATIONS

| Item | Standard | Limit |
|--|--|--|
| Cylinder head Warp limit *  | ---- | 0.05 mm (0.002 in) |
| Cylinder Bore size | 95.00 ~ 95.01 mm (3.7402 ~ 3.7406 in) | ---- |
| Camshaft Drive method Camshaft cap inside diameter Camshaft journal diameter Camshaft-journal-to-camshaft-cap clearance Camshaft lobe dimensions  | Chain drive (Left) 22.000 ~ 22.021 mm (0.8661 ~ 0.8670 in) 21.967 ~ 21.980 mm (0.8648 ~ 0.8654 in) 0.020 ~ 0.054 mm (0.0008 ~ 0.0021 in) | ---- ---- 0.080 mm (0.0032 in) |
| Intake “A” “B” Exhaust “A” “B” | 31.200 ~ 31.300 mm (1.2283 ~ 1.2323 in) 22.550 ~ 22.650 mm (0.8878 ~ 0.8917 in) 30.950 ~ 31.050 mm (1.2185 ~ 1.2224 in) 22.494 ~ 22.594 mm (0.8856 ~ 0.8895 in) | 31.100 mm (1.2244 in) 22.450 mm (0.8839 in) 30.850 mm (1.2146 in) 22.394 mm (0.8817 in) |
| Camshaft runout limit  | ---- | 0.03 mm (0.0012 in) |
| Timing chain Timing chain type/No. of links Timing chain adjustment method | 98XRH2010-118M Automatic | ---- ---- |







| Item | | Standard | Limit |
|---------------------------------------|----|---------------------------------------|------------------------|
| Valve, valve seat, valve guide | | | |
| Valve clearance (cold) | IN | 0.10 ~ 0.15 mm (0.0039 ~ 0.0059 in) | ---- |
| | EX | 0.20 ~ 0.25 mm (0.0079 ~ 0.0098 in) | ---- |
| Valve dimensions | | | |
| | | | |
| Head Diameter | | Face Width | Seat Width |
| | | Margin Thickness | |
| “A” head diameter | IN | 26.9 ~ 27.1 mm (1.0591 ~ 1.0669 in) | ---- |
| | EX | 27.9 ~ 28.1 mm (1.0984 ~ 1.1063 in) | ---- |
| “B” face width | IN | 2.26 mm (0.0890 in) | ---- |
| | EX | 2.26 mm (0.0890 in) | ---- |
| “C” seat width | IN | 0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in) | 1.6 mm (0.06 in) |
| | EX | 0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in) | 1.6 mm (0.06 in) |
| “D” margin thickness | IN | 1.0 mm (0.0394 in) | 0.85 mm (0.033 in) |
| | EX | 1.0 mm (0.0394 in) | 0.85 mm (0.033 in) |
| Stem outside diameter | IN | 4.475 ~ 4.490 mm (0.1762 ~ 0.1768 in) | 4.445 mm (0.175 in) |
| | EX | 4.965 ~ 4.980 mm (0.1955 ~ 0.1961 in) | 4.935 mm (0.194 in) |
| Guide inside diameter | IN | 4.500 ~ 4.512 mm (0.1772 ~ 0.1776 in) | 4.550 mm (0.179 in) |
| | EX | 5.000 ~ 5.012 mm (0.1969 ~ 0.1973 in) | 5.050 mm (0.199 in) |
| Stem-to-guide clearance | IN | 0.010 ~ 0.037 mm (0.0004 ~ 0.0015 in) | 0.080 mm (0.003 in) |
| | EX | 0.020 ~ 0.047 mm (0.0008 ~ 0.0019 in) | 0.100 mm (0.004 in) |
| Valve stem runout | | ---- | 0.01 mm (0.0004 in) |
| Valve seat width | IN | 0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in) | 1.6 mm (0.06 in) |
| | EX | 0.9 ~ 1.1 mm (0.0354 ~ 0.0433 in) | 1.6 mm (0.06 in) |
| | | | |



| Item | | Standard | Limit |
|---|----|---|---------------------------------|
| Valve spring | | | |
| Free length | IN | 37.03 mm (1.46 in) | 35.17 mm (1.38 in) |
| | EX | 37.68 mm (1.48 in) | 35.79 mm (1.41 in) |
| Set length (valve closed) | IN | 27.87 mm (1.10 in) | ---- |
| | EX | 27.38 mm (1.08 in) | ---- |
| Compressed pressure (installed) | IN | 111.3 ~ 127.9 N (11.35 ~ 13.04 kg, 25.02 ~ 28.75 lb) | ---- |
| | EX | 127.4 ~ 146.4 N (12.99 ~ 14.93 kg, 28.64 ~ 32.91 lb) | ---- |
| Tilt limit * | IN | ---- | 2.5°/1.61 mm (2.5°/0.063 in) |
| | EX | ---- | 2.5°/1.65 mm (2.5°/0.065 in) |
|  | | | |
| Direction of winding (top view) | IN | Clockwise | ---- |
| | EX | Clockwise | ---- |
| Piston | | | |
| Piston to cylinder clearance | | 0.040 ~ 0.065 mm (0.0016 ~ 0.0026 in) | 0.10 mm (0.004 in) |
| Piston size "D" | | 94.945 ~ 94.960 mm (3.7380 ~ 3.7386 in) | ---- |
|  | | | |
| Measuring point "H" | | 10 mm (0.39 in) | ---- |
| Piston off set | | 1.0 mm (0.0394 in) | ---- |
| Offset direction | | Intake side | ---- |
| Piston pin bore inside diameter | | 20.004 ~ 20.015 mm (0.7876 ~ 0.7880 in) | 20.045 mm (0.789 in) |
| Piston pin outside diameter | | 19.991 ~ 20.000 mm (0.7870 ~ 0.7874 in) | 19.971 mm (0.786 in) |
| Piston-pin-to-piston-pin-bore clearance | | 0.004 ~ 0.024 mm (0.0002 ~ 0.0009 in) | 0.074 mm (0.0029 in) |



| Item | Standard | Limit |
|---|---------------------------------------|------------------------|
| Piston rings | | |
| Top ring | | |
|  | | |
| Type | Barrel | ---- |
| Dimensions (B × T) | 1.2 × 3.5 mm (0.047 × 0.138 in) | ---- |
| End gap (installed) | 0.20 ~ 0.30 mm (0.008 ~ 0.012 in) | 0.55 mm (0.022 in) |
| Side clearance | 0.030 ~ 0.065 mm (0.0012 ~ 0.0026 in) | 0.12 mm (0.0047 in) |
| 2nd ring | | |
|  | | |
| Type | Taper | ---- |
| Dimensions (B × T) | 1.00 × 3.35 mm (0.039 × 0.132 in) | ---- |
| End gap (installed) | 0.35 ~ 0.50 mm (0.014 ~ 0.020 in) | 0.85 mm (0.034 in) |
| Side clearance | 0.020 ~ 0.055 mm (0.0008 ~ 0.0022 in) | 0.12 mm (0.0047 in) |
| Oil ring | | |
|  | | |
| Dimensions (B × T) | 2.0 × 2.9 mm (0.079 × 0.114 in) | ---- |
| End gap (installed) | 0.20 ~ 0.50 mm (0.008 ~ 0.020 in) | ---- |
| Crankshaft | | |
|  | | |
| Crank width "A" | 61.95 ~ 62.00 mm (2.439 ~ 2.441 in) | ---- |
| Runout limit C1 | 0.03 mm (0.0012 in) | 0.05 mm (0.002 in) |
| C2 | 0.03 mm (0.0012 in) | 0.05 mm (0.002 in) |
| Big end side clearance "D" | 0.15 ~ 0.45 mm (0.0059 ~ 0.0177 in) | 0.50 mm (0.0197 in) |
| Big end radial clearance "E" | 0.010 ~ 0.025 mm (0.0004 ~ 0.0010 in) | ---- |




| Item | Standard | Limit |
|--|---------------------------------------|------------------------|
| Balancer | | |
| Balancer drive method | Gear | ---- |
| Clutch | | |
| Friction plate 1 (inside dia.: 120 mm) | | |
| Thickness | 2.9 ~ 3.1 mm (0.114 ~ 0.122 in) | 2.8 mm (0.110 in) |
| Quantity | 7 | ---- |
| Friction plate 2 (inside dia.: 128 mm) | | |
| Thickness | 2.9 ~ 3.1 mm (0.114 ~ 0.122 in) | 2.8 mm (0.110 in) |
| Quantity | 1 | ---- |
| Clutch plate | | |
| Thickness | 1.5 ~ 1.7 mm (0.059 ~ 0.067 in) | ---- |
| Quantity | 7 | ---- |
| Max. warpage | ---- | 0.2 mm (0.0079 in) |
| Clutch spring | | |
| Free length | 51.8 mm (2.04 in) | 50.0 mm (1.97 in) |
| Quantity | 6 | ---- |
| Clutch housing thrust clearance | 0.10 ~ 0.35 mm (0.0039 ~ 0.0138 in) | ---- |
| Clutch housing radial clearance | 0.010 ~ 0.044 mm (0.0004 ~ 0.0017 in) | ---- |
| Clutch release method | Inner push, cam push | ---- |
| Push rod 2 bending limit | 0.1 mm (0.004 in) | ---- |
| Transmission | | |
| Main axle deflection limit | ---- | 0.08 mm (0.0031 in) |
| Drive axle deflection limit | ---- | 0.08 mm (0.0031 in) |
| Shifter | | |
| Shifter type | Shift drum and guide bar | ---- |
| Max. shift fork guide bar bending | ---- | 0.05 mm (0.002 in) |
| Decompression device | | |
| Device type | Auto decomp | ---- |
| Air filter oil grade | Engine oil | ---- |




| Item | Standard | Limit |
|---|---|------------------------|
| Carburetor | | |
| I. D. mark | 5TG1 00 | ---- |
| Main jet (M.J) | #158 | ---- |
| Main air jet (M.A.J) | ø1.0 | ---- |
| Jet needle/clip position (J.N) | NDSR/4 | ---- |
| Cutaway (C.A) | 1.5 | ---- |
| Pilot air jet (P.A.J.1) | #100 | ---- |
| Pilot outlet (P.O) | ø0.9 | ---- |
| Pilot jet (P.J) | #42 | ---- |
| Bypass 1 (B.P.1) | ø1.0 | ---- |
| Valve seat size (V.S) | ø3.8 | ---- |
| Starter jet (G.S.1) | #90 | ---- |
| Float height (F.H) | 8 mm (0.31 in) | ---- |
| Engine idle speed | 1,750 ~ 1,850 r/min | ---- |
| Intake vacuum | 34.7 ~ 37.3 kPa (260 ~ 280 mmHg, 10.2 ~ 11.0 inHg) | ---- |
| Throttle position sensor | | |
| Resistance | 4 ~ 6 kΩ at 20 °C | ---- |
| Oil filter type | | |
| | Paper | ---- |
| Oil pump | | |
| Oil pump type | Trochoid | ---- |
| Inner-rotor-to-outer-rotor-tip clearance | 0.07 ~ 0.12 mm (0.0028 ~ 0.0047 in) | 0.20 mm (0.0079 in) |
| Outer-rotor-to-oil-pump-housing clearance | 0.09 ~ 0.17 mm (0.0035 ~ 0.0067 in) | 0.24 mm (0.0094 in) |
| Bypass valve setting pressure | 40.0 ~ 80.0 kPa (300 ~ 602 mmHg, 11.8 ~ 23.7 inHg) | ---- |
| Cooling system | | |
| Radiator core | | |
| Width | 300 mm (11.8 in) | ---- |
| Height | 188 mm (7.4 in) | ---- |
| Depth | 24 mm (0.94 in) | ---- |
| Radiator cap opening pressure | 107.9 ~ 137.3 kPa (1.079 ~ 1.373 kg/cm ² , 15.35 ~ 19.53 psi) | ---- |
| Radiator capacity | 0.58 L (0.51 Imp qt, 0.61 US qt) | ---- |
| Coolant reservoir | | |
| Capacity | 0.29 L (0.26 Imp qt, 0.31 US qt) | ---- |
| From low to full level | 0.16 L (0.14 Imp qt, 0.17 US qt) | ---- |
| Water pump | | |
| Type | Single-suction centrifugal pump | ---- |



Lubrication chart



**Cylinder head tightening sequence**



EBS01003

CHASSIS SPECIFICATIONS

| Item | | Standard | Limit |
|-------------------------|---------|-----------------------------------|---------------------|
| Steering system | | | |
| Steering bearing type | | Ball and race bearing | ---- |
| Front suspension | | | |
| Shock absorber travel | | 110 mm (4.33 in) | ---- |
| Fork spring free length | | 265 mm (10.43 in) | ---- |
| Spring fitting length | | 255 mm (10.04 in) | ---- |
| Spring rate (K1) | | 19.6 N/mm (2.00 kg/mm, 112 lb/in) | ---- |
| Spring rate (K2) | | 39.2 N/mm (4.00 kg/mm, 224 lb/in) | ---- |
| Optional spring | | No | ---- |
| Rear suspension | | | |
| Shock absorber travel | | 116.0 (4.57 in) | ---- |
| Spring free length | | 259 mm (10.20 in) | ---- |
| Spring fitting length | | 244 mm (9.61 in) | ---- |
| Spring rate (K1) | | 46.0 N/mm (4.69 kg/mm, 263 lb/in) | ---- |
| Stroke (K1) | | 0 ~ 116.0 mm (0 ~ 4.57 in) | ---- |
| Optional spring | | No | ---- |
| Swingarm | | | |
| Free play limit | end | ---- | 1 mm (0.04 in) |
| | side | ---- | 1 mm (0.04 in) |
| Front wheel | | | |
| Type | | Panel wheel | ---- |
| Rim size | | 10 × 5.5 AT | ---- |
| Rim material | | Aluminum | ---- |
| Rim runout limit | radial | ---- | 2.0 mm (0.08 in) |
| | lateral | ---- | 2.0 mm (0.08 in) |
| Rear wheel | | | |
| Type | | Panel wheel | ---- |
| Rim size | | 9 × 8.5 AT | ---- |
| Rim material | | Aluminum | ---- |
| Rim runout limit | radial | ---- | 2.0 mm (0.08 in) |
| | lateral | ---- | 2.0 mm (0.08 in) |
| Drive chain | | | |
| Type/manufacturer | | 520MXV/DAIDO | ---- |
| Link quantity | | 96 | ---- |
| Drive chain slack | | 25 ~ 35 mm (0.98 ~ 1.38 in) | ---- |



| Item | Standard | Limit |
|------------------------------------|---------------------------------|---------------------|
| Front disc brake | | |
| Type | Dual | ---- |
| Disc outside diameter × thickness | 161.0 × 3.5 mm (6.34 × 0.14 in) | ---- |
| Pad thickness inner | 4.5 mm (0.18 in) | 1.0 mm (0.04 in) |
| Pad thickness outer | 4.5 mm (0.18 in) | 1.0 mm (0.04 in) |
| Master cylinder inside diameter | 12.7 mm (0.50 in) | ---- |
| Caliper cylinder inside diameter | 27 mm (1.06 in) | ---- |
| Brake fluid type | DOT 4 | ---- |
| Rear disc brake | | |
| Type | Single | ---- |
| Disc outside diameter × thickness | 200.0 × 3.6 mm (7.87 × 0.14 in) | ---- |
| Pad thickness inner | 4.5 mm (0.18 in) | 1.0 mm (0.04 in) |
| Pad thickness outer | 4.5 mm (0.18 in) | 1.0 mm (0.04 in) |
| Master cylinder inside diameter | 12.7 mm (0.50 in) | ---- |
| Caliper cylinder inside diameter | 33.96 mm (1.34 in) | ---- |
| Brake fluid type | DOT 4 | ---- |
| Brake lever and brake pedal | | |
| Brake pedal position | 11.7 mm (0.46 in) | ---- |
| Parking brake cable end length | 56 ~ 60 mm (2.20 ~ 2.36 in) | ---- |
| Clutch lever free play (lever end) | 8 ~ 13 mm (0.31 ~ 0.51 in) | ---- |
| Throttle lever free play | 2 ~ 4 mm (0.08 ~ 0.16 in) | ---- |
| Speed limiter length | Less than 12 mm (0.47 in) | ---- |
| Shift pedal height | 25 mm (0.98 in) | ---- |



EBS01004

ELECTRICAL SPECIFICATIONS

| Item | Standard | Limit |
|--------------------------------|---|---------------------|
| Voltage | 12 V | ---- |
| Ignition system | | |
| Ignition timing (B.T.D.C.) | 7.5°/1,800 r/min | ---- |
| Advancer type | Digital type | ---- |
| C.D.I. | | |
| C.D.I. unit model/manufacturer | 5TG/MORIC | ---- |
| Pickup coil resistance/color | 248 ~ 372 Ω at 20 °C (68 °F) red–white | ---- |
| Ignition coil | | |
| Model/manufacturer | J0474/DENSO | ---- |
| Minimum ignition spark gap | 6 mm (0.24 in) | ---- |
| Primary winding resistance | 0.08 ~ 0.10 Ω at 20 °C (68 °F) | ---- |
| Secondary winding resistance | 4.56 ~ 6.84 kΩ at 20 °C (68 °F) | ---- |
| Charging system | | |
| Type | A.C. magneto | ---- |
| Model/manufacturer | F5TG/MORIC | ---- |
| Nominal output | 14 V 120 W at 5,000 r/min | ---- |
| Lighting coil resistance/color | 0.224 ~ 0.336 Ω at 20 °C (68 °F) yellow–ground | ---- |
| Charging coil resistance/color | 0.288 ~ 0.432 Ω at 20 °C (68 °F) white–ground | ---- |
| Rectifier/regulator | | |
| Type | Semi conductor-short circuit | ---- |
| Model/manufacturer | SH712AB/SHINDENGEN | ---- |
| No load regulated voltage (DC) | 14.1 ~ 14.9 V | ---- |
| (AC) | 13.0 ~ 14.0 V | ---- |
| Rectifier capacity (DC) | 8.0 A | ---- |
| (AC) | 12.0 A | ---- |
| Electric starter system | | |
| Type | Constant mesh type | ---- |
| Starter motor | | |
| Model/manufacturer | SM-14/MITSUBA | ---- |
| Output | 0.5 kW | ---- |
| Armature coil resistance | 0.004 ~ 0.005 Ω at 20 °C (68 °F) | ---- |
| Brush overall length | 10 mm (0.39 in) | 3.5 mm (0.14 in) |
| Spring force | 7.16 ~ 9.52 N (730 ~ 971 gf, 25.77 ~ 34.27 oz) | ---- |
| Commutator diameter | 28 mm (1.10 in) | 27 mm (1.06 in) |
| Mica undercut | 0.7 mm (0.03 in) | ---- |








| Item | Standard | Limit |
|---------------------------------|---------------------------------|-------|
| Starter relay | | |
| Model/manufacturer | 2768079-A/JIDECO | ---- |
| Amperage rating | 180 A | ---- |
| Coil winding resistance | 4.18 ~ 4.62 Ω | ---- |
| Thermo switch | | |
| Thermo switch 1 | | |
| Model/manufacturer | 5GH/NIPPON THERMOSTAT | ---- |
| Opening temperature | 95 ~ 101 °C (203.0 ~ 213.8 °F) | ---- |
| Closing temperature | 89 ~ 95 °C (192.2 ~ 203.0 °F) | ---- |
| Thermo switch 2 | | |
| Model/manufacturer | 5LP/NIPPON THERMOSTAT | ---- |
| Opening temperature | 117 ~ 123 °C (242.6 ~ 253.4 °F) | ---- |
| Closing temperature | 112 ~ 118 °C (233.6 ~ 244.4 °F) | ---- |
| Circuit breaker | | |
| Type | Fuse | ---- |
| Amperage for individual circuit | | |
| Fuse | 15 A \times 1 | ---- |
| Reserve | 15 A \times 1 | ---- |



EBS01005

TIGHTENING TORQUES







ENGINE TIGHTENING TORQUES

| Part to be tightened | Part name | Thread size | Q'ty | Tightening torque | | | Remarks |
|---|------------|-------------|------|-------------------|--------|---------|--|
| | | | | Nm | m · kg | ft · lb | |
| Spark plug | — | M10S | 1 | 13 | 1.3 | 9.4 |   |
| Cylinder head cover | Bolt | M6 | 2 | 10 | 1.0 | 7.2 | |
| Camshaft cap | Bolt | M6 | 10 | 10 | 1.0 | 7.2 | |
| Cylinder head blind plug screw | Screw | M12 | 1 | 37 | 3.7 | 27 | |
| Timing chain tensioner | Bolt | M6 | 2 | 10 | 1.0 | 7.2 | |
| Timing chain tensioner cap | Bolt | M6 | 1 | 7 | 0.7 | 5.1 | |
| Timing chain guide (intake) | Bolt | M6 | 2 | 10 | 1.0 | 7.2 | |
| Cylinder head (exhaust pipe) | Stud bolt | M8 | 1 | 15 | 1.5 | 11 | |
| Cylinder head (timing chain side) | Stud bolt | M6 | 2 | 7 | 0.7 | 5.1 | |
| Cylinder head | Bolt | M10 | 4 | See NOTE. ** | | | |
| | Nut | M6 | 2 | 10 | 1.0 | 7.2 | |
| Parking brake cable and clutch cable holder | Bolt | M6 | 1 | 10 | 1.0 | 7.2 |   |
| Cylinder | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | |
| Engine oil drain bolt (oil tank) | Bolt | M8 | 1 | 19 | 1.9 | 13 | |
| Engine oil drain bolt (engine) | Bolt | M10 | 1 | 20 | 2.0 | 14 | |
| Oil pump | Bolt | M6 | 3 | 10 | 1.0 | 7.2 | |
| Oil pump housing cover | Screw | M4 | 1 | 2 | 0.2 | 1.4 | |
| Engine oil drain bolt (oil filter) | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | |
| Oil filter cover | Bolt | M6 | 2 | 10 | 1.0 | 7.2 | |
| Oil delivery pipe 1 | Union bolt | M10 | 1 | 20 | 2.0 | 14 | |
| | Union bolt | M8 | 2 | 18 | 1.8 | 13 | |
| Oil delivery pipe 2 | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | |
| Oil pipe 1 and crankcase cover | Bolt | M6 | 1 | 8 | 0.8 | 8 | |
| Oil pipe 2 and left crankcase | Bolt | M6 | 1 | 8 | 0.8 | 8 | |
| Oil pipe 2 and oil tank | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | |
| Oil gallery bolt | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | |
| Exhaust pipe | Bolt | M8 | 1 | 24 | 2.4 | 17 | |
| | Nut | M8 | 1 | 13 | 1.3 | 9.4 | |
| Exhaust pipe protector | Screw | M6 | 2 | 7 | 0.7 | 5.1 | |
| Muffler protector | Screw | M6 | 2 | 7 | 0.7 | 5.1 | |
| Muffler | Bolt | M8 | 2 | 34 | 3.4 | 24 | |
| Muffler and exhaust pipe | Bolt | M8 | 1 | 20 | 2.0 | 14 | |
| Spark arrester | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | |
| Silencer cap | Bolt | M6 | 1 | 10 | 1.0 | 7.2 |  |
| Radiator | Bolt | M6 | 4 | 7 | 0.7 | 5.1 | |
| Radiator fan | Bolt | M6 | 3 | 9 | 0.9 | 6.5 | |
| Coolant drain bolt | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | |
| Impeller | — | M8 | 1 | 14 | 1.4 | 10 | |
| Water pump inlet pipe | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | |

TIGHTENING TORQUES

SPEC



| Part to be tightened | Part name | Thread size | Q'ty | Tightening torque | | | Remarks |
|---|-----------|-------------|------|-------------------|--------|---------|---|
| | | | | Nm | m · kg | ft · lb | |
| Cylinder head water jacket | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | Use a lock washer. |
| Water pump housing cover | Bolt | M6 | 4 | 10 | 1.0 | 7.2 | |
| Coolant reservoir | Bolt | M6 | 2 | 7 | 0.7 | 5.1 | |
| Clutch cover | Bolt | M6 | 7 | 10 | 1.0 | 7.2 | |
| Clutch spring | Bolt | M6 | 6 | 8 | 0.8 | 8 | |
| Clutch boss | Nut | M20 | 1 | 75 | 7.5 | 54 | |
| Push lever shaft plate | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | |
| Clutch cable holder | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | |
| Crankcase cover | Bolt | M6 | 8 | 10 | 1.0 | 7.2 | |
| Parking brake cable holder and crankcase cover | Bolt | M6 | 2 | 10 | 1.0 | 7.2 | |
| Left crankcase | Bolt | M6 | 11 | 12 | 1.2 | 8.7 |  |
| Oil strainer | Bolt | M6 | 2 | 10 | 1.0 | 7.2 | |
| Crankcase bearing retainer | Screw | M6 | 3 | 12 | 1.2 | 8.7 | |
| | Screw | M6 | 4 | 12 | 1.2 | 8.7 | |
| Primary drive gear | Bolt | M6 | 7 | 10 | 1.0 | 7.2 |  |
| | Nut | M20 | 1 | 75 | 7.5 | 54 | |
| Balancer driven gear | Nut | M14 | 1 | 50 | 5.0 | 36 | Use a lock washer. |
| Drive sprocket | Nut | M20 | 1 | 75 | 7.5 | 54 | Use a lock washer. |
| Drive axle oil seal retainer | Bolt | M6 | 2 | 10 | 1.0 | 7.2 |  |
| Torque limiter cover | Bolt | M6 | 2 | 10 | 1.0 | 7.2 |  |
| A.C. magneto cover | Bolt | M6 | 9 | 10 | 1.0 | 7.2 | |
| A.C. magneto rotor | Nut | M12 | 1 | 65 | 6.5 | 47 | |
| Stator coil | Bolt | M5 | 2 | 7 | 0.7 | 5.1 | |
| A.C. magneto lead holder | Bolt | M5 | 2 | 7 | 0.7 | 5.1 | |
| Pickup coil | Bolt | M6 | 2 | 10 | 1.0 | 7.2 | |
| Starter clutch | Bolt | M6 | 6 | 16 | 1.6 | 11 | |
| Shift drum segment | Bolt | M8 | 1 | 30 | 3.0 | 22 | |
| Shift guide | Bolt | M6 | 2 | 10 | 1.0 | 7.2 | |
| Stopper lever | Bolt | M6 | 1 | 10 | 1.0 | 7.2 | |
| Shift pedal | Bolt | M6 | 1 | 12 | 1.2 | 8.7 |  |
| Throttle cable cover (carburetor) | Bolt | M5 | 2 | 4 | 0.4 | 2.9 | |
| Carburetor joint clamp screw (carburetor side) | Screw | M5 | 1 | 3 | 0.4 | 2.9 | |
| Carburetor joint clamp screw (cylinder head side) | Screw | M4 | 1 | 3 | 0.3 | 2.2 | |
| Carburetor clamp screw (air intake duct side) | Screw | M6 | 1 | 3 | 0.3 | 2.2 |  |
| Neutral switch | — | M10 | 1 | 20 | 2.0 | 14 | |
| Thermo switch 1 | — | M18 | 1 | 28 | 2.8 | 20 | |

TIGHTENING TORQUES

SPEC

| Part to be tightened | Part name | Thread size | Q'ty | Tightening torque | | | Remarks |
|---|-----------|-------------|------|-------------------|--------|---------|---------|
| | | | | Nm | m · kg | ft · lb | |
| Thermo switch 2 | — | M18 | 1 | 28 | 2.8 | 20 | |
| Starter motor | Bolt | M6 | 2 | 10 | 1.0 | 7.2 | |
| Starter motor lead | Nut | M6 | 1 | 7 | 0.7 | 5.1 | |
| Bush holder assembly and rear bracket nut | Nut | M6 | 1 | 7 | 0.7 | 5.1 | |

NOTE:

*1: Tighten the cylinder head bolts to 30 Nm (3.0 m · kg, 22 ft · lb) in the proper tightening sequence, remove and retighten the cylinder head bolts to 20 Nm (2.0 m · kg, 14 ft · lb) in the proper tightening sequence, and then tighten the cylinder head bolts further in two steps of 90° to reach the specified angle of 180° in the proper tightening sequence.



EBS01006

CHASSIS TIGHTENING TORQUES









| Part to be tightened | Thread size | Tightening torque | | | Remarks |
|--|-------------|-------------------|--------|---------|--------------------|
| | | Nm | m · kg | ft · lb | |
| Engine stay and frame | M8 | 33 | 3.3 | 24 | Use a lock washer. |
| Engine stay and engine upper bracket | M8 | 26 | 2.6 | 19 | |
| Engine upper bracket and engine | M10 | 40 | 4.0 | 29 | |
| Engine lower bracket and engine | M10 | 66 | 6.6 | 48 | |
| Engine and frame | M10 | 66 | 6.6 | 48 | |
| Engine lower bracket and frame | M8 | 38 | 3.8 | 27 | |
| Swingarm pivot shaft, engine, and frame | M16 | 100 | 10 | 72 | |
| Rear shock absorber and frame | M12 | 80 | 8.0 | 58 | |
| Rear shock absorber locknut | M50 | 45 | 4.5 | 32 | |
| Relay arm and swingarm | M12 | 55 | 5.5 | 40 | |
| Connecting arm and frame | M12 | 55 | 5.5 | 40 | |
| Relay arm and rear shock absorber | M12 | 43 | 4.3 | 31 | |
| Relay arm and connecting arm | M12 | 55 | 5.5 | 40 | |
| Hub, brake caliper bracket, and swingarm | M12 | 85 | 8.5 | 61 | |
| Drive chain adjusting bolt and locknut | M8 | 16 | 1.6 | 11 | |
| Front shock absorber and frame | M10 | 45 | 4.5 | 32 | |
| Front shock absorber and lower front arm | M10 | 45 | 4.5 | 32 | |
| Front shock absorber locknut | M50 | 30 | 3.0 | 22 | |
| Upper front arm and frame | M10 | 38 | 3.8 | 27 | |
| Lower front arm and frame | M10 | 55 | 5.5 | 40 | |
| Steering stem, pitman arm, and frame | M14 | 180 | 18 | 130 | |
| Steering stem bushing and frame | M8 | 23 | 2.3 | 17 | |
| Steering stem and handlebar holder | M8 | 23 | 2.3 | 17 | |
| Tie-rod end and locknut | M10 | 15 | 1.5 | 11 | |
| Steering knuckle and front wheel hub | M14 | 70 | 7.0 | 50 | |
| Steering knuckle and front arm (upper and lower) | M10 | 25 | 2.5 | 18 | |
| Steering knuckle and tie-rod ball joint | M10 | 25 | 2.5 | 18 | |
| Pitman arm and tie-rod ball joint | M10 | 25 | 2.5 | 18 | |
| Frame and bearing retainer | M42 | 65 | 6.5 | 47 | |
| Fuel tank and fuel cock | M6 | 4 | 0.4 | 2.9 | |
| Fuel tank and frame | M6 | 7 | 0.7 | 5.1 | |
| Front wheel and front wheel hub | M10 | 45 | 4.5 | 32 | |
| Steering knuckle and front brake caliper bracket | M8 | 28 | 2.8 | 20 | |
| Front brake disc and front wheel hub | M8 | 28 | 2.8 | 20 | |
| Rear axle and rear wheel hub | M14 | 120 | 12 | 85 | |
| Rear brake caliper and brake caliper bracket | M8 | 31 | 3.1 | 22 | |
| Rear wheel and rear wheel hub | M10 | 45 | 4.5 | 32 | |
| Driven sprocket and sprocket bracket | M10 | 55 | 5.5 | 40 | |
| Front brake pipe nut | M10 | 19 | 1.9 | 13 | |
| Front brake master cylinder and handlebar | M6 | 7 | 0.7 | 5.1 | |
| Parking brake lever and clutch lever | M6 | 7 | 0.7 | 5.1 | |



TIGHTENING TORQUES

SPEC



| Part to be tightened | Thread size | Tightening torque | | | Remarks |
|---|-------------|-------------------|--------|---------|---|
| | | Nm | m · kg | ft · lb | |
| Front brake master cylinder and brake lever | M6 | 6 | 0.6 | 4.3 | |
| Front brake master cylinder and brake hose | M10 | 27 | 2.7 | 19 | |
| Brake hose joint and frame | M6 | 10 | 1.0 | 7.2 | |
| Bleed screw | M8 | 6 | 0.6 | 4.3 | |
| Front brake pad retaining bolt | M10 | 18 | 1.8 | 13 |  |
| Front brake caliper and brake hose | M10 | 27 | 2.7 | 19 | |
| Rear brake caliper retaining bolt | M8 | 23 | 2.3 | 17 |  |
| Parking brake case bracket and parking brake case | M8 | 23 | 2.3 | 17 |  |
| Rear axle ring nut | M36 | 100 | 10.0 | 72 |  |
| Rear axle ring nut set bolt | M6 | 7 | 0.7 | 5.1 |  |
| Rear brake pad retaining bolt | M8 | 18 | 1.8 | 13 | Use a lock washer. |
| Rear brake caliper and brake hose | M10 | 30 | 3.0 | 22 | |
| Rear brake master cylinder and frame | M8 | 20 | 2.0 | 14 | |
| Rear brake master cylinder and brake hose | M10 | 30 | 3.0 | 22 | |
| Parking brake adjusting bolt and locknut | M8 | 16 | 1.6 | 11 | |
| Rear brake disc and brake disc bracket | M8 | 28 | 2.8 | 20 |  |
| Rear brake fluid reservoir cover and bracket | M6 | 11 | 1.1 | 8 | |
| Rear brake fluid reservoir and bracket | M6 | 4 | 0.4 | 2.9 | |
| Front bumper and frame | M8 | 31 | 3.1 | 22 | |
| Front fender and frame | M6 | 7 | 0.7 | 5.1 | |
| Side cover and frame | M6 | 7 | 0.7 | 5.1 | |
| Side cover, rear fender, and frame | M6 | 7 | 0.7 | 5.1 | |
| Rear fender and frame | M6 | 7 | 0.7 | 5.1 | |
| Rear fender stay and rear fender | M6 | 7 | 0.7 | 5.1 | |
| Front fender stay and front fender | M6 | 7 | 0.7 | 5.1 | |
| Rear carrier bar and frame | M8 | 33 | 3.3 | 24 | |
| Footrest and frame | M10 | 65 | 6.5 | 48 | |
| Foot protector and footrest | M6 | 13 | 1.3 | 9.4 | |
| Foot protector and footrest | M8 | 16 | 1.6 | 11 | |
| Foot protector and frame | M8 | 16 | 1.6 | 11 | |
| Battery holding bracket and frame | M6 | 7 | 0.7 | 5.1 | |
| Air filter case and frame | M6 | 7 | 0.7 | 5.1 | |
| Carburetor joint clamp screw | M4 | 3 | 0.3 | 2.2 | |
| Headlight and frame | M6 | 7 | 0.7 | 5.1 | |
| Tail/brake light bracket and frame | M6 | 7 | 0.7 | 5.1 | |
| Tail/brake light bracket and tail/brake light | M6 | 7 | 0.7 | 5.1 | |
| Drive chain guide roller and frame | M8 | 19 | 1.9 | 13 | |
| Engine skid plate and frame | M6 | 7 | 0.7 | 5.1 |  |
| Main frame and rear frame | M10 | 54 | 5.4 | 39 |  |

HOW TO USE THE CONVERSION TABLE/ GENERAL TIGHTENING TORQUE SPECIFICATIONS



EBS00022

HOW TO USE THE CONVERSION TABLE

All specification data in this manual are listed in SI and METRIC UNITS.

Use this table to convert METRIC unit data to IMPERIAL unit data.

Ex.

| METRIC | | MULTIPLIER | | IMPERIAL |
|--------|---|------------|---|----------|
| ** mm | × | 0.03937 | = | ** in |
| 2 mm | × | 0.03937 | = | 0.08 in |


CONVERSION TABLE

| METRIC TO IMPERIAL | | | |
|---------------------|-----------------------|------------|---------------------------|
| | Metric unit | Multiplier | Imperial unit |
| Torque | m · kg | 7.233 | ft · lb |
| | m · kg | 86.794 | in · lb |
| | cm · kg | 0.0723 | ft · lb |
| | cm · kg | 0.8679 | in · lb |
| Weight | kg | 2.205 | lb |
| | g | 0.03527 | oz |
| Speed | km/hr | 0.6214 | mph |
| Distance | km | 0.6214 | mi |
| | m | 3.281 | ft |
| | m | 1.094 | yd |
| | cm | 0.3937 | in |
| | mm | 0.03937 | in |
| Volume/ Capacity | cc (cm ³) | 0.03527 | oz (IMP liq.) |
| | cc (cm ³) | 0.06102 | cu · in |
| | lt (liter) | 0.8799 | qt (IMP liq.) |
| | lt (liter) | 0.2199 | gal (IMP liq.) |
| Misc. | kg/mm | 55.997 | lb/in |
| | kg/cm ² | 14.2234 | psi (lb/in ²) |
| | Centigrade (°C) | 9/5+32 | Fahrenheit (°F) |

EBS00023

GENERAL TIGHTENING TORQUE SPECIFICATIONS

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided for each chapter of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross pattern and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.



A: Distance between flats

B: Outside thread diameter

| A (nut) | B (bolt) | General tightening torques | | |
|------------|-------------|----------------------------|--------|---------|
| | | Nm | m · kg | ft · lb |
| 10 mm | 6 mm | 6 | 0.6 | 4.3 |
| 12 mm | 8 mm | 15 | 1.5 | 11 |
| 14 mm | 10 mm | 30 | 3.0 | 22 |
| 17 mm | 12 mm | 55 | 5.5 | 40 |
| 19 mm | 14 mm | 85 | 8.5 | 61 |
| 22 mm | 16 mm | 130 | 13.0 | 94 |



EBS00024

LUBRICATION POINTS AND LUBRICANT TYPES

ENGINE

| Lubrication point | Lubricant |
|--|--|
| Oil seal lips | |
| O-rings | |
| Bearings | |
| Crankshaft pins | |
| Valve stems (intake and exhaust) | |
| Valve stem ends (intake and exhaust) | |
| Valve lifters (intake and exhaust) | |
| Camshafts (intake and exhaust) | |
| Camshaft cap bolt | |
| Cylinder head bolt | |
| Piston surfaces | |
| Piston pins | |
| Auto decomp | |
| Auto decompression lever | |
| Water pump impeller shaft | |
| Oil pump rotors (inner and outer) and oil pump housing | |
| Oil pump drive gear | |
| Connecting rod (bearing) | |
| Torque limiter | |
| Starter idle gear inner surface and shaft | |
| Starter clutch inner surface | |
| Primary driven gear | |
| Push rod 1, 2 and ball | |
| Push lever shaft | |
| Push rod bearing and plane washer | |
| Transmission gears (wheel and pinion) | |
| Shift forks and shift fork guide bars | |
| Transmission gears (wheel and pinion) splines | |
| Shift drum shaft | |
| Shift shaft | |
| Shift shaft assembly | |
| Cylinder head cover mating surface | Sealant (Quick Gasket®) Yamaha bond No.1215 |

LUBRICATION POINTS AND LUBRICANT TYPES

SPEC


| Lubrication point | Lubricant |
|---|--|
| Crankcase mating surfaces | Sealant (Quick Gasket®) Yamaha bond No.1215 |
| Cylinder head and cylinder head cover mating surfaces | Sealant (Quick Gasket®) Yamaha bond No.1215 |
| AC magneto lead grommet (AC magneto cover) | Sealant (Quick Gasket®) Yamaha bond No.1215 |



EBS00025


COOLANT FLOW DIAGRAMS

- ① Radiator inlet hose
- ② Radiator
- ③ Radiator fan
- ④ Radiator outlet hose
- ⑤ Water pump inlet pipe
- ⑥ Water pump
- ⑦ Thermo switch 1
- ⑧ Thermo switch 2
- ⑨ Cylinder head water jacket





- A** Install the radiator outlet hose with the white paint mark parallel to the ground as shown.
- B** Install the radiator outlet hose completely on the radiator pipe until the hose contacts the flange of the pipe.
- C** 30 mm (1.18 in)
- D** Install the radiator outlet hose onto the water pump inlet pipe until the end of the hose reaches the middle of the blue paint mark on the pipe.
- E** Align the white paint mark on the radiator inlet hose with the projection on the radiator pipe.
- F** Install the radiator inlet hose onto the radiator pipe until the end of the hose contacts the projection of the pipe.
- G** Install the radiator inlet hose onto the outlet pipe of the cylinder head water jacket until the end of the hose reaches the middle of the blue paint mark on the pipe.






EBS00026

OIL FLOW DIAGRAMS


- ① Intake camshaft
- ② Exhaust camshaft
- ③ Oil filter element
- ④ Oil tank
- ⑤ Oil pipe 1
- ⑥ Oil pipe 2
- ⑦ Main axle
- ⑧ Drive axle
- ⑨ Oil delivery pipe 1

- ⑩ Oil pump
- ⑪ Oil strainer





- ① Camshaft
- ② Oil filter element
- ③ Crankshaft
- ④ Main axle
- ⑤ Drive axle
- ⑥ Oil delivery pipe 2
- ⑦ Connecting rod







EBS00028



CABLE ROUTING

- ① Parking brake cable
- ② Clutch cable
- ③ Clutch switch lead
- ④ Handlebar switch lead
- ⑤ Front brake light switch lead
- ⑥ Throttle switch lead
- ⑦ Front brake hose
- ⑧ Throttle cable






- A** Fasten the clutch switch lead and handlebar switch lead to the handlebar with the plastic band.
- B** Fasten the front brake light switch lead and throttle switch lead to the handlebar with the plastic band.
- C** Less than 10 mm (0.39 in)
- D** Make sure that there is no slack in the throttle switch lead.
- E** Fasten the throttle switch lead to the handlebar with the plastic band.






- | | |
|---------------------------------|-------------------------------|
| ① Throttle cable | ⑫ C.D.I. unit leads |
| ② Front brake hose | ⑬ Rectifier/regulator coupler |
| ③ Front brake light switch lead | ⑭ Brake pipe |
| ④ Throttle switch lead | ⑮ Rectifier/regulator |
| ⑤ Clutch cable | ⑯ C.D.I. unit |
| ⑥ Parking brake cable | ⑰ Diode 1 |
| ⑦ Clutch switch lead | ⑱ Diode 2 |
| ⑧ Handlebar switch lead | ⑲ Thermo switch 1 lead |
| ⑨ Radiator fan breather hose | ⑳ Headlight coupler (right) |
| ⑩ Thermo switch 2 lead | ㉑ Main switch coupler |
| ⑪ Headlight coupler (left) | |






- [A] Pass the throttle cable through the cable guide.
- [B] Pass the throttle cable, leads (front brake light switch, throttle switch, clutch switch, and handlebar switch), parking brake cable, and clutch cable through the cable guide in the order listed.
- [C] Pass the throttle cable through the steering stem cable guide.
- [D] 30 ~ 50 mm (1.18 ~ 1.97 in)
- [E] Fasten the front brake light switch lead, throttle switch lead, clutch switch lead, and handlebar switch lead with the plastic band and then place the end of the band under the fuel tank cover.
- [F] Pass the radiator fan breather hose through the hose guide.
- [G] Fasten the radiator fan breather hose, clutch cable, and parking brake cable with the clamp.






- [H] Slide the rubber cover over the couplers (front brake light switch, throttle switch, clutch switch, and handlebar switch) and fasten the center of the cover with the plastic band.
- [I] Pass the clutch cable and parking brake cable through the cable guide in this order.
- [J] Fasten the radiator fan breather hose with the holder on the radiator grill.
- [K] Install the brake hose cover so that the slits in the cover fit over the brake hose grommet.






- | | | |
|---------------------------------|--------------------------|-------------------------------|
| ① Indicator coupler | ⑫ Battery negative lead | ⑳ Indicator leads |
| ② Radiator fan motor coupler | ⑬ Starter motor lead | ㉑ Cylinder head breather hose |
| ③ Thermo switch 2 | ⑭ Neutral switch lead | |
| ④ Fuel tank breather hose | ⑮ A.C. magneto lead | |
| ⑤ Radiator fan motor lead | ⑯ Oil tank breather hose | |
| ⑥ Radiator fan breather hose | ⑰ Neutral switch coupler | |
| ⑦ Wire harness | ⑱ A.C. magneto coupler | |
| ⑧ Fuel hose | ㉒ Front brake hose | |
| ⑨ Throttle position sensor lead | ㉓ Throttle cable | |
| ⑩ Carburetor switch lead | ㉔ Parking brake cable | |
| ⑪ Crankcase breather hose | ㉕ Clutch cable | |






- A** Route the neutral switch lead, A.C. magneto lead, and radiator fan motor lead under the frame.
- B** Fasten the wire harness, thermo switch 2 lead, A.C. magneto lead, and neutral switch lead with the plastic band and then face the end of the band inward between the frame tubes.
- C** Route the fuel tank breather hose behind the steering stem.
- D** 7 ~ 21 mm (0.28 ~ 0.83 in)
- E** 50 ~ 70 mm (1.97 ~ 2.76 in)
- F** Fasten the wire harness, throttle position sensor lead, and carburetor switch lead with the plastic band. Make sure that there is no slack in the throttle position sensor lead and carburetor switch lead along the frame as shown.
- G** Install the cylinder head breather hose with the paint mark facing to the left.
- H** More than 15 mm (0.59 in)
- I** Fasten the wire harness with the plastic band on the white tape and then face the end of the plastic band inward.






- J** Fasten the negative battery lead and starter motor lead with the plastic band and then face the end of the plastic band inward.
- K** Fasten the starter motor lead to the negative battery lead at the mark on the battery lead with a plastic band. Then, fasten the starter motor lead and negative battery lead to the frame with a plastic band and face the end of the band inward.
- L** Install the crankcase breather hose with the paint mark facing outward.

- M** Fasten the neutral switch lead with the lead holder.
- N** Fasten the neutral switch lead with the clamp.
- O** Fasten the A.C. magneto lead with the lead holder.
- P** Fasten the neutral switch lead and A.C. magneto lead with the plastic band. Face the end of the plastic band inward on top of the frame.
- Q** Pass the neutral switch lead and A.C. magneto lead through the guide on the fender stay.





- R** When installing the fuel tank cover, do not pinch the front brake hose, throttle cable, front brake light switch lead, or throttle switch lead.
- S** Route the front brake hose in front of the handlebar cover.
- T** Route the clutch cable and parking brake cable in front of the handlebar cover.
- U** When installing the fuel tank cover, do not pinch the clutch cable, parking brake cable, clutch switch lead, or handlebar switch lead.






- ① Wire harness
- ② Air filter case breather hose
- ③ Cylinder head breather hose
- ④ Coolant reservoir breather hose
- ⑤ Coolant reservoir hose
- ⑥ Tail/brake light
- ⑦ Tail/brake light lead
- ⑧ Crankcase breather hose
- ⑨ Carburetor drain hose
- ⑩ Carburetor air vent hose
- ⑪ Battery negative lead


- ⑫ Starter motor lead

- [A] When installing the rear fender, make sure that the rear fender does not overlap or pinch the cylinder head breather hose, coolant reservoir hose, or wire harness.
- [B] Install the air filter case breather hose with the paint mark facing outward.
- [C] Install the cylinder head breather hose with the paint mark facing outward.






- D** Install the coolant reservoir breather hose without twisting the hose.
- E** Fasten the coolant reservoir hose and the coolant reservoir breather hose with a clamp. Do not pinch the coolant reservoir breather hose.
- F** Install the coolant reservoir breather hose as shown so that there is no slack.
- G** Install the wire harness so that it does not hang from the rear fender.
- H** Pass the carburetor drain hose and carburetor air vent hoses through the hose guide on the engine from the left side of the machine in the order listed. Do not pinch the hoses.
- I** Route the negative battery lead to the outside of the carburetor air vent hose and to the inside of the carburetor drain hose.
- J** Route the carburetor drain hose between the rear shock absorber and swingarm, and then under the frame.






- K** Route the carburetor drain hose between the frame and connecting arm and let it hang freely under the vehicle.





- ① Rear brake light switch lead
- ② Throttle cable
- ③ Clutch cable
- ④ Coolant reservoir hose
- ⑤ Oil tank breather hose
- ⑥ Thermo switch 1 lead
- ⑦ Parking brake cable


- A** Fasten the coolant reservoir hose with a clamp so that it is not pinched.
- B** Route the thermo switch 1 lead under the frame.
- C** Fasten the thermo switch 1 lead with a plastic band between the diode 1 and the diode 2 and then face the end of the band inward.
- D** Pass the parking brake cable through the cable guide.





- ① Rear brake hose
- ② Parking brake cable
- ③ Rear brake light switch
- ④ Rear brake light switch lead

- A** Install the lead protector of the rear brake light switch lead between the clamps.
- B** Face the rear brake light switch lead holder inward and then fasten the lead with the holder.






- ① Rectifier/regulator
- ② Headlight lead (right)
- ③ Main switch lead
- ④ Thermo switch 1 lead
- ⑤ Coolant reservoir hose
- ⑥ Oil tank breather hose
- ⑦ Throttle cable
- ⑧ Ignition coil lead
- ⑨ Rear brake light switch lead
- ⑩ Cylinder head breather hose
- ⑪ Carburetor switch lead

- ⑫ Throttle position sensor lead
- ⑬ Wire harness
- ⑭ Headlight lead (left)
- ⑮ C.D.I. unit


- [A] Route the wire harness on top of the frame.
- [B] Route the headlight lead (right) over the frame and connect. After connecting the lead to the headlight, place the headlight coupler behind the headlight toward the center of the vehicle.





- C** Route the main switch lead under the frame and connect.
- D** To thermo switch 1
- E** To main switch
- F** To radiator
- G** Route the rear brake light switch lead over the throttle cable.
- H** Route the rear brake light switch lead and ignition coil lead over the cylinder head breather hose.


- I** To carburetor
- J** Fasten the wire harness with the holder on the shield under the fuel tank.
- K** Route the headlight lead (left) over the frame and connect. After connecting the lead to the headlight, place the headlight coupler behind the headlight toward the center of the vehicle.
- L** When installing the left side cover, do not pinch the wire harness.






- ① Starter relay
- ② Battery positive lead
- ③ Tail/brake light lead
- ④ Starter motor lead
- ⑤ Starting circuit cut-off relay
- ⑥ Earth lead
- ⑦ Battery negative lead
- ⑧ Coolant reservoir hose
- ⑨ Cylinder head breather hose
- ⑩ Wire harness

- [A] Pass the coolant reservoir hose through the hose guide.
- [B] Route the earth lead and wire harness under the battery bracket.
- [C] Connect the tail/brake light lead between the coolant reservoir and the rear fender.
- [D] Pass the wire harness through the notch in the rear fender. Be sure that the rear fender and air filter case do not pinch the wire harness.





- E** Fasten the coolant reservoir hose and the cylinder head breather hose to the frame with the plastic beaded tie at its loosest position so that the hoses are not pinched.



EBS00029

PERIODIC CHECKS AND ADJUSTMENTS

INTRODUCTION

This chapter includes all information necessary to perform recommended checks and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable machine operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to machines already in service as well as to new machines that are being prepared for sale. All service technicians should be familiar with this entire chapter.

EBS00030

PERIODIC MAINTENANCE/LUBRICATION

| ITEM | ROUTINE | INITIAL | | | EVERY | |
|--|---|--|-----------------------|-----------------------|-----------------------|-----------------------|
| | | 1 month | 3 months | 6 months | 6 months | 1 year |
| Valves* | <ul style="list-style-type: none"> • Check valve clearance. • Adjust if necessary. | <input type="radio"/> | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Cooling system | <ul style="list-style-type: none"> • Check for coolant leakage. • Repair if necessary. • Replace coolant every 24 months. | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Spark plug | <ul style="list-style-type: none"> • Check condition. • Adjust gap and clean. • Replace if necessary. | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Air filter element | <ul style="list-style-type: none"> • Clean. • Replace if necessary. | Every 20~40 hours (More often in wet or dusty areas.) | | | | |
| Carburetor* | <ul style="list-style-type: none"> • Check starter (choke) operation. • Adjust engine idling speed. | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Crankcase breather system* | <ul style="list-style-type: none"> • Check breather hose for cracks or damage. • Replace if necessary. | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Exhaust system* | <ul style="list-style-type: none"> • Check for leakage. • Tighten if necessary. • Replace gasket if necessary. | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Spark arrester | <ul style="list-style-type: none"> • Clean. | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Fuel line* | <ul style="list-style-type: none"> • Check fuel hose for cracks or damage. • Replace if necessary. | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Engine oil | <ul style="list-style-type: none"> • Replace (Warm engine before draining). | <input type="radio"/> | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Engine oil filter element | <ul style="list-style-type: none"> • Replace. | <input type="radio"/> | | <input type="radio"/> | | <input type="radio"/> |
| Drive chain | <ul style="list-style-type: none"> • Check and adjust slack/alignment/clean/lube. | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Front brake* | <ul style="list-style-type: none"> • Check free play/operation/fluid leakage/ See NOTE. • Correct if necessary. | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Rear brake* | <ul style="list-style-type: none"> • Check operation/fluid leakage/See NOTE. • Correct if necessary. | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Clutch* | <ul style="list-style-type: none"> • Check operation. • Adjust if necessary. | <input type="radio"/> | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Wheels* | <ul style="list-style-type: none"> • Check balance/damage/runout. • Replace if necessary. | <input type="radio"/> | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Wheel bearings* | <ul style="list-style-type: none"> • Check bearing assemblies for looseness/damage. • Replace if damaged. | <input type="radio"/> | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Steering system* | <ul style="list-style-type: none"> • Check operation. • Repair if damaged. • Check toe-in. • Adjust if necessary. | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Front and rear suspension* | <ul style="list-style-type: none"> • Check operation. • Correct if necessary. | | | <input type="radio"/> | | <input type="radio"/> |
| Upper and lower arm pivot and steering shaft* | <ul style="list-style-type: none"> • Lubricate every 6 months with lithium-soap-based grease. | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |

PERIODIC MAINTENANCE/LUBRICATION



| ITEM | ROUTINE | INITIAL | | | EVERY | |
|-------------------------|--|-----------------------|-----------------------|-----------------------|-----------------------|-----------------------|
| | | 1 month | 3 months | 6 months | 6 months | 1 year |
| Rear arm pivot* | <ul style="list-style-type: none"> Lubricate every 6 months with lithium-soap-based grease. | | | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Fittings and fasteners* | <ul style="list-style-type: none"> Check all chassis fittings and fasteners. Correct if necessary. | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Lights and switches* | <ul style="list-style-type: none"> Check operation. Adjust headlight beams. | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |

* Since these items require special tools, data and technical skills, have a Yamaha dealer perform the service.

EBS00031

NOTE:

- Recommended brake fluid: DOT4
- Brake fluid replacement:
 - When disassembling the master cylinder or caliper cylinder, replace the brake fluid. Normally check the brake fluid level and add fluid as required.
 - On the inner parts of the master cylinder and caliper cylinder, replace the oil seals every two years.
 - Replace the brake hoses every four years, or if cracked or damaged.

WARNING


Indicates a potential hazard that could result in serious injury or death.

3



EBS00033

SEAT, FENDERS AND FUEL TANK
SEAT, FUEL TANK COVER AND SIDE COVERS




| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|--|
| 1 | Removing the seat, fuel tank cover and side covers Seat | 1 | Remove the parts in the order listed. NOTE: _____ Pull back the seat lock lever, than pull up on the rear of the seat. _____ |
| 2 | Fuel tank cover | 1 | |
| 3 | Left side cover | 1 | |
| 4 | Right side cover | 1 | |
| | | | For installation, reverse the removal procedure. |



EBS00034

FOOT PROTECTORS AND ENGINE SKID PLATE




| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|--|
| | Removing the foot protectors and engine skid plate | | Remove the parts in the order listed. |
| 1 | Left foot protector | 1 | |
| 2 | Right foot protector | 1 | |
| 3 | Engine skid plate | 1 | |
| | | | For installation, reverse the removal procedure. |



EBS00036

HEADLIGHTS AND FRONT FENDER




| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|--|
| | Removing the headlight and front fender | | Remove the parts in the order listed. |
| | Seat/fuel tank cover/side covers (left and right) | | Refer to "SEAT, FENDERS AND FUEL TANK". |
| 1 | Headlight coupler | 2 | Disconnect. |
| 2 | Left headlight | 1 | |
| 3 | Right headlight | 1 | |
| 4 | Main switch coupler | 1 | Disconnect. |
| 5 | Indicator light coupler | 1 | Disconnect. |
| 6 | Front fender | 1 | |
| | | | For installation, reverse the removal procedure. |



EBS00039

REAR FENDER




| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|---|
| 1 | Removing the rear fender Seat/fuel tank cover/side covers (left and right) Battery lead | 2 | Remove the parts in the order listed. Refer to "SEAT, FENDERS AND FUEL TANK". CAUTION: First disconnect the negative lead, then disconnect the positive lead. |
| 2 | Battery holding bracket | 1 | |
| 3 | Battery | 1 | |
| 4 | Air filter case breather hose | 1 | Disconnect. |
| 5 | Clamp | 1 | Loosen. |
| 6 | Air filter case | 1 | |
| 7 | Rear fender | 1 | For installation, reverse the removal procedure. |



EBS00042

FUEL TANK



| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|---|
| | Removing the fuel tank | | |
| 1 | Seat/fuel tank cover/side covers (left and right) Fuel hose (fuel cock side) | 1 | Remove the parts in the order listed. Refer to "SEAT, FENDERS AND FUEL TANK". NOTE: _____ Before disconnecting the fuel hose, turn the fuel cock to "OFF". |
| 2 | Fuel tank | 1 | NOTE: _____ When installing the fuel tank, pass the fuel tank breather hose through the hole in the handlebar cover. |
| 3 | Fuel tank shield | 1 | For installation, reverse the removal procedure. |

EAS00048

ENGINE

ADJUSTING THE VALVE CLEARANCE

The following procedure applies to all of the valves.

NOTE:

- Valve clearance adjustment should be made on a cold engine, at room temperature.
- When the valve clearance is to be measured or adjusted, the piston must be at the Top Dead Center (TDC) on the compression stroke.



1. Remove:

- seat
- fuel tank cover
- side covers (left and right)
- fuel tank

Refer to "SEAT, FENDERS AND FUEL TANK".

2. Remove:

- ignition coil ①
- oil tank breather hose ②
- cylinder head breather hose ③
- spark plug
- cylinder head cover ④



3. Remove:

- timing mark accessing screw ①
- crankshaft end accessing screw ②

4. Measure:

- valve clearance
- Out of specification → Adjust.



Valve clearance (cold)

Intake valve

0.10 ~ 0.15 mm

(0.0039 ~ 0.0059 in)

Exhaust valve

0.20 ~ 0.25 mm


(0.0079 ~ 0.0098 in)

EXAMPLE:

Original valve pad number = 148 {thickness = 1.48 mm (0.058 in)}

Rounded value = 150

- d. Locate the rounded number of the original valve pad and the measured valve clearance in the valve pad selection table. The point where the column and row intersect is the new valve pad number.



NOTE:

The new valve pad number is only an approximation. The valve clearance must be measured again and the above steps should be repeated if the measurement is still incorrect.

- e. Install the new valve pad ① and the valve lifter ②.

NOTE:

- Lubricate the valve pad with molybdenum disulfide oil.
- Lubricate the valve lifter with engine oil.
- The valve lifter must turn smoothly when rotated by hand.
- Install the valve lifter and the valve pad in the correct place.

- f. Install the exhaust and intake camshafts, timing chain and the camshaft caps.



Camshaft cap bolt
10 Nm (1.0 m · kg, 7.2 ft · lb)

NOTE:

- Refer to “INSTALLING THE CAMSHAFTS — CAMSHAFTS” in chapter 4.
- Lubricate the camshaft bearings, camshaft lobes and camshaft journals.
- First, install the exhaust camshaft.
- Align the camshaft sprocket marks with the edge of the cylinder head.
- Turn the crankshaft counterclockwise several full turns to seat the parts.

- g. Measure the valve clearance again.
h. If the valve clearance is still out of specification, repeat all of the valve clearance adjustment steps until the specified clearance is obtained.



ADJUSTING THE VALVE CLEARANCE



INTAKE

| MEASURED CLEARANCE | INSTALLED PAD NUMBER | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-----------------------|----------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|--|--|
| | 120 | 125 | 130 | 135 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | |
| 0.00 ~ 0.04 | | | 120 | 125 | 130 | 135 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | | |
| 0.05 ~ 0.09 | | 120 | 125 | 130 | 135 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | | | |
| 0.10 ~ 0.15 | STANDARD CLEARANCE | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0.16 ~ 0.20 | 125 | 130 | 135 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | |
| 0.21 ~ 0.25 | 130 | 135 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | |
| 0.26 ~ 0.30 | 135 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | |
| 0.31 ~ 0.35 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | |
| 0.36 ~ 0.40 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | |
| 0.41 ~ 0.45 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | |
| 0.46 ~ 0.50 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | |
| 0.51 ~ 0.55 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | |
| 0.56 ~ 0.60 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | |
| 0.61 ~ 0.65 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | |
| 0.66 ~ 0.70 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | |
| 0.71 ~ 0.75 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | |
| 0.76 ~ 0.80 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | |
| 0.81 ~ 0.85 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | |
| 0.86 ~ 0.90 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | |
| 0.91 ~ 0.95 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | | |
| 0.96 ~ 1.00 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | | | |
| 1.01 ~ 1.05 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | | | | |
| 1.06 ~ 1.10 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | | | | | |
| 1.11 ~ 1.15 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | | | | | | |
| 1.16 ~ 1.20 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | | | | | | | |
| 1.21 ~ 1.25 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1.26 ~ 1.30 | 235 | 240 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1.31 ~ 1.35 | 240 | | | | | | | | | | | | | | | | | | | | | | | | | | | |

VALVE CLEARANCE (cold):

0.10 ~ 0.15 mm (0.0039 ~ 0.0059 in)

Example: Installed is 175 pad

Measured clearance is 0.22 mm (0.0087 in)

Replace pad 175 with pad 185.

Pad number: (example)

Pad No. 175 = 1.75 mm (0.069 in)

Pad No. 185 = 1.85 mm (0.073 in)

VALVE CLEARANCE (cold):
 0.10 ~ 0.15 mm (0.0039 ~ 0.0059 in)
 Example: Installed is 175 pad
 Measured clearance is 0.22 mm
 (0.0087 in)
 Replace pad 175 with pad 185.
 Pad number: (example)
 Pad No. 175 = 1.75 mm (0.069 in)
 Pad No. 185 = 1.85 mm (0.073 in)

EXHAUST

| MEASURED CLEARANCE | INSTALLED PAD NUMBER | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|-----------------------|----------------------|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|--|--|--|
| | 120 | 125 | 130 | 135 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | |
| 0.00 ~ 0.04 | | | | | 120 | 125 | 130 | 135 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | | | |
| 0.05 ~ 0.09 | | | | 120 | 125 | 130 | 135 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | | | |
| 0.10 ~ 0.14 | | | 120 | 125 | 130 | 135 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | | | |
| 0.15 ~ 0.19 | | 120 | 125 | 130 | 135 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | | | |
| 0.20 ~ 0.25 | STANDARD CLEARANCE | | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 0.26 ~ 0.30 | 125 | 130 | 135 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | |
| 0.31 ~ 0.35 | 130 | 135 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | |
| 0.36 ~ 0.40 | 135 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | |
| 0.41 ~ 0.45 | 140 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | |
| 0.46 ~ 0.50 | 145 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | |
| 0.51 ~ 0.55 | 150 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | |
| 0.56 ~ 0.60 | 155 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | |
| 0.61 ~ 0.65 | 160 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | |
| 0.66 ~ 0.70 | 165 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | |
| 0.71 ~ 0.75 | 170 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | |
| 0.76 ~ 0.80 | 175 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | |
| 0.81 ~ 0.85 | 180 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | |
| 0.86 ~ 0.90 | 185 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | |
| 0.91 ~ 0.95 | 190 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | |
| 0.96 ~ 1.00 | 195 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | |
| 1.01 ~ 1.05 | 200 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | | |
| 1.06 ~ 1.10 | 205 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | | | |
| 1.11 ~ 1.15 | 210 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | | | | |
| 1.16 ~ 1.20 | 215 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | | | | | |
| 1.21 ~ 1.25 | 220 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | | | | | | |
| 1.26 ~ 1.30 | 225 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | | | | | | | |
| 1.31 ~ 1.35 | 230 | 235 | 240 | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1.36 ~ 1.40 | 235 | 240 | | | | | | | | | | | | | | | | | | | | | | | | | | |
| 1.41 ~ 1.45 | 240 | | | | | | | | | | | | | | | | | | | | | | | | | | | |

VALVE CLEARANCE (cold):

0.20 ~ 0.25 mm (0.0079 ~ 0.0098 in)

Example: Installed is 175 pad

Measured clearance is 0.32 mm (0.0126 in)

Replace pad 175 with pad 185.

Pad number: (example)

Pad No. 175 = 1.75 mm (0.069 in)

Pad No. 185 = 1.85 mm (0.073 in)

VALVE CLEARANCE (cold):
 0.20 ~ 0.25 mm (0.0079 ~ 0.0098 in)
 Example: Installed is 175 pad
 Measured clearance is 0.32 mm
 (0.0126 in)
 Replace pad 175 with pad 185.
 Pad number: (example)
 Pad No. 175 = 1.75 mm (0.069 in)
 Pad No. 185 = 1.85 mm (0.073 in)

7. Install:
- all removed parts

NOTE: _____
For installation, reverse the removal procedure.

EBS00051

ADJUSTING THE ENGINE IDLING SPEED

1. Start the engine and let it warm up for several minutes.
2. Remove:
 - seat
 - fuel tank cover
 - side covers (left and right)
 - fuel tank

NOTE: _____
Slide the fuel tank.

Refer to “SEAT, FENDERS AND FUEL TANK”.

3. Attach:
 - digital tachometer
(onto the ignition coil)
4. Install:
 - fuel tank


Refer to “SEAT, FENDERS AND FUEL TANK”.
5. Measure:
 - engine idling speed

Out of specification → Adjust.



Engine idling speed
1,750 ~ 1,850 r/min


ADJUSTING THE THROTTLE LEVER FREE PLAY



1. Measure:
 - throttle lever free play **a**
 Out of specification → Adjust.



Throttle lever free play
2 ~ 4 mm (0.08 ~ 0.16 in)



2. Adjust:
 - throttle lever free play

First step:


- a. Slide back the rubber cover **1**.
- b. Loosen the locknut **2** on the carburetor side.
- c. Turn the adjusting nut **3** in direction **a** or **b** until the correct free play is obtained.

| | |
|--------------------|-------------------------|
| Direction a | Free play is increased. |
| Direction b | Free play is decreased. |

- d. Tighten the locknut.
- e. Slide the rubber cover to its original position.

NOTE:

If the free play cannot be adjusted here, adjust it at the throttle lever side of the cable.



Second step:

- f. Slide back the rubber cover **4**.
- g. Loosen the locknut **5**.
- h. Turn the adjusting bolt **6** in direction **c** or **d** until the correct free play is obtained.

| | |
|--------------------|-------------------------|
| Direction c | Free play is increased. |
| Direction d | Free play is decreased. |

- i. Tighten the locknut.
- j. Slide the rubber cover to its original position.

⚠ WARNING

After adjusting the free play, turn the handlebar to the right and left to make sure that the engine idling speed does not increase.

EBS00057

CHECKING THE SPARK PLUG

1. Remove:

- seat
- fuel tank cover
- side covers (left and right)
- fuel tank

NOTE:

Slide the fuel tank.

2. Remove:

- ignition coil


3. Remove:

- spark plug

4. Check:

- spark plug type
Incorrect → Change.

**Standard spark plug
CR8E/NGK**




5. Check:

- electrode ①
Wear/damage → Replace.
- insulator ②
Abnormal color → Replace.
Normal color is a medium-to-light tan color.

6. Clean:

- spark plug
(with a spark plug cleaner or wire brush)



7. Measure:

- spark plug gap ③
Use a wire gauge or thickness gauge.
Out of specification → Regap.



**Spark plug gap
0.7 ~ 0.8 mm (0.028 ~ 0.031 in)**

8. Tighten:

- spark plug

13 Nm (1.3 m · kg, 9.4 ft · lb)

NOTE:

Before installing a spark plug, clean the gasket surface and plug surface.

9. Install:
- ignition coil
 - fuel tank
 - side covers (left and right)
 - fuel tank cover
 - seat
- Refer to “SEAT, FENDERS AND FUEL TANK”.

EBS00058

CHECKING THE IGNITION TIMING

NOTE: _____
Engine idling speed and throttle cable free play should be adjusted properly before checking the ignition timing.

1. Remove:
- seat
 - fuel tank cover
 - side covers (left and right)
 - fuel tank

NOTE: _____
Slide the fuel tank.

Refer to “SEAT, FENDERS AND FUEL TANK”.



2. Attach:
- digital tachometer
 - timing light
(onto the ignition coil)



Timing light
P/N. YM-33277-A, 90890-03141

3. Install:
- fuel tank
- Refer to “SEAT, FENDERS AND FUEL TANK”.

CHECKING THE IGNITION TIMING/ CHECKING THE ENGINE OIL LEVEL



4. Check:
 - ignition timing



- a. Warm up the engine and keep it at the specified speed.

| | |
|--|--|
| | Engine speed 1,750 ~ 1,850 r/min |
|--|--|

- b. Remove the timing mark accessing screw ①.
- c. Visually check the stationary pointer ③ to verify it is within the required firing range ④ indicated on the A.C. magneto rotor.
Incorrect firing range → Check the pulser coil assembly.
- d. Install the timing mark accessing screw.



5. Remove:
 - fuel tank

NOTE:

Slide the fuel tank.

6. Detach:
 - timing light
 - engine tachometer
7. Install:
 - fuel tank
 - side covers (left and right)
 - fuel tank cover
 - seat

Refer to “SEAT, FENDERS AND FUEL TANK”.

EBS01101



CHECKING THE ENGINE OIL LEVEL

1. Place the machine on a level surface.
2. Start the engine, warm it up until the engine oil has reached a normal temperature of 40 °C (104 °F), let it continue to idle for ten seconds, and then turn the engine off.

NOTE:

To achieve the proper engine oil temperature for an accurate oil level reading, the engine must have first completely cooled down, and then warmed up again for several minutes to normal operating temperature.

CHECKING THE ENGINE OIL LEVEL



3. Check:

- engine oil level

Oil level should be between the minimum level mark (a) and the maximum level mark (b).

Low oil level → Add oil to the proper level.

NOTE:

- Wait a few minutes until the oil settles before checking the oil level.
- Do not screw the dipstick (1) in when checking the oil level.



Recommended oil
Follow the chart on the left.

NOTE:

Recommended oil classification:

API Service "SE", "SF", "SG" type or equivalent (e.g. "SF—SE—CC", "SF—SE—SD" etc.)

CAUTION:

- Do not add any chemical additives. Engine oil also lubricates the clutch and additives could cause clutch slippage.
- Do not allow foreign material to enter the crankcase.

4. Start the engine, warm it up for several minutes, and then turn it off.

5. Check:

- engine oil level





NOTE:

Before checking the engine oil level, wait a few minutes until the oil has settled.

EBS00067

CHANGING THE ENGINE OIL

1. Remove:
 - engine skid plate
Refer to “SEAT, FENDERS AND FUEL TANK”.
2. Start the engine, warm it up for several minutes, and then turn it off.
3. Place a container under the engine oil drain bolt.
4. Remove:
 - engine oil filler cap ①
 - dipstick ②



5. Remove:
 - engine oil drain bolt (oil tank) ①
(along with the washer)
6. Remove:
 - engine oil drain bolt (crankcase) ①
(along with the gasket)
7. Remove:
 - oil filter element drain bolt ①
8. Drain:
 - engine oil
(completely from the oil tank and the crankcase)



Overhaul

Total amount

1.95 L (1.72 Imp qt, 2.06 US qt)

Quantity in oil tank

1.55 L (1.36 Imp qt, 1.64 US qt)

Quantity in crankcase

0.40 L (0.35 Imp qt, 0.42 US qt)

Periodic oil replacement

Total amount

1.75 L (1.54 Imp qt, 1.85 US qt)

Quantity in oil tank

1.55 L (1.36 Imp qt, 1.64 US qt)

Quantity in crankcase

0.20 L (0.18 Imp qt, 0.21 US qt)

With oil filter element replacement

Total amount

1.85 L (1.63 Imp qt, 1.96 US qt)

Quantity in oil tank

1.55 L (1.36 Imp qt, 1.64 US qt)

Quantity in crankcase

0.30 L (0.26 Imp qt, 0.32 US qt)

13.Install:

- dipstick
- engine oil filler cap

14.Start the engine, warm it up for several minutes, and then turn it off.

15.Check:


- engine
(for engine oil leaks)

16.Check:

- engine oil level

Refer to "CHECKING THE ENGINE OIL LEVEL".

CHANGING THE ENGINE OIL/ ADJUSTING THE CLUTCH CABLE



17. Check:

- engine oil pressure




- Slightly loosen the oil gallery bolt ①.
- Start the engine and keep it idling until engine oil starts to seep from the oil gallery bolt. If no engine oil comes out after one minute, turn the engine off so that it will not seize.
- Check the engine oil passages, the oil filter element and the oil pump for damage or leakage. Refer to "OIL PUMP" in chapter 4.
- Start the engine after solving the problem(s) and check the engine oil pressure again.
- Tighten the oil gallery bolt to specification.

| | |
|---|---|
|  | Oil gallery bolt 10 Nm (1.0 m · kg, 7.2 ft · lb) |
|---|---|



18. Install:

- engine skid plate
Refer to "SEAT, FENDERS AND FUEL TANK".




EBS00070

ADJUSTING THE CLUTCH CABLE

1. Check:

- clutch lever free play ①
Out of specification → Adjust.

| | |
|---|--|
|  | Clutch lever free play (at the clutch lever end) 8 ~ 13 mm (0.31 ~ 0.51 in) |
|---|--|



2. Adjust:
 - clutch release lever free play




Handlebar side

- a. Turn the adjusting nut ① in direction ③ or ④ until the specified clutch cable free play is obtained.

| | |
|-------------|--------------------------------------|
| Direction ③ | Clutch cable free play is increased. |
| Direction ④ | Clutch cable free play is decreased. |

NOTE:

If the specified clutch cable free play cannot be obtained on the handlebar side of the cable, use the adjusting nut on the engine side.




Engine side

- a. Slide back the rubber cover ②.
- b. Loosen the locknut ③.
- c. Turn the adjusting nut ④ in direction ③ or ④ until the specified clutch cable free play is obtained.

| | |
|-------------|--------------------------------------|
| Direction ③ | Clutch cable free play is increased. |
| Direction ④ | Clutch cable free play is decreased. |

- d. Tighten the locknut.
- e. Slide the rubber cover to its original position.





EBS00073

CLEANING THE AIR FILTER ELEMENT


NOTE:

There is a check hose (1) at the bottom of the air filter case. If dust and/or water collects in this hose, clean the air filter element and air filter case.

1. Remove:


- seat

Refer to "SEAT, FENDERS AND FUEL TANK".



2. Remove:

- air filter case cover (1)



3. Remove:

- wing bolt (1)
- air filter element (2)
- air filter element frame (3)


CAUTION:

The engine should never be run without the air filter; excessive piston and/or cylinder wear may result.


4. Check:

- air filter element

Damage → Replace.



CHECKING THE COOLANT LEVEL/ CHANGING THE COOLANT



EBS00076

CHECKING THE COOLANT LEVEL

1. Place the machine on a level surface.

2. Check:

- coolant level

The coolant level should be between the minimum level mark ① and maximum level mark ②.

Below the minimum level mark → Add the recommended coolant to the proper level.

CAUTION:

- Adding water instead of coolant lowers the antifreeze content of the coolant. If water is used instead of coolant, check and if necessary, correct the antifreeze concentration of the coolant.
- Use only distilled water. However, soft water may be used if distilled water is not available.

4. Start the engine, warm it up for several minutes, and then turn it off.

5. Check:

- coolant level

NOTE:

Before checking the coolant level, wait a few minutes until the coolant has settled.


EBS00075

CHANGING THE COOLANT

1. Remove:

- seat
- fuel tank cover
- right side cover

Refer to "SEAT, FENDERS AND FUEL TANK".



2. Disconnect:

- coolant reservoir breather hose ①


3. Remove:

- coolant reservoir cap ②
- coolant reservoir bolts ③
- coolant reservoir ④


4. Drain:

- coolant
(from the coolant reservoir)

5. Install:
 - coolant reservoir
 - coolant reservoir bolts

 **7 Nm (0.7 m · kg, 5.1 ft · lb)**

6. Connect:
 - coolant reservoir breather hose




7. Remove:
 - radiator cap ①


WARNING

A hot radiator is under pressure. Therefore, do not remove the radiator cap when the engine is hot. Scalding hot fluid and steam may be blown out, which could cause serious injury. When the engine has cooled, open the radiator cap as follows:

Place a thick rag or a towel over the radiator cap and slowly turn the radiator cap counterclockwise toward the detent to allow any residual pressure to escape. When the hissing sound has stopped, press down on the radiator cap and turn it counterclockwise to remove.





8. Remove:
 - coolant drain bolt ①
(along with the copper washer)
9. Drain:
 - coolant
(from the engine and radiator)



10. Check:
 - copper washer ① **New**
 - coolant drain bolt ②
 - Damage → Replace.

11. Install:
 - coolant drain bolt

 **10 Nm (1.0 m · kg, 7.2 ft · lb)**



12.Fill:

- cooling system
(with the specified amount of the recommended coolant)



Recommended antifreeze

High-quality ethylene glycol antifreeze containing corrosion inhibitors for aluminum engines

Mixing ratio

1:1 (antifreeze:water)

Quantity

Total amount

1.3 L (1.14 Imp qt, 1.37 US qt)

Coolant reservoir capacity

0.29 L (0.26 Imp qt, 0.31 US qt)

Handling notes for coolant

Coolant is potentially harmful and should be handled with special care.

WARNING


- If coolant splashes in your eyes, thoroughly wash them with water and consult a doctor.
- If coolant splashes on your clothes, quickly wash it away with water and then with soap and water.
- If coolant is swallowed, induce vomiting and get immediate medical attention.

CAUTION:

- Adding water instead of coolant lowers the antifreeze content of the coolant. If water is used instead of coolant check, and if necessary, correct the antifreeze concentration of the coolant.
- Use only distilled water. However, if distilled water is not available, soft water may be used.
- If coolant comes into contact with painted surfaces, immediately wash them with water.
- Do not mix different types of antifreeze.

13.Install:

- radiator cap



14.Fill:

- coolant reservoir
(with the recommended coolant to the maximum level mark (a))

15.Install:

- coolant reservoir cap

16.Start the engine, warm it up for several minutes, and then stop it.

17.Check:

- coolant level
Refer to "CHECKING THE COOLANT LEVEL".

NOTE: _____


Before checking the coolant level, wait a few minutes until the coolant has settled.

18.Install:

- right side cover
- fuel tank cover
- seat

Refer to "SEAT, FENDERS AND FUEL TANK".

CHECKING THE COOLANT TEMPERATURE WARNING LIGHT







EBS00077

CHECKING THE COOLANT TEMPERATURE WARNING LIGHT

- ① Coolant temperature warning light

Coolant temperature warning light checking method





CLEANING THE SPARK ARRESTER


1. Clean:
 - Spark arrester

⚠ WARNING

- Select a well-ventilated area free of combustible materials.
- Always let the exhaust system cool before performing this operation.
- Do not start the engine when removing the tailpipe from the muffler.

- a. Remove the bolt ①.
- b. Remove the tailpipe ② by pulling it out of the muffler.
- c. Tap the tailpipe lightly with a soft-face hammer or suitable tool, then use a wire brush to remove any carbon deposits from the spark arrester portion of the tailpipe and the inner contact surfaces of the muffler.
- d. Insert the tailpipe into the muffler and align the bolt holes.
- e. Insert the bolt and tighten it.
- f. Remove the purging bolt ③.
- g. Start the engine and rev it up approximately twenty times while momentarily creating exhaust system back pressure by blocking the end of the muffler with a shop towel.
- h. Stop the engine and allow the exhaust pipe to cool.
- i. Install the purging bolt ③ and tighten it.

ADJUSTING THE REAR BRAKE/ ADJUSTING THE PARKING BRAKE



2. Adjust:
 - rear brake pedal height




- a. Loosen the locknut ①.
- b. Turn the adjusting bolt ② until the brake pedal height is within the specified limits.
- c. Tighten the locknut.

NOTE:

When adjusting the brake pedal height make sure the locknut-to-adjusting bolt clearance (a) does not exceed 2.2 ~ 3.2 mm (0.09 ~ 0.13 in).


⚠ WARNING

After this adjustment is performed, lift the front and rear wheels off the ground by placing a block under the engine, and spin the rear wheels to ensure there is no brake drag. If any brake drag is noticed, perform the above steps again.





ADJUSTING THE PARKING BRAKE

1. Check:
 - parking brake cable end length (a)
Out of specification → Adjust.

| | |
|---|--|
|  | Parking brake cable end length 56 ~ 60 mm (2.20 ~ 2.36 in) |
|---|--|

CHECKING THE BRAKE FLUID LEVEL/ CHECKING THE FRONT BRAKE PADS



2. Check:

- brake fluid level

Below the minimum level mark ① → Add the recommended brake fluid to the proper level.



A Front brake

B Rear brake

⚠ WARNING

- Use only the designated brake fluid. Other brake fluids may cause the rubber seals to deteriorate, causing leakage and poor brake performance.
- Refill with the same type of brake fluid that is already in the system. Mixing brake fluids may result in a harmful chemical reaction, leading to poor brake performance.
- When refilling, be careful that water does not enter the brake fluid reservoir. Water will significantly lower the boiling point of the brake fluid and could cause vapor lock.

CAUTION:

Brake fluid may damage painted surfaces and plastic parts. Therefore, always clean up any spilt brake fluid immediately.

NOTE:

In order to ensure a correct reading of the brake fluid level, make sure that the top of the brake fluid reservoir is horizontal.

EBS00088


CHECKING THE FRONT BRAKE PADS

1. Remove:

- front wheels

Refer to "FRONT AND REAR WHEELS" in chapter 7.

CHECKING THE FRONT BRAKE PADS/ CHECKING THE REAR BRAKE PADS



2. Check:

- brake pads

Wear indicators ① almost touch the brake disc → Replace the brake pads as a set.
Refer to “FRONT AND REAR BRAKES” in chapter 7.




Brake pad wear limit ②
1.0 mm (0.04 in)

3. Operate the brake lever.

4. Install:

- front wheels

Refer to “FRONT AND REAR WHEELS” in chapter 7.



EBS00089

CHECKING THE REAR BRAKE PADS

1. Check:

- brake pads



Wear indicator ① almost touch the brake disc → Replace the brake pads as a set.
Refer to “FRONT AND REAR BRAKES” in chapter 7.



Brake pad wear limit ②
1.0 mm (0.04 in)

2. Operate the brake pedal.

CHECKING THE BRAKE HOSES/ BLEEDING THE HYDRAULIC BRAKE SYSTEM



2. Check:
 - front brake hoses ①
 - rear brake hose ②Cracks/wear/damage → Replace.
3. Check:
 - brake hose clampsLoosen → Tighten.
4. Hold the machine in an upright position and apply the front or rear brake.
5. Check:
 - brake hosesApply the brake lever or brake pedal several times.
Fluid leakage → Replace the hoses.
Refer to “FRONT AND REAR BRAKES” in chapter 7.
6. Install:
 - front fender
 - side covers (left and right)
 - fuel tank cover
 - seatRefer to “SEAT, FENDERS AND FUEL TANK”.

EBS00094

BLEEDING THE HYDRAULIC BRAKE SYSTEM



WARNING

Bleed the hydraulic brake system whenever:

- the system is disassembled,
- a brake hose is loosened, disconnected or replaced,
- the brake fluid level is very low,
- brake operation is faulty.

NOTE: _____

- Be careful not to spill any brake fluid or allow the brake master cylinder reservoir or brake fluid reservoir to overflow.
- When bleeding the hydraulic brake system, make sure there is always enough brake fluid before applying the brake. Ignoring this precaution could allow air to enter the hydraulic brake system, considerably lengthening the bleeding procedure.
- If bleeding is difficult, it may be necessary to let the brake fluid settle for a few hours. Repeat the bleeding procedure when the tiny bubbles in the hose have disappeared.



1. Bleed:
 - hydraulic brake system



- a. Fill the brake fluid reservoir to the proper level with the recommended brake fluid.
- b. Install the diaphragm (brake master cylinder reservoir or brake fluid reservoir).
- c. Connect a clear plastic hose ① tightly to the bleed screw ②.
- d. Place the other end of the hose into a container.
- e. Slowly apply the brake lever or brake pedal several times.
- f. Fully squeeze the brake lever or fully depress the brake pedal and hold it in position.
- g. Loosen the bleed screw.

A Front

B Rear



NOTE: _____

Loosening the bleed screw will release the pressure and cause the brake lever to contact the throttle grip or the brake pedal to fully extend.

- h. Tighten the bleed screw and then release the brake lever or brake pedal.

-

⚠ WARNING



-

ADJUSTING THE DRIVE CHAIN SLACK


NOTE:

Measure the drive chain slack halfway between the drive axle and the rear axle.

CAUTION:

A drive chain that is too tight will overload the engine and other vital parts, and one that is too loose can skip and damage the swingarm or cause an accident. Therefore, keep the drive chain slack within the specified limits.

1. Elevate the rear wheels by placing the suitable stand under the frame.




2. Measure:

- drive chain slack (a)
Out of specification → Adjust.



Drive chain slack
25 ~ 35 mm (0.98 ~ 1.38 in)




3. Adjust:

- drive chain slack



- a. Loosen the hub nuts (1).
- b. Loosen the locknuts (2).
- c. Turn both adjusting bolts (3) in direction (a) or (b) until the specified drive chain slack is obtained.

| | |
|---------------|---------------------------------|
| Direction (a) | Drive chain slack is reduced. |
| Direction (b) | Drive chain slack is increased. |



NOTE:

To maintain the proper axle alignment, adjust both sides evenly. (There are marks (c) on each side of hub.)

CAUTION:

Excessive chain slack will overload the engine and other vital parts; keep the slack within the specified limits.

- d. If the chain slack cannot be adjusted, replace the sprockets and drive chain as a set.
- e. Tighten the hub nuts and locknuts.



Hub nut

85 Nm (8.5 m · kg, 61 ft · lb)

Locknut (chain puller)

16 Nm (1.6 m · kg, 11 ft · lb)

NOTE:




The chain should be cleaned and lubricated after every use of the machine.





EBS00106

CHECKING THE STEERING SYSTEM

1. Place the machine on a level surface.
2. Check:
 - steering assembly bushings
Move the handlebar up and down, and/or back and forth.
Excessive play → Replace the steering stem bushings.
3. Check:
 - tie-rod ends
Turn the handlebar to the left and right until it stops completely, and then move the handlebar slightly in the opposite direction.
Tie-rod end(s) ① have vertical play → Replace the tie-rod end(s).
4. Raise the front end of the machine so that there is no weight on the front wheels.
5. Check:
 - ball joints and/or wheel bearings
Move the wheels laterally back and forth.
Excessive free play → Replace the front arms (upper and lower) and/or wheel bearings.





EBS00108

ADJUSTING THE TOE-IN

1. Place the machine on a level surface.
2. Measure:
 - toe-in
 Out of specification → Adjust.



Toe-in
2 ~ 12 mm (0.08 ~ 0.47 in)



NOTE:

Before measuring the toe-in, make sure that the tire pressure is correct.

- a. Mark both front tire tread centers.
- b. Raise the front end of the machine so that there is no weight on the front tires.
- c. Face the handlebar straight ahead.
- d. Measure the width **A** between the marks.
- e. Rotate the front tires 180° until the marks are exactly opposite one another.
- f. Measure the width **B** between the marks.
- g. Calculate the toe-in using the formula given below.

$$\text{Toe-in} = \text{B} - \text{A}$$

- h. If the toe-in is incorrect, adjust it.

C Forward



3. Adjust:
 - toe-in



WARNING

- Be sure that both tie-rods are turned the same amount. If not, the machine will drift right or left even though the handlebar is positioned straight. This may lead to mis-handling and an accident.
- After setting the toe-in to specification, run the machine slowly for some distance with both hands lightly holding the handlebar and check that the handlebar responds correctly. If not, turn either the right or left tie-rod within the toe-in specification.





EBS00111

ADJUSTING THE FRONT SHOCK ABSORBERS

⚠ WARNING

Always adjust the spring preload, rebound damping force and compression damping force of both front shock absorbers to the same setting. Uneven adjustment can result in poor handling and loss of stability.



1. Adjust:
 - spring preload



- a. Elevate the front wheels by placing a suitable stand under the frame.
- b. Loosen the locknut ①.
- c. Turn the adjusting ring ② in direction ③ or ④.

| | |
|-------------|---|
| Direction ③ | Spring preload is increased (suspension is harder). |
| Direction ④ | Spring preload is decreased (suspension is softer). |

Adjusting length ⑤
 Standard: 255 mm (10.04 in)
 Minimum: 245 mm (9.65 in)
 Maximum: 256.5 mm (10.10 in)

NOTE:

- Be sure to remove all dirt and mud from around the locknut and adjusting ring before adjustment.
- The length of the spring (installed) changes 1.5 mm (0.06 in) per turn of the adjuster.


CAUTION:

Never attempt to turn the adjusting ring beyond the maximum or minimum setting.

- d. Tighten the locknut ① with a steering nut wrench ③.


NOTE:

Set the torque wrench at a right angle to the steering nut wrench.





NOTE: Always tighten the locknut against the adjusting ring, then torque it to specification.




- a. Turn the adjusting screw ① in direction ② or ③.

| | |
|--------------------|--|
| Direction ① | Rebound damping force is increased. |
| Direction ② | Rebound damping force is decreased. |

CAUTION:

Do not force the adjuster past the minimum or maximum extent of adjustment. The adjuster may be damaged.

ADJUSTING THE FRONT SHOCK ABSORBERS/ ADJUSTING THE REAR SHOCK ABSORBER



3. Adjust:
 - compression damping force



- a. Turn the adjusting screw ① in direction ② or ③.

| | |
|-------------|---|
| Direction ② | Compression damping force is increased. |
| Direction ③ | Compression damping force is decreased. |

From the fully turned-in position
 Standard: 11 clicks out
 Minimum: 22 clicks out
 Maximum: 1 click out

CAUTION:


Do not force the adjuster past the minimum or maximum extent of adjustment. The adjuster may be damaged.



EBS00111

ADJUSTING THE REAR SHOCK ABSORBER

1. Remove:
 - seat
 Refer to “SEAT, FENDERS AND FUEL TANK”.



2. Loosen the clamp screw ①, and then disconnect the air intake duct.

ADJUSTING THE REAR SHOCK ABSORBER




Steering nut wrench
P/N. YU-33975, 90890-01443



Locknut
45 Nm (4.5 m · kg, 32 ft · lb)

NOTE:

Always tighten the locknut against the adjusting ring, then torque it to specification.




5. Install:

- air filter case with air intake duct

NOTE:

Align the projection (a) on the carburetor with the slot (b) in the air intake duct.



6. Adjust:

- rebound damping force

a. Turn the adjusting screw (1) in direction (a) or (b).

| | |
|---------------|-------------------------------------|
| Direction (a) | Rebound damping force is increased. |
| Direction (b) | Rebound damping force is decreased. |

Minimum (soft): Adjusting screw fully turned out
Standard: Adjusting screw 1 3/4 turns out from the fully turned in position
Maximum (hard): Adjusting screw fully turned in


NOTE:

Make sure that the position indicator marks (c) are aligned when the shock absorber is set to the standard setting.

CAUTION:

Do not force the adjuster past the minimum or maximum extent of adjustment. The adjuster may be damaged.

ADJUSTING THE REAR SHOCK ABSORBER



7. Adjust:

- compression damping force



- a. Turn the adjusting screw ① in direction ② or ③.

| | |
|-------------|---|
| Direction ② | Compression damping force is increased. |
| Direction ③ | Compression damping force is decreased. |

Minimum (soft): Adjusting screw fully turned out
Standard: Adjusting screw 1 3/4 turns out from the fully turned in position
Maximum (hard): Adjusting screw fully turned in

NOTE:

Make sure that the position indicator marks ④ are aligned when the shock absorber is set to the standard setting.

CAUTION:

Do not force the adjuster past the minimum or maximum extent of adjustment. The adjuster may be damaged.



8. Install:

- seat

Refer to "SEAT, FENDERS AND FUEL TANK".

EBS00114

CHECKING THE TIRES

⚠ WARNING

This model is equipped with low pressure tires. It is important that they be inflated correctly and maintained at the proper pressures.

• **TIRE CHARACTERISTICS**

- 1) Tire characteristics influence the handling of ATVs. The tires listed below have been approved by Yamaha Motor Co., Ltd. for this model. If other tire combinations are used, they can adversely affect your machine's handling characteristics and are therefore not recommended.

| | Manufacturer | Size | Type |
|-------|--------------|-------------|---------------|
| Front | DUNLOP | AT21 × 7-10 | KT331A Radial |
| Rear | DUNLOP | AT20 × 10-9 | KT355 Radial |


• **TIRE PRESSURE**

- 1) Recommended tire pressure
Front 30 kPa (0.30 kg/cm², 4.4 psi)
Rear 35 kPa (0.35 kg/cm², 5.0 psi)
- 2) Tire pressure below the minimum specification could cause the tire to dislodge from the rim under severe riding conditions.
The following are minimums:
Front 27 kPa (0.27 kg/cm², 3.9 psi)
Rear 32 kPa (0.32 kg/cm², 4.5 psi)
- 3) Use no more than
Front 250 kPa (2.5 kg/cm², 36 psi)
Rear 250 kPa (2.5 kg/cm², 36 psi)
when seating the tire beads. Higher pressures may cause the tire to burst. Inflate the tires slowly and carefully. Fast inflation could cause the tire to burst.

• **MAXIMUM LOADING LIMIT**

- 1) Vehicle load limits: 100 kg (220 lb)
*Total weight of the cargo, rider, and accessories.

Be extra careful of the machine balance and stability when towing a trailer.



1. Measure:
 - tire pressure
 Out of specification → Adjust.

NOTE:


- The low-pressure tire gauge ① is included as standard equipment.
- If dust or the like is stuck to this gauge, it will not provide the correct readings. Therefore, take two measurements of the tire's pressure and use the second reading.

| Cold tire pressure | Front | Rear |
|--------------------|--|--|
| Standard | 30 kPa (0.30 kg/cm ² , 4.4 psi) | 35 kPa (0.35 kg/cm ² , 5.0 psi) |
| Minimum | 27 kPa (0.27 kg/cm ² , 3.9 psi) | 32 kPa (0.32 kg/cm ² , 4.5 psi) |
| Maximum | 33 kPa (0.33 kg/cm ² , 4.7 psi) | 38 kPa (0.38 kg/cm ² , 5.4 psi) |

⚠ WARNING

Uneven or improper tire pressure may adversely affect the handling of this machine and may cause loss of control.

- Maintain proper tire pressures.
- Set tire pressures when the tires are cold.
- Tire pressures must be equal in both front tires and equal in both rear tires.



2. Check:
 - tire surfaces
 Wear/damage → Replace.




Tire wear limit ②
Front and rear: 3.0 mm (0.12 in)

⚠ WARNING

It is dangerous to ride with a worn-out tire. When tire wear is out of specification, replace the tire immediately.

CHECKING THE WHEELS/CHECKING AND LUBRICATING THE CABLES



EBS00116

CHECKING THE WHEELS

1. Check:

- wheel ①

Damage/bends → Replace.

NOTE:

Always balance the wheel when a tire or wheel has been changed or replaced.

⚠ WARNING

- Never attempt even small repairs to the wheel.
- Ride conservatively after installing a tire to allow it to seat itself properly on the rim.

EBS00117

CHECKING AND LUBRICATING THE CABLES

⚠ WARNING

A damaged cable sheath may cause corrosion and interfere with the cable movement. An unsafe condition may result so replace a damaged cable as soon as possible.

1. Check:

- cable sheath

Damage → Replace.

2. Check:

- cable operation

Unsmooth operation → Lubricate or replace.



Recommended lubricant
Yamaha chain and cable lube or engine oil

NOTE:

Hold the cable end up and apply several drops of lubricant to the cable.

3. Apply:

- Lithium-soap-based grease (onto end of the cable)


EBS00118

LUBRICATING THE LEVERS AND PEDALS

Lubricate the pivoting point and metal-to-metal moving parts of the levers and pedals.



Recommended lubricant
Lithium-soap-based grease



EBS00120

ELECTRICAL SYSTEM

CHECKING AND CHARGING THE BATTERY

WARNING

Batteries generate explosive hydrogen gas and contain electrolyte which is made of poisonous and highly caustic sulfuric acid. Therefore, always follow these preventive measures:

- Wear protective eye gear when handling or working near batteries.
- Charge batteries in a well-ventilated area.
- Keep batteries away from fire, sparks or open flames (e.g., welding equipment, lighted cigarettes).
- **DO NOT SMOKE** when charging or handling batteries.
- **KEEP BATTERIES AND ELECTROLYTE OUT OF REACH OF CHILDREN.**
- Avoid bodily contact with electrolyte as it can cause severe burns or permanent eye injury.

FIRST AID IN CASE OF BODILY CONTACT: EXTERNAL

- Skin — Wash with water.
- Eyes — Flush with water for 15 minutes and get immediate medical attention.

INTERNAL

- Drink large quantities of water or milk followed with milk of magnesia, beaten egg or vegetable oil. Get immediate medical attention.

CAUTION:

- This is a sealed battery. Never remove the sealing caps because the balance between cells will not be maintained and battery performance will deteriorate.
 - Charging time, charging amperage and charging voltage for an MF battery are different from those of conventional batteries. The MF battery should be charged as explained in the charging method illustrations. If the battery is overcharged, the electrolyte level will drop considerably. Therefore, take special care when charging the battery.
-



NOTE: _____

- The charge state of an MF battery can be checked by measuring its open-circuit voltage (i.e., the voltage when the positive terminal is disconnected).
- No charging is necessary when the open-circuit voltage equals or exceeds 12.8 V.

b. Check the charge of the battery, as shown in the charts and the following example.

Example

- c. Open-circuit voltage = 12.0 V
- d. Charging time = 6.5 hours
- e. Charge of the battery = 20 ~ 30%



6. Charge:

- battery
(refer to the appropriate charging method illustration)



Do not quick charge a battery.



CAUTION:

- **Never remove the MF battery sealing caps.**
- **Do not use a high-rate battery charger since it forces a high-amperage current into the battery quickly and can cause battery overheating and battery plate damage.**
- **If it is impossible to regulate the charging current on the battery charger, be careful not to overcharge the battery.**
- **When charging a battery, be sure to remove it from the machine. (If charging has to be done with the battery mounted on the machine, disconnect the negative battery lead from the battery terminal.)**
- **To reduce the chance of sparks, do not plug in the battery charger until the battery charger leads are connected to the battery.**




- Before removing the battery charger lead clips from the battery terminals, be sure to turn off the battery charger.
 - Make sure the battery charger lead clips are in full contact with the battery terminal and that they are not shorted. A corroded battery charger lead clip may generate heat in the contact area and a weak clip spring may cause sparks.
 - If the battery becomes hot to the touch at any time during the charging process, disconnect the battery charger and let the battery cool before reconnecting it. Hot batteries can explode!
 - As shown in the following illustration, the open-circuit voltage of an MF battery stabilizes about 30 minutes after charging has been completed. Therefore, wait 30 minutes after charging is completed before measuring the open-circuit voltage.
-


Charging method using a variable-current (voltage) charger



Charging method using a constant voltage charger



7. Install:
 - battery
8. Install:
 - battery holding bracketRefer to “SEAT, FENDERS AND FUEL TANK”.



9. Connect:
 - battery leads
(to the battery terminals)

CAUTION:

First, connect the positive battery lead ①, and then the negative battery lead ②.

10. Check:
 - battery terminals
Dirt → Clean with a wire brush.
Loose connection → Connect properly.

11. Lubricate:
 - battery terminals



**Recommended lubricant
Dielectric grease**

12. Install:
 - seatRefer to “SEAT, FENDERS AND FUEL TANK”.

CHK
ADJ

| Items | Amperage rating | Q'ty |
|---------|-----------------|------|
| Main | 15 A | 1 |
| Reserve | 15 A | 1 |

Never use a fuse with an amperage rating other than that specified. Improvising or using a fuse with the wrong amperage rating may cause extensive damage to the electrical system, cause the lighting and ignition systems to malfunction and could possibly cause a fire.

[illegible]

-

EBS00122

1. Adjust:

- headlight beam (vertically)

[illegible]

- a. Turn the adjusting bolt ① in direction ② or ③.

| | |
|--------------------|-----------------------------------|
| Direction ① | Headlight beam is raised. |
| Direction ② | Headlight beam is lowered. |


EBS00124

REPLACING A HEADLIGHT BULB

1. Remove:

- headlight

Refer to “SEAT, FENDERS AND FUEL TANK”.




2. Disconnect:

- headlight lead coupler ①

3. Remove:

- headlight bulb holder cover ②



4. Remove:

- bulb holder ①
- bulb

NOTE:

Push the headlight bulb holder inward, turn it counterclockwise and remove the defective bulb.

⚠ WARNING

Keep flammable products and your hands away from the bulb while it is on. since it will be hot. Do not touch the bulb until it cools down.

5. Install:


- bulb **New**

Secure the new bulb with the headlight unit.

CAUTION:

Avoid touching the glass part of the bulb. Keep it free from oil; otherwise, the transparency of the glass, life of the bulb, and luminous flux will be adversely affected. If oil gets on the bulb, thoroughly clean it with a cloth moistened with alcohol or lacquer thinner.

REPLACING A HEADLIGHT BULB



6. Install:
- bulb holder
 - headlight bulb holder cover ①

NOTE: _____

After installing the bulb holder cover, make sure that the "TOP" mark ③ is in the position shown.

7. Connect:
- headlight lead coupler ②
8. Install:
- headlight
- Refer to "SEAT, FENDERS AND FUEL TANK".




EBS00198

ENGINE


ENGINE REMOVAL

MUFFLER AND EXHAUST PIPE



4

| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|--|
| | Removing the muffler and exhaust pipe | | Remove the parts in the order listed. |
| | Seat/fuel tank cover/side covers (left and right) | | Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3. |
| | Fuel tank | | |
| | Right foot protector/engine skid plate | | |
| | | | |
| 1 | Clamp | 1 | Loosen. |
| 2 | Muffler | 1 | |
| 3 | Muffler protector | 1 | Refer to "INSTALLING THE EXHAUST PIPE AND MUFFLER". |
| 4 | Gasket | 1 | |
| 5 | Exhaust pipe | 1 | |
| 6 | Exhaust pipe protector | 1 | |
| 7 | Gasket | 1 | |
| | | | For installation, reverse the removal procedure. |



INSTALLING THE EXHAUST PIPE AND MUFFLER

1. Install:


- gasket ① **New**
(to muffler)

NOTE:

Install the gasket with the chamfer (a), located on an inner rim of the gasket, and the chamfer (b), located on an outer rim of the gasket, as shown.



Installed depth of gasket (c)
1 ~ 1.5 mm (0.04 ~ 0.06 in)



2. Install:


- exhaust pipe protector
- exhaust pipe protector screws



Screw
7 Nm (0.7 m · kg, 5.1 ft · lb)
LOCTITE®

NOTE:

Tighten the screws to the specified torque in the proper tightening sequence as shown.



3. Install:


- exhaust pipe ①
- nut (exhaust pipe) ②
- bolt (exhaust pipe) ③

13 Nm (1.3 m · kg, 9.4 ft · lb)

24 Nm (2.4 m · kg, 17 ft · lb)

NOTE:

First, temporarily tighten the nut (exhaust pipe), then tighten the bolt (exhaust pipe) 20 Nm (2.0 m · kg, 14 ft · lb). After that, retighten the nut (exhaust pipe) 13 Nm (1.3 m · kg, 9.4 ft · lb) and then the bolt (exhaust pipe) 24 Nm (2.4 m · kg, 17 ft · lb).



4. Install:

- clamp


NOTE:

Slide the clamp onto the end of the muffler and insert the projection ① of the clamp into a slot ② in the muffler. Tighten the clamp after installing the muffler.




EBS00204

LEADS, CABLES AND HOSES



| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|---|
| | Removing the leads, cables and hoses | | Remove the parts in the order listed. |
| | Engine oil | | Drain. |
| | Coolant | | Drain. |
| | Radiator outlet hose/water pump inlet pipe | | Refer to "WATER PUMP" in chapter 5. |
| | Carburetor | | Refer to "CARBURETOR" in chapter 6. |
| | Drive sprocket/drive chain | | Refer to "SWINGARM AND DRIVE CHAIN" in chapter 7. |
| 1 | Ignition coil | 1 | |
| 2 | Cylinder head breather hose | 1 | |
| 3 | Oil tank breather hose | 1 | |
| 4 | Radiator inlet hose | 1 | |
| 5 | Crankcase breather hose | 1 | |




| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------|------|--|
| 6 | Starter motor lead | 1 | Disconnect. |
| 7 | Battery negative lead | 1 | Disconnect. |
| 8 | Clutch cable | 1 | |
| 9 | Parking brake cable | 1 | |
| 10 | Oil pipe 1 | 1 | |
| 11 | A.C. magneto coupler | 2 | Disconnect. |
| 12 | Plastic band | 2 | |
| 13 | Oil pipe 2 | 1 | |
| 14 | Neutral switch lead | 1 | Disconnect. |
| | | | For installation, reverse the removal procedure. |




EBS00205


ENGINE MOUNTING BOLTS



| Order | Job/Part | Q'ty | Remarks |
|-------|---|-------|--|
| | Removing the engine mounting bolts | | Remove the parts in the order listed. |
| 1 | Engine lower bracket bolt | 4 | CAUTION: _____ Install all of the bolts/nuts and then tighten them to full torque specifications. |
| 2 | Engine mounting bolt (middle)/nut | 1/1 | |
| 3 | Engine lower bracket (right) | 1 | |
| 4 | Engine lower bracket (left) | 1 | |
| 5 | Engine mounting bolt (lower)/nut | 1/1 | |
| 6 | Engine upper bracket bolt | 2 | |
| 7 | Engine stay bolt/washer | 2/2 | |
| 8 | Engine stay | 1 | |
| 9 | Engine mounting bolt (upper)/washer | 1/1 | |
| 10 | Engine upper bracket (right) | 1 | |
| 11 | Engine upper bracket (left) | 1 | |
| 12 | Pivot shaft/nut/washer | 1/1/1 | |



| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------|------|--|
| 13 | Engine assembly | 1 | <p>NOTE: _____</p> <p>Remove the engine assembly from the right side of the machine.</p> <p>_____</p> <p>For installation, reverse the removal procedure.</p> |



EBS00206

INSTALLING THE ENGINE**1. Install:**

- pivot shaft/nut/washer ①
- engine upper bracket (left) ②
- engine upper bracket (right) ③
- engine mounting bolt (upper) ③
- engine stay ④
- engine stay bolts/washers ⑤
- engine upper bracket bolts ⑥
- engine mounting bolt (lower)/nut ⑦
- engine lower bracket (left) ⑧
- engine lower bracket (right) ⑧
- engine mounting bolt (middle)/nut ⑨
- engine lower bracket bolts ⑩

NOTE:

Do not fully tighten the bolts and nuts.

2. Tighten:

- pivot shaft/nut ①

100 Nm (10.0 m · kg, 72 ft · lb)

- engine mounting bolt (upper) ③

40 Nm (4.0 m · kg, 29 ft · lb)

- engine stay bolts ⑤

33 Nm (3.3 m · kg, 24 ft · lb)

- engine upper bracket bolts ⑥

26 Nm (2.6 m · kg, 19 ft · lb)

- engine mounting bolt (lower)/nut ⑦

66 Nm (6.6 m · kg, 48 ft · lb)

- engine mounting bolt (middle)/nut ⑨

66 Nm (6.6 m · kg, 48 ft · lb)

- engine lower bracket bolts ⑩


38 Nm (3.8 m · kg, 27 ft · lb)



EBS00208

CAMSHAFTS


CYLINDER HEAD COVER








| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|--|
| | Removing the cylinder head cover | | Remove the parts in the order listed. Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3. |
| 1 | Spark plug | 1 | |
| 2 | Engine upper bracket (right) | 1 | |
| 3 | Engine upper bracket (left) | 1 | |
| 4 | Engine stay | 1 | |
| 5 | Cylinder head breather hose | 1 | |
| 6 | Oil tank breather hose | 1 | |
| 7 | Cylinder head cover | 1 | |
| 8 | Cylinder head cover gasket | 1 | |
| 9 | Timing chain guide (top side) | 1 | |
| | | | For installation, reverse the removal procedure. |



CAMSHAFTS



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------|------|---|
| | Removing the camshafts | | Remove the parts in the order listed. |
| 1 | Tensioner cap bolt | 1 | Refer to "REMOVING THE CAM-SHAFTS" and "INSTALLING THE CAM-SHAFTS". |
| 2 | Timing chain tensioner | 1 | |
| 3 | Gasket | 1 | |
| 4 | Exhaust camshaft cap | 1 | |
| 5 | Clip | 1 | |
| 6 | Exhaust camshaft | 1 | |
| 7 | Intake camshaft cap | 1 | |
| 8 | Clip | 1 | |
| 9 | Intake camshaft | 1 | |
| | | | For installation, reverse the removal procedure. |



REMOVING THE CAMSHAFTS

1. Remove:

- timing mark accessing screw ①
- crankshaft end accessing screw ②

2. Align:

- "I" mark on the A.C. magneto rotor (with stationary pointer on the A.C. magneto cover)



a. Turn the crankshaft counterclockwise.

- b. When the piston is at the Top Dead Center (TDC) on the compression stroke, align the "I" mark ① on the A.C. magneto rotor with the stationary pointer ② on the A.C. magneto cover.

NOTE:

- In order to be sure that the piston is at the Top Dead Center (TDC), the punch mark ③ on the exhaust camshaft sprocket and the punch mark ④ on the intake camshaft sprocket must align with the cylinder head mating surface, as shown in the illustration.
- The Top Dead Center (TDC) on the compression stroke can be found when the camshaft lobes are turned away from each other.



3. Loosen:

- tensioner cap bolt ①

4. Remove:

- timing chain tensioner ②

5. Remove:


- camshaft cap bolts ①
- camshaft caps ②

NOTE:

Remove the camshaft cap bolts in a crisscross pattern, working from the outside in.

CAUTION:

To prevent damage to the cylinder head, camshafts or camshaft caps, loosen the camshaft cap bolts in stages and in a crisscross pattern, working from the outside in.




6. Remove:


- exhaust camshaft ①
- intake camshaft ②
- clips

NOTE:

To prevent the timing chain from falling into the crankcase, fasten it with a wire ③.



I1151001



I1151002

CHECKING THE CAMSHAFTS

1. Check:

- camshaft lobes
Pitting/scratches/blue discoloration → Replace the camshaft.

2. Measure:

- camshaft lobe dimensions ① and ②
Out of specification → Replace the camshaft.




Camshaft lobe dimensions

Intake

- ① 31.200 ~ 31.300 mm
(1.2283 ~ 1.2323 in)
<Limit>: 31.100 mm
(1.2244 in)
- ② 22.550 ~ 22.650 mm
(0.8878 ~ 0.8917 in)
<Limit>: 22.450 mm
(0.8839 in)

Exhaust

- ① 30.950 ~ 31.050 mm
(1.2185 ~ 1.2224 in)
<Limit>: 30.850 mm
(1.2146 in)
- ② 22.494 ~ 22.594 mm
(0.8856 ~ 0.8895 in)
<Limit>: 22.394 mm
(0.8817 in)




I1151402

3. Measure:

- camshaft runout
Out of specification → Replace.



Camshaft runout limit
0.03 mm (0.0012 in)



EBS00224

CHECKING THE CAMSHAFT SPROCKETS

1. Check:

- camshaft sprockets


Wear/damage → Replace the camshaft sprockets and timing chain as a set.

a 1/4 of a tooth

b Correct

① Roller

② Sprocket



EBS00225

CHECKING THE DECOMPRESSION SYSTEM

1. Check:

- decompression system

a. Check that the decompressor lever pin ① projects from the camshaft.

b. Check that the decompressor cam ② moves smoothly.

EBS00226

CHECKING THE TIMING CHAIN GUIDE

1. Check:

- timing chain guide (top side)

Wear/damage → Replace.





- d. Remove the screwdriver, mark sure that the timing chain tensioner rod releases, and then tighten the cap bolt to the specified torque.



Tensioner cap bolt
7 Nm (0.7 m · kg, 5.1 ft · lb)



4. Turn:
- crankshaft
 (counterclockwise several turns)
5. Check:
- A.C. magneto rotor “I” mark
 Align with the A.C. magneto cover stationary pointer.
 - camshaft sprocket punch marks
 Align with the cylinder head mating surface.
 Out of alignment → Adjust.
 Refer to “INSTALLING THE CAMSHAFTS”.
6. Measure:
- valve clearance
 Out of specification → Adjust.
 Refer to “ADJUSTING THE VALVE CLEARANCE” in chapter 3.



7. Install:
- timing chain guide (top side)
 - cylinder head cover gasket **New**
 - cylinder head cover


10 Nm (1.0 m · kg, 7.2 ft · lb)

NOTE:


- Apply Sealant (Quick Gasket®) or Yamaha bond No. 1215 ① onto the mating surfaces of the cylinder head cover and cylinder head cover gasket.
- Apply Sealant (Quick Gasket®) or Yamaha bond No. 1215 ② onto the mating surfaces of the cylinder head cover gasket and cylinder head.



CYLINDER HEAD




| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|--|
| | Removing the cylinder head | | Remove the parts in the order listed. |
| | Seat/fuel tank cover/side covers (left and right)/fuel tank | | Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3. |
| | Muffler and exhaust pipe | | Refer to "MUFFLER AND EXHAUST PIPE". |
| | Radiator inlet hose/parking brake and clutch cable holder | | Refer to "LEADS, CABLES AND HOSES". |
| | Parking brake holder | | |
| | Carburetor | | Refer to "CARBURETOR" in chapter 6. |
| | Camshafts | | Refer to "CAMSHAFTS". |
| 1 | Radiator inlet hose | 1 | |
| 2 | Cylinder head water jacket | 1 | |
| 3 | Oil delivery pipe 1 | 1 | Refer to "INSTALLING THE CYLINDER HEAD". |



| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------------------|------|---|
| 4 | Cylinder head | 1 | Refer to "REMOVING THE CYLINDER HEAD" and "INSTALLING THE CYLINDER HEAD". |
| 5 | Cylinder head gasket | 1 | |
| 6 | Dowel pin | 2 | |
| 7 | Timing chain guide (exhaust side) | 1 | |
| | | | For installation, reverse the removal procedure. |

NOTE:

*1: Tighten the cylinder head bolts to 30 Nm (3.0 m · kg, 22 ft · lb) in the proper tightening sequence, remove and retighten the cylinder head bolts to 20 Nm (2.0 m · kg, 14 ft · lb) in the proper tightening sequence, and then tighten the cylinder head bolts further in two steps of 90° to reach the specified angle of 180° in the proper tightening sequence.

**REMOVING THE CYLINDER HEAD**

1. Remove:

- cylinder head

NOTE:

- Loosen the bolts in the proper sequence.
- Follow the numerical order shown in the illustration. Loosen each bolt 1/4 of a turn at a time until all of the bolts are loose.

EBS00230

CHECKING THE CYLINDER HEAD


1. Eliminate:

- combustion chamber carbon deposits (with a rounded scraper)

NOTE:


Do not use a sharp instrument to avoid damaging or scratching:

- spark plug bore threads
- valve seats



2. Check:

- cylinder head
Damage/scratches → Replace.
- cylinder head water jacket
Mineral deposits/rust → Eliminate.



3. Measure:


- cylinder head warpage
Out of specification → Resurface the cylinder head.



**Maximum cylinder head warpage
0.05 mm (0.002 in)**



- Place a straightedge ① and a thickness gauge ② across the cylinder head.
- Measure the warpage.
- If the limit is exceeded, resurface the cylinder head as follows.
- Place a 400 ~ 600 grit wet sandpaper on the surface plate and resurface the cylinder head using a figure-eight sanding pattern.





NOTE:

To ensure an even surface, rotate the cylinder head several times.



CHECKING THE OIL DELIVERY PIPE

1. Check:
 - oil delivery pipe 1
Cracks/damage → Replace.
Clogged → Blow out with compressed air.

CHECKING THE TIMING CHAIN GUIDE


1. Check:
 - timing chain guide (exhaust side)
Wear/damage → Replace.

INSTALLING THE CYLINDER HEAD

1. Install:
 - timing chain guide (exhaust side)
 - gasket **New**
 - dowel pins
2. Install:
 - cylinder head

NOTE:

Pass the timing chain through the timing chain cavity.



3. Install:

- washers
- bolts ①: $\ell = 159 \text{ mm (6.26 in)}$
- bolts ②: $\ell = 149 \text{ mm (5.87 in)}$

**NOTE:**


Tighten the bolts to the specified torque in two or three steps in the proper tightening sequence as shown.

- Wash the threads and contact surfaces of the bolts, the contact surfaces of the washers, the contact surface of the cylinder head, and the threads of the crankcase.
- Apply molybdenum disulfide grease on the threads and contact surfaces of the bolts and on both contact surfaces of the washers.
- Install the washers and bolts.
- Tighten the bolts to the specified torque in two or three steps in the proper tightening sequence as shown.

**Cylinder head bolts****1st****30 Nm (3.0 m · kg, 22 ft · lb)**

- Remove the bolts.
- Again apply molybdenum disulfide grease on the threads and contact surfaces of the bolts and on both contact surfaces of the washers.
- Retighten the bolts.

**Cylinder head bolts****2nd****20 Nm (2.0 m · kg, 14 ft · lb)**



- h. Put a mark on the corner ① of the cylinder head bolt and the cylinder head ② as shown.

NOTE:



Tighten the bolts 90° in each of the two steps to reach the specified angle of 180° in the proper tightening sequence as shown.

**Cylinder head bolts****Final****Specified angle 180°**

4. Install:

- cylinder head nuts

10 Nm (1.0 m · kg, 7.2 ft · lb)



5. Install:

- copper washers **New**
- oil delivery pipe 1 ①
- union bolts (M8) ②

18 Nm (1.8 m · kg, 13 ft · lb)


- union bolt (M10) ③

20 Nm (2.0 m · kg, 14 ft · lb)




EBS00234

VALVES AND VALVE SPRINGS



| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|---|
| | Removing the valves and valve springs | | Remove the parts in the order listed. |
| | Cylinder head | | Refer to "CYLINDER HEAD". |
| 1 | Valve lifter | 5 | Refer to "REMOVING THE VALVES AND VALVE SPRINGS" and "INSTALLING THE VALVES AND VALVE SPRINGS". |
| 2 | Adjusting pad | 5 | |
| 3 | Valve cotter | 10 | |
| 4 | Upper valve spring seat | 5 | |
| 5 | Exhaust valve spring | 2 | |
| 6 | Intake valve spring | 3 | |



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------|------|---|
| 7 | Stem seal | 5 | Refer to "REMOVING THE VALVES AND VALVE SPRINGS" and "INSTALLING THE VALVES AND VALVE SPRINGS". For installation, reverse the removal procedure. |
| 8 | Lower valve spring seat | 5 | |
| 9 | Exhaust valve | 2 | |
| 10 | Intake valve 1 | 1 | |
| 11 | Intake valve 2 | 2 | |




EBS00238

REMOVING THE VALVES AND VALVE SPRINGS

The following procedure applies to all of the valves and related components.

NOTE:

Before removing the internal parts of the cylinder head (e.g., valves, valve springs, valve seats), make sure the valves properly seal.




1. Remove:

- valve lifter ①
- valve pad ②

NOTE:

Make a note of the position of each valve lifter and valve pad so that they can be reinstalled in their original place.




2. Check:

- valve sealing

Leakage at the valve seat → Check the valve face, valve seat and valve seat width. Refer to "CHECKING THE VALVES AND VALVE SPRINGS".



- Pour a clean solvent ③ into the intake and exhaust ports.
- Check that the valve seals properly. There should be no leakage at the valve seat ①.



3. Remove:


- valve cotteners

NOTE:

Attach a valve spring compressor ① and attachment ② between the valve spring retainer and the cylinder head to remove the valve cotteners.



Valve spring compressor
P/N. YM-04019, 90890-04019
Valve spring compressor attachment
P/N. YM-04114, 90890-04114




4. Remove:

- upper valve spring seat ①
- valve spring ②
- valve stem seal ③
- lower valve spring seat ④
- valve ⑤

NOTE:

Identify the position of each part very carefully so that it can be reinstalled in its original place.



EBS00240


CHECKING THE VALVES AND VALVE SPRINGS

1. Measure:

- stem-to-guide clearance

Stem-to-guide clearance =
valve guide inside diameter (a) -
valve stem diameter (b)

Out of specification → Replace the valve guide.






Stem-to-guide clearance

Intake

0.010 ~ 0.037 mm
(0.0004 ~ 0.0015 in)
<Limit>: 0.080 mm (0.003 in)

Exhaust

0.020 ~ 0.047 mm
(0.0008 ~ 0.0019 in)
<Limit>: 0.100 mm (0.004 in)



11170601

2. Replace:
 - valve guide



NOTE:

To ease guide removal, installation and to maintain correct fit, heat the cylinder head to 100 °C (212 °F) in an oven.

- a. Remove the valve guide using a valve guide remover ①.
- b. Install the new valve guide using a valve guide remover ① and valve guide installer ②.
- c. After installing the valve guide, bore the valve guide using a valve guide reamer ③ to obtain proper stem-to-guide clearance.



Valve guide remover

Intake (ø 4.5)

P/N. YM-04116/90890-04116

Exhaust (ø 5)

P/N. YM-04097/90890-04097

Valve guide installer

Intake (ø 4.5)

P/N. YM-04117/90890-04117

Exhaust (ø 5)

P/N. YM-04098/90890-04098

Valve guide reamer

Intake (ø 4.5)

P/N. YM-04118/90890-04118

Exhaust (ø 5)




P/N. YM-04099/90890-04099

NOTE:

After replacing the valve guide reface the valve seat.



3. Check:
 - valve face
Pitting/wear → Grind the face.
 - valve stem end
Mushroom shape or diameter larger than the body of the stem → Replace.



4. Measure:

- margin thickness ①
- Out of specification → Replace.



Margin thickness

Intake

1.0 mm (0.0394 in)

<Limit>: 0.85 mm (0.033 in)

Exhaust

1.0 mm (0.0394 in)

<Limit>: 0.85 mm (0.033 in)

5. Measure:

- valve stem runout
- Out of specification → Replace.



Valve stem runout

0.01 mm (0.0004 in)

NOTE:

- When installing a new valve always replace the guide.
- If the valve is removed or replaced always replace the oil seal.

6. Eliminate:

- carbon deposits
(from the valve face and valve seat)

7. Check:

- valve seats
- Pitting/wear → Reface the valve seat.

8. Measure:

- valve seat width ①
- Out of specification → Reface the valve seat.



Valve seat width

Intake

0.9 ~ 1.1 mm

(0.0354 ~ 0.0433 in)

<Limit>: 1.6 mm (0.06 in)

Exhaust


0.9 ~ 1.1 mm

(0.0354 ~ 0.0433 in)

<Limit>: 1.6 mm (0.06 in)



- f. Apply Mechanic's blueing dye (Dykem) to the valve face.
- g. Install the valve into the cylinder head.
- h. Press the valve through the valve guide and onto the valve seat to make a clear pattern.
- i. Measure the valve seat width again. If the valve seat width is out of specification, reface and relap the valve seat.



10.Measure:

- valve spring free length ①
- Out of specification → Replace.



Valve spring free length

Intake


37.03 mm (1.46 in)

<Limit>: 35.17 mm (1.38 in)

Exhaust

37.68 mm (1.48 in)

<Limit>: 35.79 mm (1.41 in)



11.Measure:

- compressed valve spring force ①
- Out of specification → Replace.

② Installed length



Compressed valve spring force (installed)

Intake

111.3 ~ 127.9 N at 27.87 mm

(11.35 ~ 13.04 kg at 27.87 mm,


25.02 ~ 28.75 lb at 1.10 in)

Exhaust

127.4 ~ 146.4 N at 27.38 mm

(12.99 ~ 14.93 kg at 27.38 mm,

28.64 ~ 32.91 lb at 1.08 in)



12. Measure:

- valve spring tilt ①

Out of specification → Replace.




Valve spring tilt limit

Intake

2.5°/1.61 mm (0.063 in)

Exhaust

2.5°/1.65 mm (0.065 in)



EAS00242

CHECKING THE VALVE LIFTERS

The following procedure applies to all of the valve lifters.

1. Check:

- valve lifter


Damage/scratches → Replace the valve lifters and cylinder head.

EBS00241

INSTALLING THE VALVES AND VALVE SPRINGS

1. Apply:

- molybdenum disulfide oil
(onto the valve stem and valve stem seal)




2. Install:

- valves
- lower valve spring seats
- valve stem seals **New**
- valve springs
- upper valve spring seats

NOTE:

Install the valve springs with the larger pitch ① facing upwards.

② Smaller pitch



3. Install:
- valve cotters

NOTE:

Install the valve cotters while compressing the valve spring with the valve spring compressor ① and attachment ②.



Valve spring compressor
P/N. YM-04019, 90890-04019
Valve spring compressor attachment
P/N. YM-04114, 90890-04114

4. To secure the valve cotters onto the valve stem, lightly tap the valve tip with a piece of wood.

CAUTION:

Hitting the valve tip with excessive force could damage the valve.

5. Install:
- valve pads
 - valve lifters


NOTE:

- Lubricate the valve lifters with engine oil and valve pads with molybdenum disulfide oil.
- The valve lifters must move smoothly when rotated with a finger.
- Each valve lifter and valve pad must be reinstalled in its original position.






EBS00245

CYLINDER AND PISTON



| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|--|
| | Removing the cylinder and piston | | |
| | Cylinder head | | Remove the parts in the order listed. |
| | | | Refer to "CYLINDER HEAD". |
| 1 | Cylinder | 1 | Refer to "INSTALLING THE CYLINDER". |
| 2 | Cylinder gasket | 1 | |
| 3 | Dowel pin | 2 | |
| 4 | Dowel pin/O-ring | 1/1 | |
| 5 | Piston pin clip | 2 | |
| 6 | Piston pin | 1 | |
| 7 | Piston | 1 | Refer to "REMOVING THE PISTON" |
| 8 | Top ring | 1 | and "INSTALLING THE PISTON". |
| 9 | 2nd ring | 1 | |
| 10 | Oil ring | 1 | |
| | | | For installation, reverse the removal procedure. |



EBS00247

REMOVING THE PISTON

1. Remove:

- piston pin clips ①
- piston pin ②
- piston ③

NOTE:

Before removing each piston pin, deburr the clip groove and pin hole area. If the piston pin groove is deburred and the piston pin is still difficult to remove, use the piston pin puller ④.



Piston pin puller
P/N. YU-01304, 90890-01304

CAUTION:

Do not use a hammer to drive the piston pin out.

2. Remove:

- piston rings

NOTE:

Spread the end gaps apart while at the same time lifting the piston ring over the top of the piston crown, as shown in the illustration.


EBS00248

CHECKING THE CYLINDER AND PISTON

1. Check:

- piston wall
- cylinder wall

Vertical scratches → Replace the cylinder, and the piston and piston rings as a set.



2. Measure:

- piston-to-cylinder clearance




- a. Measure the cylinder bore “C” with a cylinder bore gauge.


NOTE:

Measure the cylinder bore “C” in parallel to and right angles to the crankshaft. Then, find the average of the measurements.

| | |
|--|--|
| Cylinder bore “C” | 95.00 ~ 95.01 mm (3.7402 ~ 3.7406 in) |
| Taper limit “T” | 0.05 mm (0.002 in) |
| Out of round “R” | 0.05 mm (0.002 in) |
| “C” = Maximum D | |
| “T” = (Maximum D ₁ or D ₂) – (Maximum D ₅ or D ₆) | |
| “R” = (Maximum D ₁ , D ₃ or D ₅) – (Minimum D ₂ , D ₄ or D ₆) | |


- b. If out of specification, replace the cylinder, and the piston and piston rings as a set.
- c. Measure piston skirt diameter “P” with the micrometer.
- ① 10 mm (0.39 in) from the bottom edge of the piston



| | |
|--|--|
|  Piston size “P” | |
| Standard | 94.945 ~ 94.960 mm (3.7380 ~ 3.7386 in) |


- d. If out of specification, replace the piston and piston rings as a set.
- e. Calculate the piston-to-cylinder clearance with the following formula.

Piston-to-cylinder clearance =
Cylinder bore “C” -
Piston skirt diameter “P”

| |
|--|
|  Piston-to-cylinder clearance 0.04 ~ 0.065 mm (0.0016 ~ 0.0026 in) <Limit>: 0.10 mm (0.004 in) |
|--|



- f. If out of specification, replace the cylinder, and the piston and piston rings as a set.



EBS00250

CHECKING THE PISTON RINGS

1. Measure:

- piston ring side clearance

Out of specification → Replace the piston and piston rings as a set.

NOTE:

Before measuring the piston ring side clearance, eliminate any carbon deposits from the piston ring grooves and piston rings.

**Piston ring side clearance****Top ring**

0.030 ~ 0.065 mm

(0.0012 ~ 0.0026 in)


<Limit>: 0.12 mm (0.0047 in)

2nd ring

0.020 ~ 0.055 mm

(0.0008 ~ 0.0022 in)

<Limit>: 0.12 mm (0.0047 in)



11221401

2. Install:

- piston ring
(into the cylinder)

NOTE:

Level the piston ring into the cylinder with the piston crown.

① 10 mm (0.39 in)



3. Measure:

- piston ring end gap

Out of specification → Replace the piston ring.

NOTE:

The oil ring expander spacer's end gap cannot be measured. If the oil ring rail's gap is excessive, replace all three piston rings.

**Piston ring end gap****Top ring**

0.20 ~ 0.30 mm

(0.008 ~ 0.012 in)

<Limit>: 0.55 mm (0.022 in)

2nd ring

0.35 ~ 0.50 mm

(0.014 ~ 0.020 in)

<Limit>: 0.85 mm (0.034 in)

Oil ring

0.20 ~ 0.50 mm

(0.008 ~ 0.020 in)


EBS00251

CHECKING THE PISTON PIN

1. Check:

- piston pin

Blue discoloration/grooves → Replace the piston pin and then check the lubrication system.



2. Measure:

- piston pin outside diameter ①

Out of specification → Replace the piston pin.

**Piston pin outside diameter**

19.991 ~ 20.000 mm

(0.7870 ~ 0.7874 in)

<Limit>: 19.971 mm (0.786 in)

3. Measure:

- piston pin bore inside diameter


Out of specification → Replace the piston.

**Piston pin bore inside diameter**

20.004 ~ 20.015 mm

(0.7876 ~ 0.7880 in)

<Limit>: 20.045 mm (0.789 in)



4. Calculate:

- piston-pin-to-piston-pin-bore clearance

Out of specification → Replace the piston pin and piston as a set.

Piston-pin-to-piston-pin-bore clearance =

Piston pin bore diameter ② –


Piston pin outside diameter ①

**Piston-pin-to-piston clearance**

0.004 ~ 0.024 mm

(0.0002 ~ 0.0009 in)

<Limit>: 0.074 mm (0.0029 in)



EBS00252


INSTALLING THE PISTON

1. Install:

- piston rings
(onto the piston)

NOTE:

- Be sure to install the piston rings so that the manufacturer's marks or numbers are located on the upper side of the rings.
- Lubricate the piston and piston rings liberally with engine oil.




2. Position:

- top ring
- 2nd ring
- oil ring

Offset the piston ring end gaps as shown.

- Ⓐ Top ring end
- Ⓑ 2nd ring end
- Ⓒ Oil ring end (upper)
- Ⓓ Oil ring
- Ⓔ Oil ring end (lower)




3. Install:

- piston ①
- piston pin ②
- piston pin clips ③ **New**

NOTE:

- Apply engine oil onto the piston pin, piston rings and piston.
- Be sure that the punch mark Ⓐ on the piston points to the exhaust side of the engine.
- Before installing the piston pin clips, cover the crankcase with a clean rag to prevent the piston pin clips from falling into the crankcase.
- Install the piston clips with their ends facing downward.






4. Lubricate:
- piston
 - piston rings
 - cylinder

NOTE:

Apply a liberal coating of engine oil.



EBS00253

INSTALLING THE CYLINDER

1. Install:

- cylinder gasket ① **New**
- dowel pins
- O-ring
- cylinder ②
- bolts

10 Nm (1.0 m · kg, 7.2 ft · lb)

NOTE:

Install the cylinder with one hand while compressing the piston rings with the other hand.


CAUTION:

- Be careful not to damage the timing chain damper during installation.
- Pass the timing chain through the timing chain cavity.




EBS00256


A.C. MAGNETO



| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------------|------|---|
| | Removing the A.C. magneto | | |
| | Engine oil | | Remove the parts in the order listed. |
| | Front fender | | Drain. |
| | | | Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3. |
| 1 | A.C. magneto coupler | 2 | Disconnect. |
| 2 | Crankcase breather hose | 1 | |
| 3 | Torque limiter cover | 1 | |
| 4 | Torque limiter | 1 | NOTE: _____ Do not disassemble. _____ |
| 5 | A.C. magneto cover/gasket | 1/1 | Refer to "REMOVING THE A.C. MAGNETO ROTOR" and "INSTALLING THE A.C. MAGNETO ROTOR". |
| 6 | Dowel pin | 2 | |
| 7 | Lead holder | 1 | |
| 8 | Pickup coil | 1 | |



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------|------|---|
| 9 | Stator coil | 1 | Refer to "REMOVING THE A.C. MAGNETO ROTOR" and "INSTALLING THE A.C. MAGNETO ROTOR". |
| 10 | Starter idle gear | 1 | |
| 11 | Bearing | 2 | |
| 12 | Starter idle gear shaft | 1 | |
| 13 | A.C. magneto rotor | 1 | |
| 14 | Starter clutch | 1 | For installation, reverse the removal procedure. |
| 15 | Woodruff key | 1 | |
| 16 | Starter wheel gear | 1 | |



EBS00259


REMOVING THE A.C. MAGNETO ROTOR

1. Remove:

- A.C. magneto cover

NOTE:

Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.



2. Remove:


- A.C. magneto rotor nut ①
- washer

NOTE:

- While holding the A.C. magneto rotor ② with the sheave holder ③, loosen the rotor nut.
- Do not allow the sheave holder to touch the projection ④ on the rotor.



Sheave holder
P/N. YS-01880-A, 90890-01701



3. Remove:


- A.C. magneto rotor ①

NOTE:

Use the rotor puller ②.



Rotor puller
P/N. YM-04142, 90890-04142




EBS00262

CHECKING THE STATOR COIL AND PICKUP COIL


1. Check:

- stator coil
- pickup coil

Damage → Replace the pickup coil/stator assembly.

**CHECKING THE TORQUE LIMITER**

1. Check:
 - torque limiterDamage/wear → Replace.




EBS00268

INSTALLING THE A.C. MAGNETO ROTOR

1. Install:
 - stator coil ①
 - pickup coil

NOTE:

Align the projection (a) on the stator coil with the slot (b) in the A.C. magneto cover.



2. Apply:

- sealant (Quick Gasket®) or Yamaha bond No. 1215 ① (into the slit)




Sealant (Quick Gasket®)
P/N. ACC-11001-05-01
Yamaha bond No. 1215
P/N. 90890-85505

3. Install:

- woodruff key
- A.C. magneto rotor

NOTE:

- Before installing the rotor, clean the outside of the crankshaft and the inside of the rotor.
- After installing the rotor, check that the rotor rotates smoothly. If not, reinstall the key and rotor.



4. Tighten:

- A.C. magneto rotor nut ①


65 Nm (6.5 m · kg, 47 ft · lb)

NOTE:

- While holding the A.C. magneto rotor ② with the sheave holder ③, tighten the A.C. magneto rotor nut.
- Do not allow the sheave holder to touch the projection ④ on the rotor.

**Sheave holder**

P/N. YS-01880-A, 90890-01701




5. Install:

- gasket **New**
- A.C. magneto cover
- A.C. magneto lead holder ①
- neutral switch lead holder ②
- bolts

10 Nm (1.0 m · kg, 7.2 ft · lb)

NOTE:

Tighten the A.C. magneto cover bolts in stages, using a crisscross pattern.



6. Install:

- torque limiter cover ①


10 Nm (1.0 m · kg, 7.2 ft · lb)

NOTE:


Install the torque limiter cover with the projection a facing up.





EBS00291

CLUTCH

| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------|------|---|
| | Removing the clutch | | |
| | Engine oil | | Remove the parts in the order listed. |
| | Clutch cable | | Drain. |
| | | | Refer to "LEADS, CABLES AND HOSES". |
| 1 | Clutch cover | 1 | Refer to "REMOVING THE CLUTCH" and "INSTALLING THE CLUTCH". |
| 2 | Gasket | 1 | |
| 3 | Dowel pin | 2 | |
| 4 | Clutch spring | 6 | Refer to "INSTALLING THE CLUTCH". |
| 5 | Pressure plate | 1 | |
| 6 | Push rod 1 | 1 | |
| 7 | Circlip | 1 | |
| 8 | Plain washer | 1 | |
| 9 | Bearing | 1 | |
| 10 | Ball | 1 | |



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------|------|---|
| 11 | Push rod 2 | 1 | Refer to "INSTALLING THE CLUTCH". |
| 12 | Friction plate 1 | 7 | |
| 13 | Clutch plate | 7 | |
| 14 | Friction plate 2 | 1 | |
| 15 | Spring washer | 1 | Refer to "REMOVING THE CLUTCH" and "INSTALLING THE CLUTCH". |
| 16 | Seat plate | 1 | |
| 17 | Lock washer | 1 | |
| 18 | Clutch boss | 1 | |
| 19 | Thrust washer | 1 | Refer to "INSTALLING THE CLUTCH". |
| 20 | Clutch housing | 1 | |
| 21 | Push lever shaft | 1 | For installation, reverse the removal procedure. |
| 22 | Circlip/washer | 1/1 | |
| 23 | Push lever | 1 | |



EBS00297

REMOVING THE CLUTCH

1. Remove:

- clutch cover ①

NOTE:

Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.

2. Straighten the lock washer tab.

3. Loosen:

- clutch boss nut ①

NOTE:

While holding the clutch boss ② with the universal clutch holder ③, loosen the clutch boss nut.



Universal clutch holder
P/N. YM-91042, 90890-04086

EBS00300

CHECKING THE FRICTION PLATES

The following procedure applies to all of the friction plates.

1. Check:

- friction plate 1
- friction plate 2

Damage/wear → Replace the friction plates as a set.


2. Measure:

- friction plate 1 thickness
- friction plate 2 thickness

Out of specification → Replace the friction plates as a set.

NOTE:

Measure the friction plate at four places.

**Friction plate 1 thickness**


2.9 ~ 3.1 mm (0.114 ~ 0.122 in)

<Limit>: 2.8 mm (0.110 in)

Friction plate 2 thickness

2.9 ~ 3.1 mm (0.114 ~ 0.122 in)

<Limit>: 2.8 mm (0.110 in)



EBS00301

CHECKING THE CLUTCH PLATES

The following procedure applies to all of the clutch plates.

1. Check:

- clutch plate

Damage → Replace the clutch plates as a set.

2. Measure:

- clutch plate warpage

(with a surface plate and thickness gauge
①)

Out of specification → Replace the clutch plates as a set.



Clutch plate warpage
0.2 mm (0.0079 in)

EBS00302

CHECKING THE CLUTCH SPRINGS

The following procedure applies to all of the clutch springs.

1. Check:


- clutch spring

Damage → Replace the clutch springs as a set.


2. Measure:

- clutch spring free length ②

Out of specification → Replace the clutch springs as a set.



Clutch spring free length
51.8 mm (2.04 in)
<Limit>: 50.0 mm (1.97 in)



EBS00303

CHECKING THE CLUTCH HOUSING


1. Check:

- clutch housing dogs

Damage/pitting/wear → Deburr the clutch housing dogs or replace the clutch housing.

NOTE:

Pitting on the clutch housing dogs will cause erratic clutch operation.



EBS00304

CHECKING THE CLUTCH BOSS


1. Check:

- clutch boss splines

Damage/pitting/wear → Replace the clutch boss.

NOTE:

Pitting on the clutch boss splines will cause erratic clutch operation.




EBS00305

CHECKING THE PRESSURE PLATE

1. Check:

- pressure plate


Cracks/damage → Replace.

**CHECKING THE PUSH RODS**

1. Check:

- push rod 1 ①
- bearing ②
- plain washer ③
- push rod 2 ④
- ball ⑤


Wear/damage/cracks/bend → Replace the defective part(s).

**CHECKING THE PUSH LEVER**

1. Check:

- push lever ①
- push lever shaft ②

Damage/wear → Replace.



EBS00307


CHECKING THE PRIMARY DRIVEN GEAR

1. Check:

- primary driven gear

Damage/wear → Replace the primary drive gear and clutch housing as a set.

Excessive noise during operation → Replace the primary drive gear and clutch housing as a set.



EBS00311

INSTALLING THE CLUTCH

1. Install:
 - push lever


NOTE:

Align the punch mark (a) on the push lever with the punch mark (b) on the push lever shaft.

2. Install:
 - clutch housing

NOTE:

- Make sure that the primary driven gear teeth and primary drive gear teeth mesh correctly.
- Make sure that the oil pump drive gear teeth and oil pump driven gear teeth mesh correctly.



3. Tighten:
 - thrust washer
 - clutch boss
 - lock washer **New**
 - clutch boss nut (1)

75 Nm (7.5 m · kg, 54 ft · lb)


NOTE:

While holding the clutch boss (2) with the universal clutch holder (3), tighten the clutch boss nut.



Universal clutch holder
P/N. YM-91042, 90890-04086

4. Bend the lock washer tab along a flat side of the nut.




5. Install:
 - clutch spring 8 Nm (0.8 m · kg, 5.8 ft · lb)

NOTE:


Tighten the bolts in stages, using a crisscross pattern.



BALANCER



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------|------|---|
| | Removing the balancer | | |
| | Clutch housing | | Remove the parts in the order listed. |
| | Right crankcase cover | | Refer to "CLUTCH". |
| | A.C. magneto rotor | | Refer to "WATER PUMP" in chapter 5. |
| | | | Refer to "A.C. MAGNETO". |
| 1 | Primary drive gear nut | 1 | Refer to "REMOVING THE BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR" and "INSTALLING THE BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR". |
| 2 | Balancer driven gear nut | 1 | |
| 3 | Lock washer | 1 | |
| 4 | Primary drive gear | 1 | |
| 5 | Balancer drive gear | 1 | |
| 6 | Lock washer | 1 | |
| 7 | Balancer driven gear | 1 | |
| 8 | Balancer | 1 | |
| | | | For installation, reverse the removal procedure. |




REMOVING THE BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR


1. Straighten the lock washer tab.
2. Loosen:
 - primary drive gear nut ①
 - balancer driven gear nut ②

NOTE:

Place an aluminum plate ④ between the teeth of the balancer drive gear ③ and driven gear ④.




3. Remove:
 - balancer drive gear
 - balancer driven gear




CHECKING THE PRIMARY DRIVE GEAR, BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR

1. Check:
 - primary drive gear ①
 - balancer drive gear ②
 - balancer driven gear ③
 Wear/damage → Replace.



CHECKING THE BALANCER

1. Check:
 - balancer
 Cracks/damage → Replace.




INSTALLING THE BALANCER DRIVE GEAR AND BALANCER DRIVEN GEAR

1. Install:

- balancer driven gear ①

NOTE:

Install the balancer driven gear onto the balancer while aligning the punch mark ① on the balancer driven gear with the shorter spline ② on the balancer end.




2. Install:

- balancer drive gear ①

NOTE:

- Align the punch mark ① on the balancer drive gear with the punch mark ② on the balancer driven gear.
- Align the punch mark ③ on the balancer drive gear with the shorter spline ④ on the crankshaft.



3. Install:

- lock washer ① **New**
- balancer driven gear nut ②


50 Nm (5.0 m · kg, 36 ft · lb)

- primary drive gear ③
- primary drive gear nut ④

75 Nm (7.5 m · kg, 54 ft · lb)

NOTE:

- Install the primary drive gear with its stepped side ① facing the engine.
- Place an aluminum plate ② between the teeth of the balancer drive gear ⑤ and driven gear ⑥.




4. Bend the lock washer tab.




EBS00315

OIL PUMP



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------|------|---------------------------------------|
| | Removing the oil pump | | |
| | Clutch housing | | Remove the parts in the order listed. |
| | Right crankcase cover | | Refer to "CLUTCH". |
| 1 | Circlip | 1 | Refer to "WATER PUMP" in chapter 5. |
| 2 | Washer | 1 | |
| 3 | Oil pump drive gear | 1 | |
| 4 | Oil pump assembly | 1 | |
| 5 | Dowel pin | 1 | |
| 6 | Outer rotor 2 | 1 | |
| 7 | Circlip | 1 | |
| 8 | Inner rotor 2 | 1 | |



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------|------|--|
| 9 | Pin | 1 | For installation, reverse the removal procedure. |
| 10 | Oil pump housing cover | 1 | |
| 11 | Outer rotor 1 | 1 | |
| 12 | Inner rotor 1 | 1 | |
| 13 | Pin | 1 | |
| 14 | Washer | 1 | |
| 15 | Oil pump driven gear | 1 | |
| 16 | Oil pump housing | 1 | |




EBS00317

CHECKING THE OIL PUMP**1. Check:**

- oil pump drive gear
- oil pump driven gear
- oil pump housing
- oil pump housing cover

Cracks/wear/damage → Replace.

**2. Measure:**

- inner-rotor-to-outer-rotor-tip clearance ①
- outer-rotor-to-oil-pump-housing clearance ②

Out of specification → Replace the oil pump.

- ① inner rotor
- ② outer rotor
- ③ oil pump housing

**Inner-rotor-to-outer-rotor-tip clearance**


0.07 ~ 0.12 mm
(0.0028 ~ 0.0047 in)

<Limit>: 0.20 mm (0.0079 in)

Outer-rotor-to-oil-pump-housing clearance

0.09 ~ 0.17 mm
(0.0035 ~ 0.0067 in)


<Limit>: 0.24 mm (0.0094 in)

**3. Check:**


- oil pump operation

Unsmooth → Repeat steps (1) and (2) or replace the defective parts.

| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------------|------|--|
| | Removing the shift shaft | | Remove the parts in the order listed. |
| | Clutch | | Refer to "CLUTCH". |
| | Oil pump drive gear | | Refer to "OIL PUMP". |
| 1 | Shift pedal | 1 | Refer to "INSTALLING THE SHIFT SHAFT". |
| 2 | Shift shaft | 1 | |
| 3 | Shift shaft spring/washer | 1/1 | |
| 4 | Roller | 1 | Refer to "INSTALLING THE SHIFT LEVER". |
| 5 | Shift guide | 1 | |
| 6 | Shift lever assembly | 1 | |
| 7 | Pawl holder | 1 | |
| 8 | Pawl | 2 | |
| 9 | Pawl pin | 2 | |
| 10 | Spring | 2 | |




| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------|------|--|
| 11 | Stopper lever | 1 | Refer to "INSTALLING THE SHIFT LEVER". |
| 12 | Stopper lever spring | 1 | |
| 13 | Shift drum segment | 1 | |
| | | | For installation, reverse the removal procedure. |



EBS01018

CHECKING THE SHIFT SHAFT


1. Check:
 - shift shaft ①
Bends/damage/wear → Replace.
 - shift shaft spring ②
Damage/wear → Replace.



EBS01019

CHECKING THE STOPPER LEVER


1. Check:
 - stopper lever ①
Bends/damage → Replace.
Roller turns roughly → Replace the stopper lever.
 - stopper spring ②
Damage/wear → Replace.



EBS00359


CHECKING THE SHIFT GUIDE AND SHIFT LEVER

1. Check:
 - shift guide ①
 - pawl holder ②
 - pawls ③
 - pawl pins ④
 - springs ⑤
Wear/cracks/damage → Replace.



CHECKING THE SHIFT DRUM SEGMENT

1. Check:
 - shift drum segment
Damage/wear → Replace.




INSTALLING THE SHIFT LEVER

1. Install:
 - shift drum segment ①
 - shift drum segment bolt

30 Nm (3.0 m · kg, 22 ft · lb)

NOTE:

Align the notch ① on the shift drum segment with the pin ② on the shift drum.




2. Install:
 - stopper lever spring ①
 - stopper lever ②

10 Nm (1.0 m · kg, 7.2 ft · lb)


NOTE:

Align the stopper lever roller with a slot on the shift drum segment.



3. Install:
 - springs ①
 - pawl pins ②
 - pawls ③
 - shift guide ④ (to the pawl holder)

10 Nm (1.0 m · kg, 7.2 ft · lb)




4. Install:
 - shift lever assembly ①
 - shift guide ②

10 Nm (1.0 m · kg, 7.2 ft · lb)

NOTE:

The shift lever assembly is installed at the same time as the shift guide.



INSTALLING THE SHIFT SHAFT

1. Install:
 - roller ①
 - shift shaft spring
 - shift shaft ②

NOTE:

- Install the end of the shift shaft spring onto the shift shaft spring stopper ③.
- Install the end of the shift shaft lever onto the roller ①.

2. Install:
 - shift pedal

12 Nm (1.2 m · kg, 8.7 ft · lb)

3. Adjust:


- shift pedal height

Refer to “ADJUSTING THE SHIFT PEDAL” in chapter 3.




EBS00320

CRANKCASE



| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------------|------|--|
| | Separating the crankcase | | Remove the parts in the order listed. |
| | Engine assembly | | Refer to "ENGINE REMOVAL". |
| | Camshafts | | Refer to "CAMSHAFTS". |
| | Cylinder head | | Refer to "CYLINDER HEAD". |
| | A.C. magneto | | Refer to "A.C. MAGNETO". |
| | Clutch | | Refer to "CLUTCH". |
| | Balancer | | Refer to "BALANCER". |
| | Oil pump | | Refer to "OIL PUMP". |
| | Shift drum segment | | Refer to "SHIFT SHAFT". |
| | Starter motor | | Refer to "STARTER MOTOR" in chapter 8. |
| 1 | Timing chain guide (intake side) | 1 | |
| 2 | Timing chain | 1 | |
| 3 | Neutral switch | 1 | |
| 4 | Hose guide | 1 | |




| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------|------|--|
| 5 | Circlip/spacer | 1/1 | Refer to "SEPARATING THE CRANK-CASE". |
| 6 | Oil delivery pipe 2 | 1 | |
| 7 | Right crankcase | 1 | |
| 8 | Left crankcase | 1 | |
| 9 | Dowel pin/O-ring | 1/1 | |
| 10 | Dowel pin | 2 | |
| 11 | Oil stainer | 1 | |
| | | | For installation, reverse the removal procedure. |




EBS00321

OIL SEAL AND BEARING




| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|--|
| | Removing the crankcase bearings | | |
| | Crankshaft | | Remove the parts in the order listed. |
| | Transmission | | Refer to "CRANKSHAFT". |
| 1 | Oil seal holder | 1 | Refer to "TRANSMISSION". |
| 2 | Oil seal | 3 | |
| 3 | Bearing retainer | 13 | |
| 4 | Bearing | 10 | |
| | | | For installation, reverse the removal procedure. |



2. Check:

- oil delivery pipe 2
Cracks/damage → Replace.
- oil delivery pipe holes ①
Clogged → Blow out with compressed air.



EBS00335


CHECKING THE TIMING CHAIN AND GUIDE

1. Check:

- timing chain
Cracks/stiffness → Replace the timing chain and camshaft as a set.

2. Check:

- timing chain guide (intake side)
Wear/damage → Replace.



EBS00339

CHECKING THE BEARINGS AND OIL SEALS

1. Check:

- bearings
Clean and lubricate, then rotate the inner race with a finger.
Roughness → Replace.



2. Check:

- oil seals
Damage/wear → Replace.

EBS00338

CHECKING THE CRANKCASE

1. Thoroughly wash the case halves in a mild solvent.
2. Clean all the gasket mating surfaces and crankcase mating surfaces thoroughly.
3. Check:
 - crankcase
Cracks/damage → Replace.
 - oil delivery passages
Clogged → Blow out with compressed air.



EBS00342

ASSEMBLING THE CRANKCASE

1. Install:

- bearing **New**
- bearing retainer
- bolt (bearing retainer)

10 Nm (1.0 m · kg, 7.2 ft · lb)

- screw [bearing retainer (crankshaft)] ①

12 Nm (1.2 m · kg, 8.7 ft · lb)

- screw [bearing retainer (drive axle)] ②


12 Nm (1.2 m · kg, 8.7 ft · lb)

NOTE:

- Install the bearing by pressing its outer race evenly.
- To prevent the screws [bearing retainer (crankshaft)] from becoming loose, flatten the edge ③ of each screw into the depression ④ using a punch, etc. Be careful not to damage the hole for the screwdriver in the screw head.

A Right crankcase

B Left crankcase



2. Apply:

- sealant (Quick Gasket®) or Yamaha bond No. 1215 ①
(to the mating surfaces of both case halves)



Sealant (Quick Gasket®)
ACC-11001-05-01
Yamaha bond No. 1215
90890-85505

3. Install:


- dowel pins ②
- O-ring ③ **New**



4. Fit the right crankcase onto the left crankcase. Tap lightly on the case with a soft hammer.


CAUTION:

Before installing and torquing the crankcase holding bolts, be sure to check whether the transmission is functioning properly by manually rotating the shift drum in both directions.



5. Install:
 - hose guide ①
 - crankcase bolts

6. Tighten:
 - crankcase bolts
(follow the proper tightening sequence)

 **12 Nm (1.2 m · kg, 8.7 ft · lb)**


NOTE:

Tighten the bolts in stages, using a crisscross pattern.


7. Apply:
 - 4-stroke engine oil
(to the crankshaft pin, bearing and oil delivery hole)
8. Check:
 - crankshaft and transmission operation
Unsmooth operation → Repair.



CRANKSHAFT



| Order | Job/Part | Q'ty | Remarks |
|-------|--------------------------------|------|---|
| 1 | Removing the crankshaft | 1 | Remove the parts in the order listed. Separate. Refer to "CRANKCASE". |
| | Crankshaft | | |
| | | | Refer to "REMOVING THE CRANK-SHAFT" and "INSTALLING THE CRANK-SHAFT". |
| | | | For installation, reverse the removal procedure. |




EBS00337

REMOVING THE CRANKSHAFT

1. Remove:
 - crankshaft ①Use a crankcase separating tool ②.



Crankcase separating tool
P/N. YU-01135-A, 90890-01135



EBS00360

CHECKING THE CRANKSHAFT

1. Measure:
 - side clearance (d)
Out of specification → Replace the crankshaft.




Big end side clearance
0.15 ~ 0.45 mm
(0.0059 ~ 0.0177 in)
<Limit>: 0.50 mm (0.0197 in)


2. Measure:
- runout ©
Out of specification → Replace the crankshaft.



Runout limit
C1: 0.05 mm (0.002 in)
C2: 0.05 mm (0.002 in)



- a. The crankshaft ① and the crankshaft pin ② oil passages must be properly interconnected with a tolerance of less than 1 mm (0.04 in).

**INSTALLING THE CRANKSHAFT**

1. Install:

- crankshaft ①



Crankshaft installer pot ②

P/N. 90890-01274

Crankshaft installer bolt ③

P/N. 90890-01275

Crankshaft installer set

P/N. YU-90050

Adapter ④

P/N. YM-90063, 90890-01278

Spacer (crankshaft installer) ⑤

P/N. YM-91044, 90890-04081

NOTE:

Hold the connecting rod at the Top Dead Center (TDC) with one hand while turning the nut of the installing tool with the other. Operate the installing tool until the crankshaft bottoms against the bearing.


CAUTION:

Apply engine oil to each bearing to protect the crankshaft against scratches and to make installation easier.



EBS00345

TRANSMISSION




| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------------|------|---|
| | Removing the transmission | | |
| | Crankcase | | Remove the parts in the order listed. Separate. Refer to "CRANKCASE". |
| 1 | Shift fork "C" | 1 | Refer to "INSTALLING THE TRANSMISSION". |
| 2 | Shift fork "R" | 1 | |
| 3 | Shift fork "L" | 1 | |
| 4 | Shift drum | 1 | |
| 5 | Main axle assembly | 1 | |
| 6 | Spacer | 1 | |
| 7 | Drive axle assembly | 1 | For installation, reverse the removal procedure. |



EBS00347

MAIN AXLE




| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------------|------|--|
| | Disassembling the main axle | | |
| ① | 2nd pinion gear | 1 | Remove the parts in the order listed. Refer to "ASSEMBLING THE MAIN AXLE AND DRIVE AXLE". |
| ② | 4th pinion gear | 1 | |
| ③ | 3rd pinion gear | 1 | |
| ④ | Circlip | 1 | Refer to "ASSEMBLING THE MAIN AXLE AND DRIVE AXLE". |
| ⑤ | Toothed washer | 1 | |
| ⑥ | 5th pinion gear | 1 | |
| ⑦ | Main axle/1st pinion gear | 1 | For assembly, reverse the disassembly procedure. |




EBS00348

DRIVE AXLE



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------------|------|--|
| | Disassembling the drive axle | | |
| | Crankcase | | Remove the parts in the order listed. Refer to "CRANKCASE". |
| ① | 1st wheel gear | 1 | Refer to "ASSEMBLING THE MAIN AXLE AND DRIVE AXLE". |
| ② | 5th wheel gear | 1 | |
| ③ | Circlip | 2 | |
| ④ | Toothed washer | 2 | |
| ⑤ | 3rd wheel gear | 1 | |
| ⑥ | Toothed spacer | 1 | |
| ⑦ | Toothed lock washer | 1 | |
| ⑧ | Toothed washer retainer | 1 | |
| ⑨ | 4th wheel gear | 1 | |
| ⑩ | 2nd wheel gear | 1 | |
| ⑪ | Drive axle | 1 | For assembly, reverse the disassembly procedure. |



EBS00350

CHECKING THE SHIFT FORKS

The following procedure applies to all of the shift forks.

1. Check:



- shift fork cam follower ①
- shift fork pawl ②

Bends/damage/scoring/wear → Replace the shift fork.

2. Check:

- shift fork movement

Rough movement → Replace the shift forks.



I1530104


EBS00351

CHECKING THE SHIFT DRUM

1. Check:

- shift drum grooves

Scratches/wear/damage → Replace.



I1650702

EBS00354

CHECKING THE TRANSMISSION

1. Measure:


- main axle runout

(with a centering device and dial gauge ①)

Out of specification → Replace the main axle.



Main axle runout limit
0.08 mm (0.0031 in)



I1650401

2. Check:

- transmission gears




Blue discoloration/pitting/wear → Replace the defective gear(s).

- transmission gear dogs

Cracks/damage/rounded edges → Replace the defective gear(s).



3. Check:
 - transmission gear engagement
(each pinion gear to its respective wheel gear)
Incorrect → Reassemble the transmission axle assemblies.
4. Check:
 - transmission gear movement
Rough movement → Replace the defective part(s).
5. Check:
 - circlips
Bends/damage/looseness → Replace.



EBS00355

ASSEMBLING THE MAIN AXLE AND DRIVE AXLE

1. Install:
 - toothed washer ①
 - circlip ② **New**

NOTE:



- Be sure the circlip shape-edged corner (a) is positioned opposite side to the toothed washer and gear.
- Be sure the circlip end (b) is positioned at axle spline groove (c).

2. Install:
 - 2nd pinion gear ①

NOTE:

Press the 2nd pinion gear into the main axle ②, as shown in the illustration.

① 112.85 ~ 113.05 mm (4.443 ~ 4.451 in)



EBS00356

INSTALLING THE TRANSMISSION**1. Install:**

- shift fork "L" ① (to drive axle)
- shift fork "C" ② (to main axle)
- shift fork "R" ③ (to drive axle)
- shift drum ④
- transmission assembly

NOTE:

The embossed marks on the shift forks should face towards the right side of the engine and be in the following sequence: "R", "C", "L". Be sure that the shift fork cam follower is properly seated in the shift drum groove.

2. Check:

- shift operation
Unsmooth operation → Repair.

NOTE:


- Oil each gear and bearing thoroughly.
- Before assembling the crankcase, be sure that the transmission is in neutral and that the gears turn freely.



EBS00125


COOLING SYSTEM

RADIATOR



5

| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|--|
| | Removing the radiator | | |
| | Seat/fuel tank cover/side covers (left and right)/front fender | | Remove the parts in the order listed. Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3. |
| | Coolant | | Drain. |
| 1 | Plastic band | 1 | |
| 2 | Radiator fan coupler | 1 | Disconnect. |
| 3 | Thermo switch 1 coupler | 1 | Disconnect. |
| 4 | Thermo switch 1 | 1 | |
| 5 | Thermo switch 2 coupler | 1 | Disconnect. |
| 6 | Thermo switch 2 | 1 | |
| 7 | Radiator fan breather hose | 1 | |
| 8 | Coolant reservoir hose | 1 | |
| 9 | Radiator outlet hose | 1 | |
| 10 | Radiator inlet hose | 1 | |



| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------------|------|--|
| 11 | Radiator | 1 | For installation, reverse the removal procedure. |
| 12 | Radiator grill | 1 | |
| 13 | Radiator fan | 1 | |
| 14 | Coolant reservoir breather hose | 1 | |
| 15 | Coolant reservoir cap | 1 | |
| 16 | Coolant reservoir | 1 | |



EBS00128

INSTALLING THE RADIATOR

1. Fill:

- cooling system
(with the specified amount of the recommended coolant)
Refer to “CHANGING THE COOLANT” in chapter 3.


2. Check:

- cooling system
Leaks → Repair or replace any faulty part.




EBS00134


WATER PUMP



| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|--|
| | Removing the water pump | | Remove the parts in the order listed. |
| | Engine oil | | Drain. |
| | Coolant | | Drain. |
| | Exhaust pipe | | Refer to "ENGINE REMOVAL" in chapter 4. |
| | Rear brake light switch/footrest (right) | | Refer to "FRONT AND REAR BRAKES" in chapter 7. |
| | Clutch cover | | Refer to "CLUTCH" in chapter 4. |
| 1 | Radiator outlet hose | 1 | |
| 2 | Water pump inlet pipe | 1 | |
| 3 | Water pump housing | 1 | |
| 4 | Oil filter element cover | 1 | |
| 5 | Oil filter element | 1 | |
| 6 | Parking brake holder | 1 | |
| 7 | Oil delivery pipe 1 | 1 | |



| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------|------|--|
| 8 | Oil hose 1 | 1 | For installation, reverse the removal procedure. |
| 9 | Right crankcase cover | 1 | |
| 10 | Gasket | 1 | |
| 11 | Impeller | 1 | |
| 12 | Washer | 1 | |
| 13 | Impeller shaft | 1 | |
| 14 | Oil seal | 1 | |
| 15 | Bearing | 1 | |
| 16 | Oil seal | 1 | |



EBS00139

CHECKING THE WATER PUMP

1. Check:

- water pump housing ①
- impeller ②
- impeller shaft ③

Cracks/damage/wear → Replace.

2. Check:

- oil seal **New**
- water pump inlet pipe

Cracks/damage/wear → Replace.

- bearing


Rough movement → Replace.



EBS00141

CARBURETOR


CARBURETOR




| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|---|
| | Removing a carburetor | | Remove the parts in the order listed. |
| | Seat/fuel tank cover/side covers (left and right) | | Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3. |
| 1 | Throttle position sensor coupler | 1 | Disconnect. |
| 2 | Carburetor switch coupler | 1 | Disconnect. |
| 3 | Fuel hose (carburetor side) | 1 | |
| 4 | Throttle cable cover | 1 | |
| 5 | Throttle cable | 1 | |
| 6 | Clamp | 1 | Loosen. |
| 7 | Clamp | 2 | Loosen. |
| 8 | Carburetor | 1 | Refer to "INSTALLING THE CARBURETOR JOINT" and "INSTALLING THE CARBURETOR". |
| 9 | Carburetor joint | 1 | |
| | | | For installation, reverse the removal procedure. |




EBS00144




| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|---------------------------------------|
| | Disassembling the carburetor | | Remove the parts in the order listed. |
| ① | Drain hose | 1 | |
| ② | Air vent hose | 2 | |
| ③ | Throttle position sensor | 1 | |
| ④ | Cover | 1 | |
| ⑤ | Carburetor switch/throttle stop screw assembly | 1 | |
| ⑥ | Starter plunger | 1 | |
| ⑦ | Carburetor top cover | 1 | |
| ⑧ | Screw (throttle shaft) | 1 | |
| ⑨ | Throttle valve | 1 | |
| ⑩ | Throttle valve plate | 1 | |




| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------|------|---------|
| ⑪ | Needle holder | 1 | |
| ⑫ | Jet needle | 1 | |
| ⑬ | Cover/spring | 1/1 | |
| ⑭ | Pilot air diaphragm | 1 | |
| ⑮ | Cover/spring | 1/1 | |
| ⑯ | Accelerator pump diaphragm | 1 | |
| ⑰ | Float chamber | 1 | |
| ⑱ | Accelerator jet | 1 | |
| ⑲ | Float pin | 1 | |
| ⑳ | Float | 1 | |




| Order | Job/Part | Q'ty | Remarks |
|-------|---------------|------|--|
| ②① | Needle valve | 1 | |
| ②② | Main jet | 1 | |
| ②③ | Needle jet | 1 | |
| ②④ | Spacer | 1 | |
| ②⑤ | Pilot jet | 1 | |
| ②⑥ | Starter jet | 1 | |
| ②⑦ | Pilot air jet | 1 | |
| | | | For assembly, reverse the disassembly procedure. |



4. Check:
- throttle valve ①
 - throttle valve plate ②
- Scratches/wear/damage → Replace.




5. Check:
- accelerator pump diaphragm ①
 - pilot jet diaphragm ②
 - spring ③




6. Check:
- jet needle ①
- Bends/wear/damage → Replace.
- clip groove
- Free play/wear → Replace.
- clip position




**Standard clip position
No.4 groove**



7. Check:
- main jet ①
 - pilot jet ②
 - needle jet ③
 - starter jet ④
 - pilot air jet ⑤
 - accelerator jet ⑥
- Bends/wear/damage → Replace.
- Blockage → Blow out the jets with compressed air.



8. Check:
- throttle valve movement ①
- Sticks → Replace the throttle valve guide and the throttle valve.
- Insert the throttle valve into the carburetor body, and check for free movement.



EBS00150

ASSEMBLING THE CARBURETOR

CAUTION:



Before reassembling, wash all of the parts in a clean petroleum based solvent.

1. Install:

- pilot screw ①

NOTE:

Before assembling the carburetor, make sure to turn out the pilot screw the same number of times, as noted before disassembly, from the seated position to the set position.



2. Measure:

- float height ②

Out of specification → Adjust.





Float height (F.H)
8.0 mm (0.31 in)

- Hold the carburetor in an upside down position.
- Measure the distance from the front mating surface of the float chamber (gasket removed) to the top of the float.

NOTE:

The float arm should be resting on the needle valve, but not compressing it.

- If the float height is not within the specification, check the valve seat and needle valve.
- If either is worn, replace the carburetor assembly.
- If both are fine, adjust the float height by bending the float tang ① on the float.
- Recheck the float height.



ADJUSTING THE ACCELERATOR PUMP TIMING

1. Adjust:
 - accelerator pump timing

NOTE:

Insert a rod ① with an outer diameter equal to the specified throttle valve height ③ under the throttle valve plate ② to achieve the specified value.



Throttle valve height
3.40 mm (0.134 in)



- a. Fully turn in the accelerator pump adjusting screw ③.
- b. Check that the link lever ④ has free play ⑥ by pushing lightly on it.
- c. Gradually turn out the adjusting screw while moving the link lever until the lever has no free play.

INSTALLING THE CARBURETOR JOINT

1. Install:
 - clamp

NOTE:


Align the projection ③ on the carburetor joint with the slot ④ in the clamp.



2. Install:
 - carburetor joint

NOTE:

Align the projection ③ on the cylinder head with the slot ④ in the carburetor joint.



INSTALLING THE CARBURETOR

1. Install:
 - carburetor

NOTE:

Align the projection ① on the carburetor with the slot ② in the carburetor joint, and then align the projection ③ on the carburetor with the slot ④ in the air intake duct.


2. Install:
 - throttle cable
 - throttle cable cover
3. Adjust:
 - throttle lever free play
Refer to “ADJUSTING THE THROTTLE LEVER FREE PLAY” in chapter 3.
4. Adjust:
 - engine idling speed
Refer to “ADJUSTING THE ENGINE IDLING SPEED” in chapter 3.

EAS00502

CHECKING AND ADJUSTING THE THROTTLE POSITION SENSOR

NOTE:

Before adjusting the throttle position sensor, the engine idling speed should be properly adjusted.



1. Check:
 - throttle position sensor



- a. Turn the main switch to “ON”.
- b. Connect the pocket tester (20 V DC) to the throttle position sensor.


Tester positive lead → blue ①
Tester negative lead → black ②

- c. Check the throttle position sensor input voltage.
Out of specification → Check the wire harness between battery and C.D.I. unit and throttle position sensor.



Throttle position sensor input voltage
5 V (blue and black)





2. Adjust:

- throttle position sensor angle



- Loosen the throttle position sensor screw (1).
- Turn the throttle position sensor in direction (a) or (b) until the specified throttle position sensor output voltage is indicated on the pocket tester.
- Connect the pocket tester (20 V DC) to the throttle position sensor.

Tester positive lead → yellow (3)

Tester negative lead → black (2)

- Check the throttle position sensor output voltage.

Out of specification → Adjust or replace.



Throttle position sensor output voltage

0.58 ~ 0.78 V (yellow and black)

NOTE:

When checking the throttle position sensor, it must be connected to the throttle position sensor coupler on the wire harness.



3. Tighten:

- throttle position sensor screw




EBS00378


CHASSIS

FRONT AND REAR WHEELS

FRONT WHEELS




| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------------|------|---|
| | Removing the front wheels | | <p>Remove the parts in the order listed. The following procedure applies to both of the front wheels. Place the machine on a level surface.</p> <p>⚠ WARNING _____</p> <p>Securely support the machine so there is no danger of it falling over.</p> <p>_____</p> |
| 1 | Cotter pin | 1 | Refer to "INSTALLING THE WHEEL HUBS". |
| 2 | Axle nut | 1 | |
| 3 | Front wheel | 1 | Refer to "INSTALLING THE FRONT WHEELS". |
| 4 | Brake disc guard (outer) | 1 | |




| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------|------|---|
| 5 | Brake caliper assembly | 1 | NOTE: _____ Do not squeeze the brake lever when the brake caliper is off of the brake discs as the brake pads will be forced shut. _____ For installation, reverse the removal procedure. |
| 6 | Wheel hub | 1 | |
| 7 | Brake disc | 1 | |



REAR WHEELS



| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------------|------|---|
| | Removing the rear wheels | | Remove the parts in the order listed. Place the machine on a level surface. |
| | | | ⚠ WARNING _____ Securely support the machine so there is no danger of it falling over. |
| 1 | Rear wheel | 2 | Refer to "INSTALLING THE WHEEL HUBS". |
| 2 | Cotter pin | 2 | |
| 3 | Axle nut | 2 | |
| 4 | Wheel hub | 2 | |
| | | | For installation, reverse the removal procedure. |



EBS00383

CHECKING THE WHEELS

1. Check:

- wheels

2. Measure:

- wheel runout

Over the specified limit → Replace the wheel or check the wheel bearing play ①.



Wheel runout limit

Radial ②: 2.0 mm (0.08 in)

Lateral ③: 2.0 mm (0.08 in)



3. Check:

- wheel balance

Out of balance → Adjust.

⚠ WARNING

After replacing the tire, ride conservatively to allow the tire to be properly seated in the rim. Failure to do so may cause an accident resulting in machine damage and possible operator injury.



EBS00385

CHECKING THE WHEEL HUBS

1. Check:

- wheel hubs ①


Cracks/damage → Replace.


- splines (wheel hub) ②

Wear/damage → Replace the wheel hub.

A Front

B Rear





2. Check:

- wheel bearings

Wheel hub play/wheel turns roughly → Replace.



a. Clean wheel hub exterior.

- Drive bearing out by pushing spacer aside and tapping around perimeter of bearing inner race. Use soft metal drift punch and hammer. The spacer ① “floats” between bearings. Remove both bearings as described.


⚠ WARNING

Eye protection is recommended when using striking tools.

- To install the wheel bearings, reverse the above sequence. Use a socket that matches outside diameter of bearing outer race to drive in bearing.

CAUTION:

Do not strike the center race or balls of the bearing. Contact should be made only with the outer race.



EBS00389

CHECKING THE BRAKE DISCS

1. Check:

- brake discs

Galling/damage → Replace.

2. Measure:

- brake disc deflection

Out of specification → Check the wheel runout.




Brake disc maximum deflection
Front: 0.10 mm (0.004 in)
Rear: 0.10 mm (0.004 in)

- brake disc thickness ②

Out of specification → Replace.



Brake disc minimum thickness
3 mm (0.12 in)




INSTALLING THE FRONT WHEEL HUB BEARINGS

1. Install:
 - bearings ①

NOTE:

Face the oil seal side of the bearing inward.




INSTALLING THE FRONT BRAKE DISCS

1. Install:
 - brake discs

NOTE:

Install the brake disc with its spot-faced side facing the bolt heads.




EBS00392

INSTALLING THE FRONT WHEELS

1. Install:
 - brake disc guards (outer) ①

NOTE:


Install the brake disc guard (outer) with punched burrs ② on the wheel hub side.



2. Install:
 - wheels

NOTE:

The arrow mark ① on the must point in the direction of rotation A of the wheel.



EBS00390

INSTALLING THE WHEEL HUBS

1. Install:

- front axle nuts ①

70 Nm (7.0 m · kg, 50 ft · lb)

- rear axle nuts ①

120 Nm (12.0 m · kg, 85 ft · lb)

- cotter pins ②

New


NOTE:

Do not loosen the axle nut after torquing it. If the axle nut groove is not aligned with the cotter pin hole, align the groove with the hole by tightening the axle nut.




EBS00382



REAR AXLE AND REAR AXLE HUB



| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|---|
| | Removing the rear axle and rear axle hub | | Remove the parts in the order listed. |
| | Rear wheels/rear wheel hubs | | Refer to "FRONT AND REAR WHEELS". |
| 1 | Bolt | 2 | Refer to "REMOVING THE REAR AXLE" and "INSTALLING THE REAR AXLE". |
| 2 | Nut | 1 | |
| 3 | Conical spring washer | 1 | |
| 4 | Locknut | 2 | |
| 5 | Adjusting bolt | 2 | |
| 6 | Brake caliper | 1 | |
| | | | NOTE: Do not apply the brake pedal and do not use the parking brake when the brake caliper is off of the brake disc as the brake pad will be force shut. |



| Order | Job/Part | Q'ty | Remarks |
|-------|----------------------------------|-------|---|
| 7 | Brake disc/brake disc bracket | 1/1 | Refer to "REMOVING THE REAR AXLE". |
| 8 | Rear axle | 1 | |
| 9 | Circlip | 1 | |
| 10 | Driven sprocket/sprocket bracket | 1/1 | Refer to "INSTALLING THE DRIVEN SPROCKET". |
| 11 | Brake caliper bracket | 1 | Refer to "INSTALLING THE FRONT WHEEL HUB BEARINGS". For installation, reverse the removal procedure. |
| 12 | Rear axle hub | 1 | |
| 13 | Spacer/bearing/oil seal | 1/2/2 | |



EBS00393

REMOVING THE REAR AXLE

1. Place the machine on a level surface.
2. Remove:
 - bolts
3. Loosen:
 - nut ①


NOTE:

- Apply the brake pedal so that the rear axle does not turn, when loosening the nut.
- Use the PTT wrench 46 or axle nut wrench (46 mm) ②.




PTT wrench 46
P/N. 90890-06588
Axle nut wrench (46 mm)
P/N. YM-37134


4. Elevate the rear wheels by placing the suitable stand under the frame.
5. Remove:
 - rear wheels
 - wheel hubs
 - nuts
 - washers



6. Loosen:
 - rear axle hub nuts ①



7. Loosen:
 - locknuts ①
 - adjusting bolts ②




8. Remove:

- rear axle ①
(with driven sprocket)


CAUTION:

- Never directly tap the axle end with a hammer, since this will result in damage to the axle thread and spline.
- Attach a suitable socket ② on the axle end and tap it with a soft hammer, then pull out the rear axle to the right.



9. Remove:

- circlip
- driven sprocket bracket



EBS00395

CHECKING THE REAR AXLE

1. Check:

- rear axle runout ③
Out of specification → Replace.

⚠ WARNING

Do not attempt to straighten a bent axle.



Rear axle runout limit
1.5 mm (0.06 in)

CHECKING THE DRIVEN SPROCKET


1. Check:

- driven sprocket
Refer to "SWINGARM AND DRIVE CHAIN".

CHECKING THE BRAKE DISC

1. Check:

- brake disc
Refer to "FRONT AND REAR WHEELS".




INSTALLING THE DRIVEN SPROCKET

1. Install:
 - driven sprocket

NOTE:

Make sure that the blunt-edged corner ① of the driven sprocket is facing outward.




EBS00397

INSTALLING THE REAR AXLE

1. Install:
 - conical spring washer ①

NOTE:

Install the conical spring washer with the convex side of the washer facing outward as shown.



2. Tighten:

- nut ①

- a. Tighten the nut with PTT wrench 46 or rear axle nut wrench ② to specification while holding the rear axle.



PTT wrench 46
P/N. 90890-06588
Axle nut wrench (46 mm)
P/N. YM-37134




Nut
100 Nm (10.0 m · kg, 72 ft · lb)
LOCTITE®

- b. Tighten bolts ③.



Bolt
7 Nm (0.7 m · kg, 5.1 ft · lb)
LOCTITE®






EBS00400

FRONT AND REAR BRAKES

FRONT BRAKE PADS




| Order | Job/Part | Q'ty | Remarks |
|-------|--------------------------------------|------|--|
| | Removing the front brake pads | | Remove the parts in the order listed. The following procedure applies to both of the front brake calipers. Refer to "FRONT AND REAR WHEELS". |
| 1 | Front wheel | 2 | Refer to "REPLACING THE FRONT BRAKE PADS". |
| 2 | Brake pad retaining bolt | 2 | |
| 3 | Brake pad | 1 | |
| | Brake pad spring | | For installation, reverse the removal procedure. |



EBS00401

REAR BRAKE PADS



| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------------------|------|---|
| | Removing the rear brake pads | | |
| 1 | Brake caliper mounting bolt | 2 | Remove the parts in the order listed. Refer to "REPLACING THE REAR BRAKE PADS". |
| 2 | Brake pad retaining bolt | 2 | |
| 3 | Lock washer | 1 | |
| 4 | Brake pad/pad shim | 2/1 | |
| 5 | Brake pad spring | 1 | |
| | | | For installation, reverse the removal procedure. |



EBS00402

CAUTION:

Disc brake components rarely require disassembly.

DO NOT:

- disassemble components unless absolutely necessary;
- use solvents on internal brake components;
- use spent brake fluid for cleaning; (use only clean brake fluid)
- allow brake fluid to come in contact with the eyes, as this may cause eye injury;
- splash brake fluid onto painted surfaces or plastic parts, as this may cause damage;
- disconnect any hydraulic connection, as this would require the entire brake system to be disassembled, drained, cleaned, properly filled and bled after reassembly.


EBS00404

REPLACING THE FRONT BRAKE PADS

The following procedure applies to both of the front brake calipers.

NOTE:

It is not necessary to disassemble the brake calipers and brake hoses to replace the brake pads.



1. Remove:

- brake pads

Ⓐ Wear limit

NOTE:

Replace the brake pads as a set if either is found to be worn to the wear limit.




EBS00405

REPLACING THE REAR BRAKE PADS

NOTE:

It is not necessary to disassemble the brake caliper and brake hose to replace the brake pads.



1. Remove:

- brake pads

Ⓐ wear limit

NOTE:


Replace the brake pads as a set if either is found to be worn to the wear limit.

2. Install:

- brake pads
- brake pad spring

NOTE:

Always install new brake pads, brake pad shim and brake pad spring as a set.



- Connect a suitable hose ① tightly to the brake caliper bleed screw ②. Put the other end of this hose into an open container.
- Loosen the brake caliper bleed screw and, using a finger, push the caliper piston into the brake caliper.
- Tighten the brake caliper bleed screw.



Brake caliper bleed screw
6 Nm (0.6 m · kg, 4.3 ft · lb)

- Install a new brake pad spring, new pad shim ③ and new brake pads.


NOTE:

- The pad shim must be installed toward the piston.
- The arrow mark Ⓐ on the pad shim must point in the direction of the disc rotation.

- Install the retaining bolts and brake caliper.



Brake pad retaining bolt
18 Nm (1.8 m · kg, 13 ft · lb)
Brake caliper mounting bolt
31 Nm (3.1 m · kg, 22 ft · lb)





- f. Bend the lock washer tabs along a flat side of the bolts.



3. Check:

- brake fluid level

Refer to “CHECKING THE BRAKE FLUID LEVEL” in chapter 3.

4. Check:

- brake lever or brake pedal operation


Soft or spongy feeling → Bleed the brake system.

Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.



EBS00407


FRONT BRAKE MASTER CYLINDER



| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|--|
| | Removing the front brake master cylinder | | Remove the parts in the order listed. |
| | Brake fluid | | Drain. |
| 1 | Brake fluid reservoir cap | 1 | |
| 2 | Brake fluid reservoir diaphragm | 1 | |
| 3 | Front brake light switch | 1 | |
| 4 | Brake lever | 1 | |
| 5 | Union bolt | 1 | |
| 6 | Copper washer | 2 | Refer to "INSTALLING THE FRONT BRAKE MASTER CYLINDER". |
| 7 | Brake hose | 1 | |
| 8 | Brake master cylinder bracket | 1 | |
| 9 | Brake master cylinder | 1 | For installation, reverse the removal procedure. |



EBS00409




| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|--|
| | Disassembling the front brake master cylinder | | Remove the parts in the order listed. |
| ① | Dust boot | 1 | Refer to "ASSEMBLING THE FRONT BRAKE MASTER CYLINDER". |
| ② | Circlip | 1 | |
| ③ | Brake master cylinder kit | 1 | |
| | | | For assembly, reverse the disassembly procedure. |




EBS00410

REAR BRAKE MASTER CYLINDER




| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|--|
| | Removing the rear brake master cylinder | | Remove the parts in the order listed. |
| | Right foot protector | | Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3. |
| | Brake fluid | | Drain. |
| 1 | Brake fluid reservoir cover | 1 | |
| 2 | Brake fluid reservoir cap | 1 | |
| 3 | Brake fluid reservoir diaphragm holder | 1 | |
| 4 | Brake fluid reservoir diaphragm | 1 | |
| 5 | Brake fluid reservoir | 1 | |
| 6 | Brake fluid reservoir hose | 1 | |








| Order | Job/Part | Q'ty | Remarks |
|-------|-------------------------|------|---|
| 7 | Union bolt | 1 | Disconnect. Refer to "INSTALLING THE REAR BRAKE MASTER CYLINDER". |
| 8 | Copper washer | 2 | |
| 9 | Brake hose | 1 | |
| 10 | Brake master cylinder | 1 | |
| 11 | Rear brake light switch | 1 | |
| 12 | Right footrest | 1 | For installation, reverse the removal procedure. |
| 13 | Brake pedal/spring | 1/1 | |



EBS00411



| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|---|
| | Disassembling the rear brake master cylinder | | Remove the parts in the order listed. |
| ① | Hose joint | 1 | Refer to "ASSEMBLING THE REAR BRAKE MASTER CYLINDER". For assembly, reverse the disassembly procedure. |
| ② | Brake master cylinder kit | 1 | |
| ③ | Brake master cylinder | 1 | |



EBS00413

CHECKING THE MASTER CYLINDERS

1. Check:

- brake master cylinder ①
Wear/scratches → Replace the brake master cylinder assembly.
- brake master cylinder body
Cracks/damage → Replace.
- brake fluid delivery passage (brake master cylinder body)
Blockage → Blow out with compressed air.

A Front

B Rear

2. Check:

- brake master cylinder kit
Scratches/wear/damage → Replace as a set.

A Front

B Rear

3. Check:

- front brake master cylinder reservoir ①
- front brake master cylinder reservoir diaphragm ②
Cracks/damage → Replace.

4. Check:

- rear brake fluid reservoir ①
- rear brake fluid reservoir diaphragm ②
Cracks/damage → Replace.



EBS00415

ASSEMBLING THE FRONT BRAKE MASTER CYLINDER

WARNING

- All internal brake components should be cleaned and lubricated with new brake fluid only before installation.



Recommended brake fluid
DOT 4

- Whenever a master cylinder is disassembled, replace the piston seals and dust seals.

EBS00416

ASSEMBLING THE REAR BRAKE MASTER CYLINDER


WARNING

- All internal brake components should be cleaned and lubricated with new brake fluid only before installation.



Recommended brake fluid
DOT 4

- Whenever a master cylinder is disassembled, replace the piston seals and dust seals.



1. Install:
 - brake master cylinder kit
 - nut ①
 - joint ②

NOTE:

Turn the adjusting bolt ③ until the clearance ④ is within the specified limits when install the joint ②.




Clearance
2.2 ~ 3.2 mm (0.09 ~ 0.13 in)

2. Tighten:

- nut ①

18 Nm (1.8 m · kg, 13 ft · lb)



EBS00418

INSTALLING THE FRONT BRAKE MASTER CYLINDER


1. Install:

- brake master cylinder ①

7 Nm (0.7 m · kg, 5.1 ft · lb)

NOTE:

- The “UP” mark on the brake master cylinder bracket should face up.
- Install the brake master cylinder so that the gaps between the brake master cylinder and the brake master cylinder bracket are equal.



2. Install:

- copper washers **New**
- brake hose
- union bolt

27 Nm (2.7 m · kg, 19 ft · lb)

NOTE:

- Tighten the union bolt while holding the brake hose as shown.
- Turn the handlebar to the left and to the right to check that the brake hose does not touch other parts (throttle cable, wire harness, leads, etc.). Correct if necessary.

WARNING

Proper brake hose routing is essential to insure safe machine operation. Refer to “CABLE ROUTING” in chapter 2.

3. Fill:

- brake fluid reservoir



Recommended brake fluid
DOT 4

CAUTION:

Brake fluid may damage painted surfaces or plastic parts. Always clean up spilled brake fluid immediately.



⚠ WARNING

- Use only the designated quality brake fluid: other brake fluids may deteriorate the rubber seals, causing leakage and poor brake performance.
- Refill with the same type of brake fluid: mixing brake fluids may result in a harmful reaction and lead to poor brake performance.
- Be careful that water does not enter the brake master cylinder when refilling. Water will significantly lower the boiling point of the brake fluid and may result in vapor lock.

4. Air bleed:

- brake system


Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.

5. Check:

- brake fluid level

Brake fluid level is under the “LOWER” level line → Add the recommended brake fluid to the proper level.

Refer to “CHECKING THE BRAKE FLUID LEVEL” in chapter 3.



EBS00419

INSTALLING THE REAR BRAKE MASTER CYLINDER

1. Install:

- copper washers **New**

- brake hose ①


- union bolt ② 30 Nm (3.0 m · kg, 2.2 ft · lb)

CAUTION:

When installing the brake hose onto the brake master cylinder, make sure the brake pipe ① touches the projection ② as shown.

⚠ WARNING

Proper brake hose routing is essential to insure safe machine operation. Refer to “CABLE ROUTING” in chapter 2.



2. Install:
 - brake fluid reservoir hose ①

NOTE: _____
Install the brake fluid reservoir hose with the white paint mark ② facing up as shown.

3. Fill:
 - brake fluid reservoir



**Recommended brake fluid
DOT 4**

CAUTION: _____

Brake fluid may damage painted surfaces or plastic parts. Always clean up spilled brake fluid immediately.

⚠ WARNING _____


- Use only the designated quality brake fluid: other brake fluids may deteriorate the rubber seals, causing leakage and poor brake performance.
- Refill with the same type of brake fluid: mixing brake fluids may result in a harmful chemical reaction and lead to poor brake performance.
- Be careful that water does not enter the brake master cylinder when refilling. Water will significantly lower the boiling point of the brake fluid and may result in vapor lock.

4. Air bleed:
 - brake system
Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.
5. Check:
 - brake fluid level
Brake fluid level is under the “LOWER” level line → Add the recommended brake fluid to the proper level.
Refer to “CHECKING THE BRAKE FLUID LEVEL” in chapter 3.



EBS00421


FRONT BRAKE CALIPERS



| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|--|
| | Removing the front brake calipers | | Remove the parts in the order listed. The following procedure applies to both of the front brake calipers. Drain. Refer to "FRONT AND REAR WHEELS". |
| 1 | Brake caliper | 1 | Disconnect. } Refer to "INSTALLING THE FRONT BRAKE CALIPERS". Loosen. |
| 2 | Front wheel | 2 | |
| 3 | Union bolt | 1 | |
| 4 | Copper washer | 2 | |
| 5 | Brake hose | 1 | |
| 6 | Brake pad retaining bolt | 2 | |
| | Brake caliper mounting bolt | 2 | |
| | Brake caliper assembly | 1 | For installation, reverse the removal procedure. |



EBS00423




| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|---|
| | Disassembling the front brake calipers | | Remove the parts in the order listed. |
| | | | The following procedure applies to both of the front brake calipers. |
| ① | Brake pad retaining bolt | 2 | Refer to "DISASSEMBLING THE FRONT AND REAR BRAKE CALIPERS" and "ASSEMBLING THE FRONT BRAKE CALIPERS". |
| ② | Brake pad | 2 | |
| ③ | Brake pad spring | 1 | |
| ④ | Caliper bracket | 1 | |
| ⑤ | Caliper piston | 2 | |
| ⑥ | Dust seal | 2 | |
| ⑦ | Caliper piston seal | 2 | |
| ⑧ | Bleed screw | 1 | For assembly, reverse the disassembly procedure. |



EBS00424


REAR BRAKE CALIPER




| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|--|
| | Removing the rear brake caliper | | |
| 1 | Brake fluid Parking brake cable | 1 | Remove the parts in the order listed. Drain. Disconnect. Refer to "REMOVING THE PARKING BRAKE CABLE". |
| 2 | Union bolt | 2 | Disconnect. } Refer to "INSTALLING THE REAR BRAKE CALIPER". |
| 3 | Copper washer | 2 | |
| 4 | Brake hose | 1 | |
| 5 | Brake caliper mounting bolt | 2 | |
| 6 | Brake caliper assembly | 1 | For installation, reverse the removal procedure. |



EBS00425



| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|---------------------------------------|
| | Disassembling the rear brake caliper | | Remove the parts in the order listed. |
| ① | Adjusting bolt | 1 | |
| ② | Locknut | 1 | |
| ③ | Parking brake arm | 1 | |
| ④ | Parking brake case mounting bolt | 2 | |
| ⑤ | Parking brake case bracket | 1 | |
| ⑥ | Parking brake case | 1 | |
| ⑦ | Gasket | 1 | |
| ⑧ | Spring | 1 | |
| ⑨ | Nut | 1 | |
| ⑩ | Bearing | 1 | |



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------|------|---|
| ⑪ | Brake pad holding bolt | 2 | Refer to "DISASSEMBLING THE FRONT AND REAR BRAKE CALIPERS" and "ASSEMBLING THE REAR BRAKE CALIPER". |
| ⑫ | Lock washer | 1 | |
| ⑬ | Brake pad/pad shim | 2/1 | |
| ⑭ | Brake pad spring | 1 | |
| ⑮ | Retaining bolt | 1 | |
| ⑯ | Caliper bracket | 1 | |
| ⑰ | Brake caliper piston | 1 | |
| ⑱ | Dust seal | 1 | |
| ⑲ | Caliper piston seal | 1 | For assembly, reverse the disassembly procedure. |
| ⑳ | O-ring | 1 | |
| ㉑ | Bleed screw | 1 | |





EBS00429

CHECKING THE FRONT AND REAR BRAKE CALIPERS

| Recommended brake component replacement schedule | |
|--|---------------------------------------|
| Brake pads | As required |
| Piston seals, dust seals | Every two years |
| Brake hoses | Every four years |
| Brake fluid | Replace when brakes are disassembled. |

⚠ WARNING

All internal brake components should be cleaned in new brake fluid only. Do not use solvents as they will cause seals to swell and distort.



1. Check:

- brake caliper pistons ①
Scratches/rust/wear → Replace the brake caliper assembly.
- brake caliper cylinders ②
Wear/scratches → Replace the brake caliper assembly.
- brake caliper body ③
Cracks/damage → Replace.
- brake fluid delivery passage (brake caliper body)
Blockage → Blow out with compressed air.

⚠ WARNING

Replace the caliper piston seals and dust seals whenever the brake caliper is disassembled.

A Front

B Rear



EBS00431

ASSEMBLING THE FRONT BRAKE CALIPERS

The following procedure applies to both of the front brake calipers.



⚠ WARNING

- All internal brake components should be cleaned and lubricated with new brake fluid only before installation.



**Recommended brake fluid
DOT 4**

- Replace the caliper piston seal whenever a brake caliper is disassembled.



1. Install:
 - caliper piston seals ① **New**
 - dust seals ② **New**
2. Install:
 - brake caliper pistons ①

EBS00432

ASSEMBLING THE REAR BRAKE CALIPER


⚠ WARNING

- All internal brake components should be cleaned and lubricated with new brake fluid only before installation.




**Recommended brake fluid
DOT 4**


- Replace the caliper piston seal whenever a brake caliper is disassembled.



1. Install:
 - O-ring ① **New**
 - caliper piston seal ② **New**
 - dust seal ③ **New**




2. Install:
 - brake caliper piston ①




3. Install:
 - lock washer ① **New**
 - brake pad holding bolts ②

18 Nm (1.8 m · kg, 13 ft · lb)

4. Bend the lock washer tabs along a flat side of the bolts.



5. Mesh the bearing race tab ① with parking brake case slit.



6. Install:
 - parking brake arm ①

NOTE:


Align the center of the parking brake arm with a adjuster nut corner ③ and position the parking brake arm as shown.

7. Measure:
 - parking-brake-arm-to-parking-brake-bracket distance ⑥

Out of specification → Adjust.



Parking-brake-arm-to-parking-brake-bracket distance
58 mm (2.28 in)



EBS00434

INSTALLING THE FRONT BRAKE CALIPERS

The following procedure applies to both of the front brake calipers.

1. Install:

- brake caliper assembly
- brake caliper mounting bolts ①

28 Nm (2.8 m · kg, 20 ft · lb)

- brake hose ②

- copper washers ③ **New**

- union bolt ④ 27 Nm (2.7 m · kg, 19 ft · lb)

CAUTION:

When installing the brake hose on the brake caliper, make sure that the brake pipe ① touches the projection ② on the brake caliper.

WARNING

Proper brake hose routing is essential to insure safe machine operation. Refer to “CABLE ROUTING” in chapter 2.

2. Fill:

- brake reservoir



**Recommended brake fluid
DOT 4**

CAUTION:

Brake fluid may damage painted surfaces or plastic parts. Always clean up spilled brake fluid immediately.

WARNING

- Use only the designated quality brake fluid: other brake fluids may deteriorate the rubber seals, causing leakage and poor brake performance.
- Refill with the same type of brake fluid: mixing brake fluids may result in a harmful chemical reaction and lead to poor brake performance.
- Be careful that water does not enter the master cylinder when refilling. Water will significantly lower the boiling point of the brake fluid and may result in vapor lock.



3. Air bleed:

- brake system


Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.

4. Check:

- brake fluid level

Brake fluid level is below the “LOWER” level line → Add the recommended brake fluid to the proper level.

Refer to “CHECKING THE BRAKE FLUID LEVEL” in chapter 3.



EBS00436

INSTALLING THE REAR BRAKE CALIPER

1. Install:

- brake caliper assembly
- brake caliper mounting bolts ①

31 Nm (3.1 m · kg, 22 ft · lb)

- brake hose ②

- copper washers ③ **New**

- union bolt ④ 30 Nm (3.0 m · kg, 22 ft · lb)

CAUTION:

When installing the brake hose on the brake caliper, make sure that the brake pipe touches the projection ③ on the brake caliper.

WARNING

Proper brake hose routing is essential to insure safe machine operation. Refer to “CABLE ROUTING” in chapter 2.

2. Fill:

- brake reservoir



**Recommended brake fluid
DOT 4**

**CAUTION:**

Brake fluid may damage painted surfaces or plastic parts. Always clean up spilled brake fluid immediately.

**WARNING**

- Use only the designated quality brake fluid: other brake fluids may deteriorate the rubber seals, causing leakage and poor brake performance.
- Refill with the same type of brake fluid: mixing brake fluids may result in a harmful chemical reaction and lead to poor brake performance.
- Be careful that water does not enter the master cylinder when refilling. Water will significantly lower the boiling point of the brake fluid and may result in vapor lock.

3. Air bleed:

- brake system

Refer to “BLEEDING THE HYDRAULIC BRAKE SYSTEM” in chapter 3.

4. Check:

- brake fluid level

Brake fluid level is below the “LOWER” level line → Add the recommended brake fluid to the proper level.

Refer to “CHECKING THE BRAKE FLUID LEVEL” in chapter 3.

5. Adjust:

- parking brake cable end length


Refer to “ADJUSTING THE PARKING BRAKE” in chapter 3.




EBS00444

STEERING SYSTEM


HANDLEBAR



| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------------|------|---|
| | Removing the handlebar | | |
| 1 | Handlebar cover | 1 | Remove the parts in the order listed. |
| 2 | Plastic band | 4 | |
| 3 | Front brake light switch | 1 | |
| 4 | Brake master cylinder/bracket | 1/1 | Refer to "REMOVING THE FRONT BRAKE LIGHT SWITCH AND CLUTCH SWITCH". |
| 5 | Throttle lever assembly/bracket | 1/1 | |
| 6 | Spacer | 1 | |
| 7 | Clutch switch | 1 | Refer to "INSTALLING THE BRAKE MASTER CYLINDER". |
| 8 | Parking brake lever | 1 | |
| 9 | Clutch lever/bracket | 1/1 | |
| 10 | Handlebar switch | 1 | Refer to "REMOVING THE FRONT BRAKE LIGHT SWITCH AND CLUTCH SWITCH". |
| | | | Refer to "INSTALLING THE CLUTCH LEVER". |



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------|------|---|
| 11 | Handlebar grip | 2 | Refer to "REMOVING THE HANDLEBAR GRIPS" and "INSTALLING THE HANDLEBAR GRIPS". Refer to "INSTALLING THE HANDLEBAR". For installation, reverse the removal procedure. |
| 12 | Handlebar holder | 2 | |
| 13 | Handlebar | 1 | |



EBS00446


REMOVING THE FRONT BRAKE LIGHT SWITCH AND CLUTCH SWITCH

1. Remove:

- front brake light switch ①
- clutch switch

NOTE:

- Push the fastener when removing the front brake light switch out of the brake master cylinder.
- Push the fastener when removing the clutch switch out of the clutch lever holder.



EBS00447


REMOVING THE HANDLEBAR GRIPS

1. Remove:

- handlebar grips ①

NOTE:

Blow compressed air between the handlebar and handlebar grip, and gradually push the grip off the handlebar.



EBS00448


CHECKING THE HANDLEBAR

1. Check:

- handlebar ①
- Bends/cracks/damage → Replace.

⚠ WARNING

Do not attempt to straighten a bent handlebar as this may dangerously weaken the handlebar.



EBS00449

INSTALLING THE HANDLEBAR

1. Install:

- handlebar
- handlebar holders



23 Nm (2.3 m · kg, 17 ft · lb)

NOTE:

- Install the handlebar within 3.3° from the horizontal line shown in the illustration.
- The upper handlebar holder should be installed with the punched mark ① forward ②.

CAUTION:

First tighten the bolt ③ on the front side of the handlebar holder, and then tighten the bolt ④ on the rear side.



EBS00450


INSTALLING THE HANDLEBAR GRIPS

1. Install:

- handlebar grips ①

NOTE:

- Before applying the adhesive, wipe off grease or oil on the handlebar surface ② with a lacquer thinner.
- Install the handlebar grips to the handlebar so that the line ③ between the two arrow marks faces straight upward.



EBS00452

INSTALLING THE CLUTCH LEVER


1. Install:

- handlebar switch ①
- clutch lever
- clutch lever bracket ②

NOTE:

Install the clutch lever bracket as shown.

① 68 ~ 69 mm (2.68 ~ 2.72 in)



EBS00453

INSTALLING THE BRAKE MASTER CYLINDER

1. Install:

- throttle lever assembly
- spacer
- brake master cylinder

7 Nm (0.7 m · kg, 5.1 ft · lb)


NOTE:

- Engage the indentations ① in the spacer with the lobes ② on the throttle lever assembly and brake master cylinder.
- The “UP” mark on the brake master cylinder bracket should face up.




EBS00454

STEERING STEM



| Order | Job/Part | Q'ty | Remarks |
|-------|---|------|--|
| | Removing the steering stem | | Remove the parts in the order listed. |
| | Fuel tank cover/side covers (left and right)/fuel tank/front fender | | Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3. |
| 1 | Pitman arm | 1 | Refer to "INSTALLING THE PITMAN ARM". |
| 2 | Lock washer | 1 | Refer to "INSTALLING THE LOCK WASHER". |
| 3 | Steering stem bushing | 2 | |
| 4 | Spacer | 2 | |
| 5 | Oil seal | 2 | |
| 6 | Steering stem | 1 | |
| 7 | Oil seal | 1 | |
| 8 | Oil seal | 1 | |



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------|------|---|
| 9 | Bearing retainer | 1 | Refer to "REMOVING THE BEARING RETAINER" and "INSTALLING THE BEARING RETAINER". |
| 10 | Bearing | 1 | For installation, reverse the removal procedure. |




EBS00455

REMOVING THE BEARING RETAINER

1. Remove:
 - bearing retainer



Damper rod holder (30 mm)
P/N. YM-01327, 90890-01327



EBS00456


CHECKING THE STEERING STEM

1. Check:
 - steering stem
 Bends → Replace.

⚠ WARNING

Do not attempt to straighten a bent stem; this may dangerously weaken the stem.

2. Check:
 - oil seals ① **New**
 - steering stem bushings ②
 Wear/damage → Replace.



EBS00457

INSTALLING THE BEARING RETAINER

1. Install:
 - bearing retainer

65 Nm (6.5 m · kg, 47 ft · lb)




Damper rod holder (30 mm)
P/N. YM-01327, 90890-01327

INSTALLING THE STEERING STEM

1. Install:
 - steering stem


NOTE:

Pass the throttle cable through the cable guide. Refer to “CABLE ROUTING” in chapter 2.



EBS00459

INSTALLING THE LOCK WASHER

1. Install:
 - lock washer **New**
 - bolts  **23 Nm (2.3 m · kg, 17 ft · lb)**
2. Bend the lock washer tab along a flat side of the bolt.

INSTALLING THE PITMAN ARM

1. Install:
 - washer
 - nut
 - pitman arm


NOTE: _____

Make sure that the threads of the steering stem, washers, nuts, and the installation surfaces of the pitman arm are free of grease and oil.




EBS00460

TIE-RODS AND STEERING KNUCKLES



| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|--|
| | Removing the tie-rods and steering knuckles | | Remove the parts in the order listed. |
| | Front wheel/brake disc | | The following procedure applies to both of the tie-rods and steering knuckles. |
| | Front brake caliper | | Refer to "FRONT AND REAR WHEELS". |
| 1 | Brake disc guard (inner) | 1 | Refer to "FRONT AND REAR BRAKES". |
| 2 | Tie-rod | 2 | Refer to "INSTALLING THE TIE-RODS". |
| 3 | Pitman arm | 1 | |
| 4 | Front bumper | 1 | |
| 5 | Lower front arm | 1 | |
| 6 | Upper front arm | 1 | |
| 7 | Steering knuckle | 1 | Refer to "REMOVING THE STEERING KNUCKLES". |
| | | | For installation, reverse the removal procedure. |



EBS00461


REMOVING THE STEERING KNUCKLES

1. Remove:

- steering knuckles ①

NOTE:

Use a general puller to separate the ball joint ② and steering knuckle.



EBS00462


CHECKING THE TIE-RODS

1. Check:

- tie-rod free play and movement
Free play → Replace the tie-rod end.
Turns roughly → Replace the tie-rod end.

2. Check:

- tie-rods
Bends/damage → Replace.




EBS00464

CHECKING THE STEERING KNUCKLES

1. Check:

- steering knuckles
Damage/pitting → Replace.



EBS00465

INSTALLING THE TIE-RODS

1. Install:

- tie-rods (left and right)

25 Nm (2.5 m · kg, 18 ft · lb)

NOTE:

The tie-rod side which must be installed on the outside has grooves ①.


2. Adjust:

- toe-in
Refer to “ADJUSTING THE TOE-IN” in chapter 3.



EBS00468


FRONT ARMS AND FRONT SHOCK ABSORBER ASSEMBLIES



| Order | Job/Part | Q'ty | Remarks |
|-------|--|-------|--|
| | Removing the front arms and front shock absorber assemblies | | Remove the parts in the order listed. |
| | Front wheel/brake disc | | The following procedure applies to both of the front arms and front shock absorber assemblies. |
| | Front brake caliper | | Refer to "FRONT AND REAR WHEELS". |
| 1 | Front bumper | 1 | Refer to "FRONT AND REAR BRAKES". |
| 2 | Brake disc guard (inner) | 1 | |
| 3 | Nut | 1 | |
| 4 | Tie-rod | 1 | Disconnect. |
| 5 | Nut | 1 | |
| 6 | Nut | 1 | |
| 7 | Nut/washer/bolt | 1/1/1 | |

FRONT ARMS AND FRONT SHOCK ABSORBER ASSEMBLIES


CHAS



| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------------|------|---|
| 8 | Nut/bolt | 2/2 | Refer to "REMOVING THE FRONT ARMS" and "INSTALLING THE FRONT ARMS". |
| 9 | Lower front arm | 1 | |
| 10 | Nut/bolt | 1/1 | |
| 11 | Upper front arm | 1 | |
| 12 | Nut/bolt | 1/1 | |
| 13 | Front shock absorber/bushing | 1/1 | |
| 14 | Steering knuckle | 1 | |
| 15 | Dust cover | 6 | |
| 16 | Spacer | 1 | |
| 17 | Spacer | 2 | |
| 18 | Bushing | 6 | For installation, reverse the removal procedure. |
| 19 | Circlip | 1 | |
| 20 | Rubber boot/boot retaining ring | 1/1 | |
| 21 | Ball joint | 1 | |



- Do not deform or damage the front shock absorber or gas cylinder in any way. If the front shock absorber, gas cylinder or both are damaged, damping performance will suffer.



EBS00486


DISPOSING OF A FRONT SHOCK ABSORBER AND GAS CYLINDER

Gas pressure must be released before disposing of a front shock absorber and gas cylinder. To release the gas pressure, press on the gas valve needle with a suitable tool as shown, until all of the gas is released (the hissing has stopped).



WARNING

Wear eye protection to prevent eye damage from released gas or metal chips.








EBS00488

CHECKING THE FRONT SHOCK ABSORBERS

The following procedure applies to both of the front shock absorber assemblies.

1. Check:
 - shock absorber
Oil leaks → Replace the front shock absorber assembly.
 - shock absorber rod
Bends/damage → Replace the front shock absorber assembly.
 - spring
Fatigue → Replace the front shock absorber assembly.
Move the spring up and down.
 - gas cylinder
Damage/gas leaks → Replace the front shock absorber assembly.



EBS00472

CHECKING THE BALL JOINTS

The following procedure applies to both of the front arm ball joints.

1. Check:

- ball joint (upper front arm)

Damage/pitting → Replace the upper front arm.

Free play → Replace the front arm.

Turns roughly → Replace the upper front arm.

2. Check:

- ball joint (lower front arm)

Damage/pitting → Replace the ball joint.

Free play → Replace the ball joint.

Turns roughly → Replace the ball joint.



a. Clean the outside of the lower front arm.

b. Remove the circlip ①, boot retaining ring ② and rubber boot ③.

Use the ball joint remover and installer set.



Ball joint remover/installer set

P/N. YM-01474, 90890-01474

Ball joint remover/installer attachment set


P/N. YM-01480, 90890-01480

| | | |
|---|---------------------------|---------------------------------|
| ④ | Body | YM-01474 90890-01474 |
| ⑤ | Long bolt | |
| ⑥ | Base | YM-01480 90890-01480 |
| ⑦ | Remover attachment | |
| ⑧ | Installer spacer | |
| ⑨ | Installer washer | |

c. Install the body ④, long bolt ⑤, base ⑥ and attachment ⑦ onto ball joint.

d. Hold the body ④ in place while turning in the long bolt ⑤ to remove the ball joint ⑩ from the lower front arm ⑪.

e. Remove the ball joint remover/installer.



- f. Attach the assembled ball joint remover/installer, new ball joint (with rubber boot and retaining ring) ⑫, installer spacer ⑧ and installer washer ⑨ to the lower front arm ⑪.

NOTE:




- Do not tap or damage the top of the ball joint.
- Installer spacer ⑧ must be aligned with the projection on the head of the ball joint ⑫.

- g. Remove the ball joint remover/installer.

- h. Install a new circlip.

NOTE:

Always use a new ball joint set.



EBS00473

INSTALLING THE FRONT ARMS

The following procedure applies to both of the front arms.

1. Install:

- upper front arm ①

38 Nm (3.8 m · kg, 27 ft · lb)

- lower front arm ②


55 Nm (5.5 m · kg, 40 ft · lb)

NOTE:


- Be sure to position the bolts (upper and lower) so that the bolt head faces forward.
- Apply lithium-soap-based grease to the grease nipple.

EBS00484

REAR SHOCK ABSORBER AND RELAY ARM



| Order | Job/Part | Q'ty | Remarks |
|-------|---|-------|---|
| | Removing the rear shock absorber and relay arm | | Remove the parts in the order listed. |
| | Seat/left foot protector | | Refer to "SEAT, FENDERS AND FUEL TANK" in chapter 3. |
| | Muffler/exhaust pipe | | Refer to "ENGINE REMOVAL" in chapter 4. |
| | Rear axle hub | | Refer to "REAR AXLE AND REAR AXLE HUB". |
| 1 | Self-locking nut/bolt | 1/1 | Refer to "INSTALLING THE RELAY ARM AND CONNECTING ARM". |
| 2 | Self-locking nut/bolt | 1/1 | |
| 3 | Connecting arm | 1 | |
| 4 | Bearing/oil seal/spacer | 2/2/1 | |
| 5 | Cotter pin | 1 | |



| Order | Job/Part | Q'ty | Remarks |
|-------|------------------------------|-------|---|
| 6 | Bolt/washer | 1/1 | Refer to "REMOVING THE REAR SHOCK ABSORBER" and "INSTALLING THE REAR SHOCK ABSORBER". |
| 7 | Self-locking nut/bolt/washer | 1/1/2 | |
| 8 | Rear shock absorber | 1 | |
| 9 | Dust seal/bearing/spacer | 2/1/1 | |
| 10 | Self-locking nut/bolt | 1/1 | Refer to "INSTALLING THE RELAY ARM AND CONNECTING ARM". |
| 11 | Relay arm | 1 | |
| 12 | Spacer/bearing/oil seal | 1/1/2 | |
| 13 | Spacer/bearing/oil seal | 1/1/2 | |
| 14 | Spacer/bearing/oil seal | 1/2/2 | For installation, reverse the removal procedure. |
| | | | |




EBS00485

HANDLING THE REAR SHOCK ABSORBER AND GAS CYLINDER

WARNING

This rear shock absorber and gas cylinder contain highly compressed nitrogen gas. Before handling the rear shock absorber or gas cylinder, read and make sure you understand the following information. The manufacturer cannot be held responsible for property damage or personal injury that may result from improper handling of the rear shock absorber and gas cylinder.

- Do not tamper or attempt to open the rear shock absorber or gas cylinder.
- Do not subject the rear shock absorber or gas cylinder to an open flame or any other source of high heat. High heat can cause an explosion due to excessive gas pressure.
- Do not deform or damage the rear shock absorber or gas cylinder in any way. If the rear shock absorber, gas cylinder or both are damaged, damping performance will suffer.



EBS00486

DISPOSING OF A REAR SHOCK ABSORBER AND GAS CYLINDER

Gas pressure must be released before disposing of a rear shock absorber and gas cylinder. To release the gas pressure, press on the gas valve needle with a suitable tool as shown, until all of the gas is released (the hissing has stopped).

WARNING

Wear eye protection to prevent eye damage from released gas or metal chips.



EBS00487


REMOVING THE REAR SHOCK ABSORBER

1. Remove:

- relay arm-to-rear shock absorber lower bolt
- rear shock absorber upper bolt

NOTE:

While removing the relay arm-to-rear shock absorber lower bolt, hold the swingarm so that it does not drop down.




EBS00488

CHECKING THE REAR SHOCK ABSORBER

1. Check:

- shock absorber
Oil leaks → Replace the rear shock absorber assembly.
- shock absorber rod
Bends/damage → Replace the rear shock absorber assembly.
- spring
Fatigue → Replace the rear shock absorber assembly.
Move the spring up and down.
- gas cylinder
Damage/gas leaks → Replace the rear shock absorber assembly.




EBS00489

CHECKING THE RELAY ARM AND CONNECTING ARM

1. Check:

- relay arm ①
- connecting arm ②
Damage/wear → Replace.
- bushings
- spacers
- oil seals
Damage/pitting/scratches → Replace.



EBS00490

INSTALLING THE RELAY ARM AND CONNECTING ARM

1. Install:
 - bearing ①
(to connecting arm)




Installed depth of bearing ①
4 mm (0.16 in)

2. Install:
 - bearings ① to ③
(to relay arm)



Installed depth of bearing ①
6.5 mm (0.26 in)
Installed depth of bearing ②
5.0 mm (0.20 in)
Installed depth of bearing ③
6.0 mm (0.24 in)





EBS00491

INSTALLING THE REAR SHOCK ABSORBER

1. Install:
 - relay arm
 - rear shock absorber
 - bolts
 - washer ①
 - washer ②
 - cotter pin ③ **New**

NOTE:

- When installing the rear shock absorber, lift up the swingarm.
- Make sure that the blunt-edged corner ① of the washer is facing outward.
- Make sure that the sharp-edged corner ② of the washer is facing outward.
- Install the cotter pin and bend the ends as shown.




[A] Rear shock absorber upper side

[a] Rear shock absorber lower side




EBS00492


SWINGARM AND DRIVE CHAIN



| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|---|
| | Removing the swingarm and drive chain | | Remove the parts in the order listed. |
| | Rear axle hub | | Refer to "REAR AXLE AND REAR AXLE HUB". |
| | Rear shock absorber | | Refer to "REAR SHOCK ABSORBER AND RELAY ARM". |
| 1 | Drive chain guard | 1 | |
| 2 | Rear brake disc guard | 1 | |
| 3 | Pivot shaft nut/washer | 1/1 | |
| 4 | Pivot shaft | 1 | |
| 5 | Swingarm | 1 | |
| 6 | Drive chain guide 1 | 1 | |
| 7 | Drive sprocket cover | 1 | |



| Order | Job/Part | Q'ty | Remarks |
|-------|---------------------------|-------|--|
| 8 | Drive chain guide 2 | 1 | Refer to "INSTALLING THE DRIVE SPROCKET". |
| 9 | Nut | 1 | |
| 10 | Lock washer | 1 | |
| 11 | Drive sprocket | 1 | |
| 12 | Drive chain | 1 | Refer to "INSTALLING THE SWING-ARM". |
| 13 | Dust cover/washer/bearing | 2/2/2 | |
| 14 | Spacer | 2 | |
| 15 | Oil seal | 2 | |
| 16 | Bushing | 2 | |
| | | | For installation, reverse the removal procedure. |



2. Check:

- pivot shaft

Roll the axle on a flat surface.

Bends → Replace.

⚠ WARNING

Do not attempt to straighten a bent pivot shaft.

3. Clean:

- pivot shaft
- spacer
- bearings
- bushings



Recommended cleaning solvent
Kerosene

4. Check:


- oil seals

Damage/wear → Replace.

- bearings

- bushings

Damage/pitting → Replace.



EBS00496

CHECKING THE DRIVE CHAIN

1. Measure:

- 15-link section ① of the drive chain
Out of specification → Replace the drive chain.



**15-link drive chain section limit
(maximum)
240.5 mm (9.47 in)**

NOTE:




- While measuring the 15-link section, push down on the drive chain to increase its tension.
- Measure the length between drive chain roller ① and ①⑥ as shown.
- Perform this measurement at two or three different places.

2. Check:

- drive chain
Stiffness → Clean and lubricate or replace.

3. Clean:

- drive chain




- Wipe the drive chain with a clean cloth.
- Put the drive chain in kerosene and remove any remaining dirt.
- Remove the drive chain from the kerosene and completely dry it.

CAUTION:

This machine has a drive chain with small rubber O-rings ① between the drive chain side plates. Never use high-pressure water or air, steam, gasoline, certain solvents (e.g., benzine), or a coarse brush to clean the drive chain. High-pressure methods could force dirt or water into the drive chain's internal parts, and solvents will deteriorate the O-rings. A coarse brush can also damage the O-rings. Therefore, use only kerosene to clean the drive chain. Don't soak the drive chain in kerosene for more than ten minutes. Kerosene will damage the O-rings.






4. Check:

- O-rings ①
Damage → Replace the drive chain.
- drive chain rollers ②
Damage/wear → Replace the drive chain.
- drive chain side plates ③
Cracks/damage/wear → Replace the drive chain.

5. Lubricate:

- drive chain





Recommended lubricant
Engine oil or chain lubricant
suitable for O-ring chains

6. Check:

- drive sprocket
- driven sprocket
More than 1/4 tooth ① wear → Replace the drive chain sprockets as a set.
Bent teeth → Replace the drive chain sprockets as a set.

- ① Correct
- ① Drive chain roller
- ② Drive chain sprocket



EBS00497

INSTALLING THE SWINGARM

1. Install:


- bearings ①
- bushings ②
(to swingarm)
- spacer ③

NOTE:

Apply the lithium-soap-based grease on the bushing when installing.



Installed depth of bearing ①
5 mm (0.20 in)
Installed depth of bushing ②
8 mm (0.31 in)




EBS00498

INSTALLING THE DRIVE SPROCKET

1. Install:

- drive sprocket ①
- lock washer ② **New**
- nut ③


 **75 Nm (7.5 m · kg, 54 ft · lb)**



2. Bend the lock washer tab along a flat side of the nut.

ELECTRICAL

ELECTRICAL COMPONENTS

- | | | | |
|----------------------------|----------------------------------|-------------------------------|-----------------------|
| ① Main switch | ⑨ Starting circuit cut-off relay | ⑬ Thermo switch 2 | ⑮ Rectifier/regulator |
| ② Throttle switch | ⑩ Tail/brake light | ⑭ Pickup coil/stator assembly | ⑯ C.D.I. unit |
| ③ Front brake light switch | ⑪ Battery | ⑮ Neutral switch | ⑰ Headlight |
| ④ Indicator light | ⑫ Ignition coil | ⑯ Rear brake light switch | ⑱ Diode 2 |
| ⑤ Clutch switch | ⑬ Spark plug | ⑰ Radiator fan | ⑲ Diode 1 |
| ⑥ Handlebar switch | ⑭ Throttle position sensor | ⑱ Circuit breaker (fan motor) | ⑳ Thermo switch 1 |
| ⑦ Fuse | ⑮ Carburetor switch | | |
| ⑧ Starter relay | | | |





EBS01028

CHECKING SWITCH CONTINUITY

Check each switch for continuity with the pocket tester. If the continuity reading is incorrect, check the wiring connections and if necessary, replace the switch.

CAUTION:

Never insert the tester probes into the coupler terminal slots ①. Always insert the probes from the opposite end of the coupler, taking care not to loosen or damage the leads.



Pocket tester
P/N. YU-03112-C, 90890-03112

NOTE:

- Before checking for continuity, set the pocket tester to "0" and to the " $\Omega \times 1$ " range.
- When checking for continuity, switch back and forth between the switch positions a few times.

The terminal connections for switches (e.g., main switch, engine stop switch) are shown in an illustration similar to the one on the left.

The switch positions ① are shown in the far left column and the switch lead colors ② are shown in the top row in the switch illustration.


NOTE:

"○—○" indicates a continuity of electricity between switch terminals (i.e., a closed circuit at the respective switch position).

The example illustration on the left shows that:

There is continuity between the switch terminals for the red and brown switch leads and between the switch terminals for the red/white and brown/blue switch leads when the switch is set to "ON".





EBS01029


CHECKING THE SWITCHES


Check each switch for damage or wear, proper connections, and also for continuity between the terminals. Refer to "CHECKING SWITCH CONTINUITY".

Damage/wear → Repair or replace.

Improperly connected → Properly connect.

Incorrect continuity reading → Replace the switch.





- ① Light switch
- ② Engine stop switch
- ③ Start switch
- ④ Main switch
- ⑤ Front brake light switch
- ⑥ Throttle switch
- ⑦ Clutch switch
- ⑧ Carburetor switch
- ⑨ Fuse
- ⑩ Neutral switch
- ⑪ Rear brake light switch



EBS01030



CHECKING THE BULBS AND BULB SOCKETS

Check each bulb and bulb socket for damage or wear, proper connections, and also for continuity between the terminals.

Damage/wear → Repair or replace the bulb, bulb socket or both.

Improperly connected → Properly connect.

No continuity → Repair or replace the bulb, bulb socket or both.



TYPES OF BULBS

The bulbs used on this machine are shown in the illustration on the left.

- Bulbs (a) and (b) are used for the headlights and usually use a bulb holder that must be detached before removing the bulb. The majority of these types of bulbs can be removed from their respective socket by turning them counterclockwise.
- Bulbs (c) is used for turn signal and tail/brake lights and can be removed from the socket by pushing and turning the bulb counterclockwise.
- Bulbs (d) and (e) are used for meter and indicator lights and can be removed from their respective socket by carefully pulling them out.


CHECKING THE CONDITION OF THE BULBS



The following procedure applies to all of the bulbs.

1. Remove:
 - bulb

EBS00503

IGNITION SYSTEM CIRCUIT DIAGRAM






THROTTLE OVERRIDE SYSTEM (T.O.R.S.) OPERATION

This model is equipped with a throttle override system as a safety device that operates according to the positions of the throttle switch and carburetor switch and stops the flow of electricity from the C.D.I. unit to the ignition coil to stop the engine if the carburetor or throttle cable malfunctions during operation.

- [A] Normally, both the throttle switch and carburetor switch are open when the throttle lever is free and closed when the throttle lever is pushed.
- [B] If either the throttle switch or the carburetor switch is closed due to a malfunction, the throttle override system operates to stop the engine.

- ① Battery
- ② Fuse
- ③ Main switch
- ④ Engine stop switch
- ⑤ C.D.I. unit
- ⑥ A.C. magneto
- ⑦ Ignition coil
- ⑧ Spark plug
- ⑨ Throttle switch
- ⑩ Carburetor switch



EBS01045

TROUBLESHOOTING

The ignition system fails to operate (no spark or intermittent spark).

Check:

1. fuse
2. battery
3. spark plug
4. ignition spark gap
5. ignition coil resistance
6. main switch
7. engine stop switch
8. throttle switch
9. carburetor switch
10. pickup coil resistance
11. wiring connections (of the entire ignition system)

NOTE:

- Before troubleshooting, remove the following part(s):
 1. seat
 2. fuel tank cover
 3. side covers (left and light)
 4. fuel tank
 5. front fender
- Troubleshoot with the following special tool(s).



Dynamic spark tester
P/N. YM-34487
Ignition checker
90890-06754
Pocket tester
P/N. YU-03112-C, 90890-03112

EBS01043

1. Fuse

- Check the fuse for continuity.
Refer to "CHECKING THE SWITCHES".
- Is the fuse OK?

↓ YES

↓ NO

Replace the fuse.

EBS01044

2. Battery

- Check the condition of the battery.
Refer to "CHECKING AND CHARGING THE BATTERY" in chapter 3.



Minimum open-circuit voltage
12.8 V or more at 20 °C (68 °F)

- Is the battery OK?

↓ YES

↓ NO

- Clean the battery terminals.
- Recharge or replace the battery.

EBS01032

3. Spark plug

- Check the condition of the spark plug.
- Check the spark plug type.
- Measure the spark plug gap.
Refer to "CHECKING THE SPARK PLUG" in chapter 3.




Standard spark plug
CR8E (NGK)
Spark plug gap
0.7 ~ 0.8 mm (0.028 ~ 0.031 in)

- Is the spark plug in good condition, is it of the correct type, and is its gap within specification?

↓ YES

↓ NO


Re-gap or replace the spark plug.



EBS01034

4. Ignition spark gap

- Disconnect the ignition coil from the spark plug.
- Connect the dynamic spark tester ① as shown.
- ② Ignition coil
- Set the main switch to "ON".
- Measure the ignition spark gap ③.
- Crank the engine by pushing the start switch and gradually increase the spark gap until a misfire occurs.



I8110201



Minimum ignition spark gap
6 mm (0.24 in)

- Is there a spark and is the spark gap within specification?

NO

YES

The ignition system is OK.

EBS01038

5. Ignition coil resistance


- Disconnect the ignition coil coupler from the ignition coil.
- Connect the pocket tester ($\Omega \times 1$) to the ignition coil as shown.

Positive tester probe →

orange lead terminal ①

Negative tester probe →

black lead terminal ②



- Measure the primary coil resistance.



Primary coil resistance
0.08 ~ 0.10 Ω at 20 °C (68 °F)


- Connect the pocket tester ($\Omega \times 1k$) to the ignition coil as shown.

Negative tester probe →

black lead terminal ①

Positive tester probe →

ignition coil terminal ②



- Measure the secondary coil resistance.




Secondary coil resistance
4.56 ~ 6.84 k Ω at 20 °C (68 °F)

- Is the ignition coil OK?

YES

NO

Replace the ignition coil.



EBS01041

6. Main switch

- Check the main switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?



Replace the main switch.

EBS01042

7. Engine stop switch

- Check the engine stop switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the engine stop switch OK?



Replace the handle-bar switch.

8. Throttle switch

- Check the throttle switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the throttle switch OK?



Replace the throttle switch.

9. Carburetor switch

- Check the carburetor switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the carburetor switch OK?





Replace the carburetor switch.

EBS01040

10. Pickup coil resistance

- Disconnect the pickup coil coupler from the wire harness.
- Connect the pocket tester ($\Omega \times 100$) to the pickup coil terminal as shown.

Positive tester probe → white terminal ①
Negative tester probe → red terminal ②




- Measure the pickup coil resistance.



Pickup coil resistance
 248 ~ 372 Ω at 20 °C (68 °F)

- Is the pickup coil OK?




Replace the pickup coil/stator assembly.

EBS01047

11. Wiring

- Check the entire ignition system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the ignition system's wiring properly connected and without defects?



Replace the C.D.I. unit.

Properly connect or repair the ignition system's wiring.



CHECKING THE THROTTLE OVERRIDE SYSTEM


⚠ WARNING

- Make sure that the parking brake is applied.
- Make sure that the transmission is in neutral.


NOTE:

Make sure that the throttle lever moves smoothly.

1. Remove:
 - throttle lever cover
 - throttle position sensor
 - carburetor switch/throttle stop screw assembly coverRefer to "CARBURETOR" in chapter 6.




2. Start the engine.
3. Check:
 - throttle switch ①


- 
- a. Press the throttle lever, and then push the throttle lever arm ② and hold it away from the throttle switch with a screwdriver.
 - b. Release the throttle lever and check that the throttle switch operates and the engine stops.

Engine stops → Throttle switch is O.K.

Engine does not stop → Check the electrical circuit. Refer to "IGNITION SYSTEM".




4. Check:
- carburetor switch ①

-  a. Push the throttle lever and hold it so that the throttle shaft arm ② does not contact the carburetor switch.
- b. Push the carburetor switch in and check that the carburetor switch operates and the engine stops.

Engine stops → Carburetor switch is O.K.

Engine does not stop → Check the electrical circuit. Refer to "IGNITION SYSTEM".




5. Install:



- throttle lever cover
- carburetor switch/throttle stop screw assembly cover
- throttle position sensor

Refer to “CHECKING AND ADJUSTING THE THROTTLE POSITION SENSOR” in chapter 6.

EBS00506

ELECTRIC STARTING SYSTEM CIRCUIT DIAGRAM






EBS00508

STARTING CIRCUIT CUT-OFF SYSTEM OPERATION

The starting circuit on this model consists of the starter motor, starter relay, clutch switch, and neutral switch. If the main switch is on and the engine stop switch is in the RUN position, the starter motor can be operated only if:

- The transmission is in neutral (the neutral switch is closed)
- or**
- You pull in the clutch lever (the clutch switch is closed).

- ① Battery
- ② Fuse
- ③ Main switch
- ④ Engine stop switch
- ⑤ Starting circuit cutoff relay
- ⑥ Clutch switch
- ⑦ Neutral switch
- ⑧ Start switch
- ⑨ Starter relay
- ⑩ Starter motor



EBS01050

TROUBLESHOOTING


The starter motor fails to turn.

Check:

1. fuse
2. battery
3. starter motor
4. starting circuit cut-off relay
5. starting circuit cut-off relay (diode)
6. starter relay
7. main switch
8. engine stop switch
9. neutral switch
10. clutch switch
11. start switch
12. wiring connections
(of the entire starting system)

NOTE:

- Before troubleshooting, remove the following part(s):
 1. seat
 2. fuel tank cover
 3. side covers (left and right)
 4. front fender
- Troubleshoot with the following special tool(s).



Pocket tester
P/N. YU-03112-C, 90890-03112

EBS01043

1. Fuse

- Check the fuse for continuity.
Refer to "CHECKING THE SWITCHES".
- Is the fuse OK?

↓ YES

↓ NO

Replace the fuse.

EBS01044

2. Battery

- Check the condition of the battery.
Refer to "CHECKING AND CHARGING THE BATTERY" in chapter 3.



Minimum open-circuit voltage
12.8 V or more at 20 °C (68 °F)

- Is the battery OK?

↓ YES


↓ NO

- Clean the battery terminals.
- Recharge or replace the battery.

EBS01051

3. Starter motor

- Connect the positive battery terminal ① and starter motor lead ② with a jumper lead ③.

**⚠ WARNING**


- A wire that is used as a jumper lead must have at least the same capacity or more as that of the battery lead, otherwise the jumper lead may burn.
- This check is likely to produce sparks, therefore make sure nothing flammable is in the vicinity.

- Does the starter motor turn?

↓ YES

↓ NO

Repair or replace the starter motor.



EBS01052

4. Starting circuit cut-off relay


- Remove the starting circuit cut-off relay from the wire harness.
- Connect the pocket tester ($\Omega \times 1$) and battery (12 V) to the starting circuit cut-off relay as shown.

Positive battery terminal → red/black ①

Negative battery terminal → sky blue ② or black/yellow ③

Positive tester probe → red/black ①

Negative tester probe → yellow/black ④



- Does the starting circuit cut-off relay have continuity between red/black and yellow/black?

↓ YES

↓ NO

Replace the starting circuit cut-off relay.

EBS01053

5. Starting circuit cut-off relay (diode)

- Remove the starting circuit cut-off relay from the wire harness.
- Connect the pocket tester ($\Omega \times 1$) to the starting circuit cut-off relay as shown.
- Measure the starting circuit cut-off relay for continuity as follows.

Positive tester probe →

sky blue ①

Negative tester probe →

red/black ②

Continuity


Positive tester probe →

red/black ②

Negative tester probe →

sky blue ①

No continuity

**NOTE:**

When you switch the tester's positive and negative probes, the readings in the above chart will be reversed.

- Are the testing readings correct?

↓ YES

↓ NO

Replace the starting circuit cut-off relay.




EBS01054

6. Starter relay

- Disconnect the starter relay coupler from the wire harness.
- Connect the pocket tester ($\Omega \times 1$) and battery (12 V) to the starter relay as shown.

Positive battery terminal → blue/black ①
Negative battery terminal → yellow/black ②

Positive tester probe → red ③
Negative tester probe → black ④



- Does the starter relay have continuity between red and black?

YES

NO

Replace the starter relay.

EBS01041

7. Main switch

- Check the main switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?

YES

NO

Replace the main switch.

EBS01042

8. Engine stop switch

- Check the engine stop switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the engine stop switch OK?

YES

NO

Replace the handle-bar switch.

EBS01046

9. Neutral switch

- Check the neutral switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the neutral switch OK?

YES

NO

Replace the neutral switch.

EBS01056

10. Clutch switch

- Check the clutch switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the clutch switch OK?

YES

NO

Replace the clutch switch.

EBS01057

11. Start switch

- Check the start switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the start switch OK?

YES

NO

Replace the handle-bar switch.



EBS01059

12.Wiring

- Check the entire starting system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the starting system's wiring properly connected and without defects?




YES



NO


The starting system circuit is OK.

Properly connect or repair the starting system's wiring.




EBS01061


STARTER MOTOR







| Order | Job/Part | Q'ty | Remarks |
|-------|-----------------------------------|------|---|
| | Removing the starter motor | | |
| | Exhaust pipe | | Remove the parts in the order listed. Refer to "ENGINE REMOVAL" in chapter 4. |
| 1 | Parking brake cable holder | 1 | |
| 2 | Oil delivery pipe 1 | 1 | |
| 3 | Starter motor lead | 1 | Disconnect. |
| 4 | Starter motor | 1 | For installation, reverse the removal procedure. |



EBS01062



| Order | Job/Part | Q'ty | Remarks |
|-------|--|------|--|
| | Disassembling the starter motor | | Remove the parts in the order listed. |
| ① | Front bracket | 1 | Refer to "ASSEMBLING THE STARTER MOTOR". |
| ② | O-ring | 1 | |
| ③ | Shim | 1 | |
| ④ | Lock washer | 1 | |
| ⑤ | Rear bracket | 1 | |
| ⑥ | O-ring | 1 | |
| ⑦ | Shim | 1 | |
| ⑧ | Brush holder assembly | 1 | |
| ⑨ | Armature assembly | 1 | |
| ⑩ | Starter motor yoke | 1 | |
| | | | For assembly, reverse the disassembly procedure. |



EBS01064

CHECKING THE STARTER MOTOR

1. Check:
 - commutator
Dirt → Clean with 600-grit sandpaper.
2. Measure:
 - commutator diameter (a)
Out of specification → Replace the starter motor.



Commutator wear limit
27 mm (1.06 in)

- ### 3. Measure:
- mica undercut Ⓐ
Out of specification → Scrape the mica to the proper measurement with a hacksaw blade that has been grounded to fit the commutator.



**Mica undercut
0.7 mm (0.03 in)**

NOTE:

The mica of the commutator must be undercut to ensure proper operation of the commutator.

4. Measure:
- armature assembly resistances (commutator and insulation)
- Out of specification → Replace the starter motor.

- a. Measure the armature assembly resistances with the pocket tester.





Pocket tester
P/N. YU-03112-C, 90890-03112



Armature coil
Commutator resistance ①
 0.004 ~ 0.005 Ω at 20 °C (68 °F)
Insulation resistance ②
 Above 1 MΩ at 20 °C (68 °F)

- b. If any resistance is out of specification, replace the starter motor.



5. Measure:

- brush length ①

Out of specification → Replace the brushes as a set.



Brush length wear limit
3.5 mm (0.14 in)


6. Measure:

- brush spring force

Out of specification → Replace the brush springs as a set.



Brush spring force
7.16 ~ 9.52 N
(730 ~ 971 gf, 25.77 ~ 34.27 oz)



7. Check:


- gear teeth

Damage/wear → Replace the gear.

8. Check:

- bushing
- bearing
- oil seal

Damage/wear → Replace the defective part(s).



EBS00515

ASSEMBLING THE STARTER MOTOR

1. Install:

- brush seat ①

NOTE:


Align the projection ① on the rear bracket with the slot ② in the yoke.

2. Install:


- yoke
- bracket


NOTE:

Align the match mark ① on the yoke with the match mark ② on the front bracket.



CHARGING SYSTEM CIRCUIT DIAGRAM





EBS01065

TROUBLESHOOTING

The battery is not being charged.

Check:

1. fuse
2. battery
3. charging voltage
4. charging coil resistance
5. wiring connections
(of the entire charging system)

NOTE:

- Before troubleshooting, remove the following part(s):
 1. seat
 2. front tank cover
 3. side covers (left and right)
 4. front fender
- Troubleshoot with the following special tool(s).



Pocket tester
P/N. YU-03112-C, 90890-03112

EBS01043

1. Fuse

- Check the fuse for continuity.
Refer to "CHECKING THE SWITCHES".
- Is the fuse OK?

↓ YES

↓ NO

Replace the fuse.

EBS01044

2. Battery

- Check the condition of the battery.
Refer to "CHECKING AND CHARGING THE BATTERY" in chapter 3.



Minimum open-circuit voltage
12.8 V or more at 20 °C (68 °F)

- Is the battery OK?



YES



NO

- Clean the battery terminals.
- Recharge or replace the battery.



EBS01066


EBS01100

3. Charging voltage

- Connect the engine tachometer to on to the ignition coil.
- Connect the pocket tester (DC 20 V) to the battery as shown.

Positive tester probe →
positive battery terminal ①

Negative tester probe →
negative battery terminal ②



- Start the engine and let it run at approximately 5,000 r/min.
- Measure the charging voltage.



Charging voltage
14 V at 5,000 r/min

NOTE: _____
Make sure the battery is fully charged.

- Is the charging voltage within specification?

NO

YES


The charging circuit is OK.

4. Charging coil resistance

- Disconnect the A.C. magneto coupler from the wire harness.
- Connect the pocket tester ($\Omega \times 1$) to the charging coils.

Positive tester probe → **white ①**

Negative tester probe → **ground ②**



- Measure the charging coil resistance.



Charging coil resistance
0.288 ~ 0.432 Ω at 20 °C (68 °F)

YES

NO

Replace the pickup coil/stator assembly.

5. Wiring


- Check the entire charging system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the charging system's wiring properly connected and without defects?

YES

NO

Replace the rectifier/regulator.


Replace the diode and properly connect or repair the charging system's wiring.




EBS00518

LIGHTING SYSTEM

CIRCUIT DIAGRAM





EBS01067

TROUBLESHOOTING

Any of the following fail to light: head-light, tail/brake light.

Check:

1. light switch
2. lighting coil resistance
3. wiring connections
(of the entire lighting system)

NOTE:

- Before troubleshooting, remove the following part(s):
 1. seat
 2. fuel tank cover
 3. side covers (left and right)
 4. front fender
- Troubleshoot with the following special tool(s).



Pocket tester
P/N. YU-03112-C, 90890-03112

EAS00783

1. Light switch

- Check the light switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the light switch OK?



YES



NO

Replace the handle-bar switch.


EAS00776

2. Lighting coil resistance

- Disconnect the A.C. magneto coupler from the wire harness.
- Connect the pocket tester ($\Omega \times 1$) to the lighting coil terminals as shown.

Positive tester probe → yellow ①

Negative tester probe → ground ②



- Measure the lighting coil resistance.



Lighting coil resistance
0.224 ~ 0.336 Ω at 20 °C (68 °F)

- Is the lighting coil OK?




YES



NO

Replace the pickup coil/stator assembly.



EBS01069

3. Wiring

- Check the entire lighting system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the lighting system's wiring properly connected and without defects?

YES

Check the condition of each of the lighting system's circuits. Refer to "CHECKING THE LIGHTING SYSTEM".

NO

Properly connect or repair the lighting system's wiring.

EBS01070

CHECKING THE LIGHTING SYSTEM

1. The headlights fail to come on.

1. Headlight bulb and socket

- Check the headlight bulb and socket for continuity. Refer to "CHECKING THE BULBS AND BULB SOCKETS".
- Are the headlight bulb and socket OK?

YES

Replace the headlight bulb, socket or both.

NO

2. Voltage

- Connect the pocket tester (AC 20 V) to the headlight couplers as shown.

A When the light switch is set to "LO"

B When the light switch is set to "HI"


Headlight coupler (wire harness side)

Headlight

Positive tester probe →

yellow ① or green ②

Negative tester probe → **black ③**




- Set the main switch to "ON".
- Start the engine.
- Set the light switch to "LO" or "HI".
- Measure the voltage (AC 12 V) of yellow ① or green ② on the headlight coupler (wire harness side).
- Is the voltage within specification?

YES

This circuit is OK.

NO

Replace the rectifier/regulator.



2. The tail/brake light fails to come on.

1. Tail/brake light bulb and socket

- Check the tail/brake light bulb and socket for continuity.
Refer to “CHECKING THE BULBS AND BULB SOCKETS”.
- Are the tail/brake light bulb and socket OK?

YES

NO

Replace the tail/brake light bulb, socket or both.

2. Voltage


- Connect the pocket tester (AC 20 V) to the tail/brake light coupler as shown.

Tail/brake light coupler (wire harness side)

Tail/brake light

Positive tester probe → blue ①

Negative tester probe → black ②




- Set the main switch to “ON”.
- Start the engine.
- Measure the voltage (AC 12 V) of blue ① on the tail/brake light coupler (wire harness side).
- Is the voltage within specification?

YES

NO


This circuit is OK.


Replace the rectifier/regulator.



EBS00521

SIGNAL SYSTEM CIRCUIT DIAGRAM





EBS01073

TROUBLESHOOTING

Any of the following fail to light: brake light or an indicator light.

Check:

1. fuse
2. battery
3. main switch
4. wiring connections
(of the entire signaling system)

NOTE:

- Before troubleshooting, remove the following part(s):
 1. seat
 2. fuel tank cover
 3. side covers (left and light)
 4. front fender
- Troubleshoot with the following special tool(s).



Pocket tester
P/N. YU-03112-C, 90890-03112

EBS01043

1. Fuse

- Check the fuse for continuity.
Refer to “CHECKING THE SWITCHES”.
- Is the fuse OK?

↓ YES

↓ NO

Replace the fuse.

EBS01044

2. Battery

- Check the condition of the battery.
Refer to “CHECKING AND CHARGING THE BATTERY” in chapter 3.



Minimum open-circuit voltage
12.8 V or more at 20 °C (68 °F)

- Is the battery OK?

↓ YES

↓ NO

- Clean the battery terminals.
- Recharge or replace the battery.

EBS01041

3. Main switch

- Check the main switch for continuity.
Refer to “CHECKING THE SWITCHES”.
- Is the main switch OK?

↓ YES

↓ NO

Replace the main switch.

EBS01074

4. Wiring


- Check the entire signal system’s wiring.
Refer to “CIRCUIT DIAGRAM”.
- Is the signaling system’s wiring properly connected and without defects?

↓ YES

↓ NO

Check the condition of each of the signaling system’s circuits.
Refer to “CHECKING THE SIGNALING SYSTEM”.

Properly connect or repair the signaling system’s wiring.



EBS01075

CHECKING THE SIGNALING SYSTEM

EBS01076

1. The tail/brake light fails to come on.

1. Tail/brake light bulb and bulb socket

- Check the tail/brake light bulb and bulb socket for continuity.
Refer to "CHECKING THE BULBS AND BULB SOCKETS".
- Are the tail/brake light bulb and bulb socket OK?

↓ YES

↓ NO

Replace the tail/
brake light bulb, bulb
socket or both.

2. Brake light switches

- Check the brake light switches for continuity.
Refer to "CHECKING THE SWITCHES".
- Is the brake light switch OK?

↓ YES

↓ NO


Replace the brake
light switch.

3. Voltage

- Connect the pocket tester (DC 20 V) to the tail/brake light coupler (wire harness side) as shown.

Positive tester probe → yellow ①

Negative tester probe → black ②



- Set the main switch to "ON".
- Pull in the brake lever or push down on the brake pedal.
- Measure the voltage (DC 12 V) of yellow ① on the tail/brake light coupler (wire harness side).
- Is the voltage within specification?

↓ YES

↓ NO

This circuit is OK.

The wiring circuit
from the main switch
to the tail/brake light
coupler is faulty and
must be repaired.

EBS01077

2. The neutral indicator light fails to come on.


1. Neutral indicator light bulb and socket

- Check the neutral indicator light bulb and socket for continuity.
Refer to "CHECKING THE BULBS AND BULB SOCKETS".
- Are the neutral indicator light bulb and socket OK?

↓ YES

↓ NO

Replace the neutral
indicator light bulb,
socket or both.



2. Neutral switch

- Check the neutral switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the neutral switch OK?

YES

NO


Replace the neutral switch.

3. Voltage

- Connect the pocket tester (DC 20 V) to the indicator light coupler (wire harness side) as shown.

Positive tester probe → brown ①

Negative tester probe → sky blue ②



- Set the main switch to "ON".
- Measure the voltage (DC 12 V).
- Is the voltage within specification?

YES

NO

This circuit is OK.

The wiring circuit from the main switch to the indicator light coupler is faulty and must be repaired.

EBS01083

3. The coolant temperature warning light does not come on when the start switch is pushed on, or if the coolant temperature warning light does not come on when the temperature is high (more than 117 ~ 123 °C (242.6 ~ 253.4 °F)).

1. Coolant temperature warning light bulb and socket

- Check the coolant temperature warning light bulb and socket for continuity. Refer to "CHECKING THE BULBS AND BULB SOCKETS".
- Are the coolant temperature warning light bulb and socket OK?

YES

NO

Replace the coolant temperature warning light bulb, socket or both.




2. Thermo switch 2


- Remove the thermo switch 2 from the radiator.
- Connect the pocket tester ($\Omega \times 1$) to the thermo switch 2 ① as shown.
- Immerse the thermo switch 2 in a container filled with coolant ②.
- Place a thermometer ③ in the coolant.
- Slowly heat the coolant, then let it cool down to the specified temperature.
- Check the thermo switch 2 for continuity at the temperatures indicated below.

| Test step | Coolant temperature | Continuity |
|-----------|--|------------|
| | Thermo switch | |
| 1 | Less than $120 \pm 3 \text{ }^{\circ}\text{C}$ ($248 \pm 5.4 \text{ }^{\circ}\text{F}$) | NO |
| 2 | More than $120 \pm 3 \text{ }^{\circ}\text{C}$ ($248 \pm 5.4 \text{ }^{\circ}\text{F}$) | YES |
| 3* | More than $115 \pm 3 \text{ }^{\circ}\text{C}$ ($239 \pm 5.4 \text{ }^{\circ}\text{F}$) | YES |
| 4* | Less than $115 \pm 3 \text{ }^{\circ}\text{C}$ ($239 \pm 5.4 \text{ }^{\circ}\text{F}$) | NO |

Steps 1 & 2: Heating phase
Steps 3* & 4*: Cooling phase



- A** The thermo switch circuit is open and the coolant temperature warning light is off.
- B** The thermo switch circuit is closed and the coolant temperature warning light is on.



⚠ WARNING

- Handle the thermo switch with special care.
- Never subject the thermo switch to strong shocks. If the thermo switch is dropped, replace it.



Thermo switch
28 Nm (2.8 m · kg, 20 ft · lb)

- Does the thermo switch 2 operate properly as described above?




YES



NO

Replace the thermo switch 2.




3. Voltage

- Connect the pocket tester (DC 20 V) to the indicator light connector (wire harness side) as shown.

Positive tester probe → red/black ①

Negative tester probe → white/blue ②



- Set the main switch to "ON".
- Measure the voltage (12 V) of red/black ① and brown ② at the indicator light coupler.
- Is the voltage within specification?

YES

NO


The wiring circuit from the main switch to the indicator light connector is faulty, repair it.

4. Diode

- Remove the diode from the coupler.
- Connect the pocket tester ($\Omega \times 1$) to the diode terminals as shown.
- Check the diode for continuity as follows.

Positive tester probe → blue/black ①
Negative tester probe → white/blue ②
Continuity

Positive tester probe → white/blue ②
Negative tester probe → blue/black ①
No continuity



NOTE:

When you switch the tester's positive and negative probes, the readings in the above chart will be reversed.

- Is the diode OK?

YES

NO

Replace the diode.

5. Start switch


- Check the start switch for continuity. Refer to "CHECKING THE SWITCHES".
- Is the start switch OK?

YES

NO

The circuit is not faulty.


Replace the handle-bar switch.




EBS00532

COOLING SYSTEM

CIRCUIT DIAGRAM





EBS01085

TROUBLESHOOTING**The radiator fan motor fails to turn.**

Check:

1. fuse
2. battery
3. main switch
4. radiator fan motor
5. circuit breaker (fan motor)
6. thermo switch 1
7. wiring connections
(the entire cooling system)

NOTE:

- Before troubleshooting, remove the following part(s):
 1. seat
 2. fuel tank cover
 3. side covers (left and right)
 4. front fender
- Troubleshoot with the following special tool(s).



Pocket tester
P/N. YU-03112-C, 90890-03112

EBS01043

1. Fuse

- Check the fuse for continuity.
Refer to "CHECKING THE SWITCHES".
- Are the fuse OK?

↓ YES

↓ NO

Replace the fuse.

EBS01044

2. Battery

- Check the condition of the battery.
Refer to "CHECKING AND CHARGING THE BATTERY" in chapter 3.



Minimum open-circuit voltage
12.8 V or more at 20 °C (68 °F)

- Is the battery OK?

↓ YES

↓ NO

- Clean the battery terminals.
- Recharge or replace the battery.

EBS01041


3. Main switch

- Check the main switch for continuity.
Refer to "CHECKING THE SWITCHES".
- Is the main switch OK?

↓ YES

↓ NO

Replace the main switch.




EBS01086

4. Radiator fan motor

- Disconnect the radiator fan motor coupler from the wire harness.
- Connect the battery (DC 12 V) as shown.

Positive battery lead → blue ①

Negative battery lead → black ②



- Does the radiator fan motor turn?


↓ YES

↓ NO

The radiator fan motor is faulty and must be replaced.

5. Circuit breaker (fan motor)

- Remove the circuit breaker from the wire harness.
- Connect the pocket tester ($\Omega \times 1$) to the circuit breaker.



Circuit breaker resistance
Zero Ω at 20 °C (68 °F)

↓ YES

↓ NO

Replace the circuit breaker.

EBS01088


6. Thermo switch 1


- Remove the thermo switch 1 from the radiator.
- Connect the pocket tester ($\Omega \times 1$) to the thermo switch 1 ① as shown.
- Immerse the thermo switch 1 in a container filled with coolant ②.
- Place a thermometer ③ in the coolant.
- Slowly heat the coolant, then let it cool down to the specified temperature.
- Check the thermo switch 1 for continuity at the temperatures indicated below.

| Test step | Coolant temperature | Continuity |
|-----------|---|------------|
| | Thermo switch | |
| 1 | Less than $98 \pm 3^\circ\text{C}$ ($208.4 \pm 5.4^\circ\text{F}$) | NO |
| 2 | More than $98 \pm 3^\circ\text{C}$ ($208.4 \pm 5.4^\circ\text{F}$) | YES |
| 3* | More than $92 \pm 3^\circ\text{C}$ ($197.6 \pm 5.4^\circ\text{F}$) | YES |
| 4* | Less than $92 \pm 3^\circ\text{C}$ ($197.6 \pm 5.4^\circ\text{F}$) | NO |

Steps 1 & 2: Heating phase

Steps 3* & 4*: Cooling phase






⚠ WARNING

- Handle the thermo switch with special care.
- Never subject the thermo switch to strong shocks. If the thermo switch is dropped, replace it.



Thermo switch
28 Nm (2.8 m · kg, 20 ft · lb)

- A** The thermo switch circuit is open and the radiator fan is off.
- B** The thermo switch circuit is closed and the radiator fan is on.



- Does the thermo switch 1 operate properly as described above?

↓ YES

↓ NO

Replace the thermo switch 1.

EBS01090

7. Wiring

- Check the entire cooling system's wiring. Refer to "CIRCUIT DIAGRAM".
- Is the cooling system's wiring properly connected and without defects?

↓ YES

↓ NO

This circuit is OK.

Properly connect or repair the cooling system's wiring.

TROUBLESHOOTING

NOTE:

The following troubleshooting does not cover all the possible causes of trouble. It should be helpful, however, as a guide to troubleshooting. Refer to the relative procedure in this manual for check, adjustment and replacement of parts.

STARTING FAILURE/HARD STARTING

FUEL SYSTEM**Fuel tank**

- Empty
- Clogged fuel strainer
- Clogged fuel tank breather hose
- Deteriorated or contaminated fuel

Fuel cock

- Clogged fuel hose

Carburetor

- Deteriorated or contaminated fuel
- Clogged pilot jet
- Clogged pilot air passage
- Sucked-in air
- Deformed float
- Worn needle valve
- Improperly sealed valve seat
- Improperly adjusted fuel level
- Improperly set pilot jet
- Clogged starter jet
- Choke valve malfunction

Air filter

- Clogged air filter element

ELECTRICAL SYSTEM**Spark plug**

- Improper plug gap
- Worn electrodes
- Wire between terminals broken
- Improper heat range

Ignition coil

- Broken or shorted primary/secondary
- Faulty ignition coil lead
- Broken body

C.D.I. system

- Faulty C.D.I. unit
- Faulty pickup coil
- Faulty lighting coil
- Faulty charging coil
- Broken woodruff key

Switches and wiring

- Faulty main switch
- Faulty engine stop switch
- Broken or shorted wiring
- Faulty neutral switch
- Faulty start switch
- Faulty clutch switch
- Faulty throttle switch
- Faulty carburetor switch
- Loose connections

Starter motor

- Faulty starter motor
- Faulty starter relay
- Faulty starting circuit cut-off relay
- Faulty starter clutch
- Faulty torque limiter

Battery

- Faulty battery
- Discharged battery

COMPRESSION SYSTEM

Cylinder and cylinder head

- Loose spark plug
- Loose cylinder head or cylinder
- Broken cylinder head gasket
- Broken cylinder gasket
- Worn, damaged or seized cylinder

Valve and camshaft

- Improperly sealed valve
- Improperly contacted valve and valve seat
- Improper valve timing
- Broken valve spring
- Seized camshaft

Piston and piston rings

- Improperly installed piston ring
- Worn, fatigued or broken piston ring
- Seized piston ring
- Seized or damaged piston

Crankcase and crankshaft

- Improperly seated crankcase
- Seized crankshaft

Valve train

- Improperly adjusted valve clearance
- Improperly adjusted valve timing

EBS00538

POOR IDLE SPEED PERFORMANCE

POOR IDLE SPEED PERFORMANCE

Carburetor

- Improperly returned choke
- Loose or clogged pilot jet
- Loose or clogged pilot air jet
- Improperly adjusted idle speed (throttle stop screw)
- Improper throttle cable play
- Flooded carburetor

Intake manifold

- Loosen carburetor joint

Electrical system

- Faulty battery
- Faulty C.D.I. unit
- Faulty pickup coil
- Faulty ignition coil

Valve train

- Improperly adjusted valve clearance

Air filter

- Clogged air filter element
- Loosen air filter joint

EBS00539

POOR MEDIUM AND HIGH-SPEED PERFORMANCE

POOR MEDIUM AND HIGH-SPEED PERFORMANCE

Refer to “STARTING FAILURE/HARD STARTING” and “POOR IDLE SPEED PERFORMANCE—Valve train”.

Carburetor

- Improper jet needle clip position
- Improperly adjusted fuel level
- Clogged or loose main jet
- Deteriorated or contaminated fuel

Air filter

- Clogged air filter element

EBS00541

FAULTY GEAR SHIFTING

HARD SHIFTING

Refer to "CLUTCH DRAGGING".

SHIFT PEDAL DOES NOT MOVE

Shift shaft

- Bent shift shaft

Shift drum and shift forks

- Groove jammed with impurities
- Seized shift fork
- Bent shift fork guide bar

Transmission

- Seized transmission gear
- Jammed impurities
- Incorrectly assembled transmission

Shift guide

- Broken shift guide

JUMPS OUT GEAR

Shift shaft

- Improperly adjusted shift lever position
- Improperly returned stopper lever

Shift forks

- Worn shift fork

Shift drum

- Improper thrust play
- Worn shift drum groove

Transmission

- Worn gear dog

EBS00545

CLUTCH SLIPPING/Dragging

CLUTCH SLIPPING

Clutch

- Loose clutch spring
- Fatigued clutch spring
- Worn friction plate
- Worn clutch plate
- Incorrectly assembled clutch

Engine oil

- Low oil level
- Improper quality (low viscosity)
- Deterioration

CLUTCH DRAGGING

Clutch

- Warped pressure plate
- Unevenly tensioned clutch springs
- Loose clutch boss nut
- Burnt primary driven gear bushing
- Bent clutch plate
- Swollen friction plate
- Broken clutch boss

Engine oil

- High oil level
- Improper quality (high viscosity)
- Deterioration

EBS00547

OVERHEATING

OVERHEATING

Ignition system

- Improper spark plug gap
- Improper spark plug heat range
- Faulty C.D.I. unit

Fuel system

- Improper carburetor main jet (improper setting)
- Improper fuel level
- Clogged air filter element

Compression system

- Heavy carbon deposit

Engine oil

- Improper oil level
- Improper oil viscosity
- Inferior oil quality

Brake

- Brake drag

Cooling system

- Low coolant level
- Clogged or damaged radiator
- Damaged or faulty water pump
- Faulty fan motor
- Faulty thermo switch

EBS00550

FAULTY BRAKE

POOR BRAKING EFFECT

Disc brake

- Worn brake pads
- Worn disc
- Air in brake fluid
- Leaking brake fluid
- Faulty master cylinder kit cup
- Faulty caliper kit seal
- Loose union bolt
- Broken brake hose and pipe
- Oily or greasy disc/brake pads
- Improper brake fluid level

EBS00551

SHOCK ABSORBER MALFUNCTION

MALFUNCTION

- Bent or damaged damper rod
- Damaged oil seal lip
- Fatigued shock absorber spring
- Leaking oil or gas

EBS00552

UNSTABLE HANDLING

UNSTABLE HANDLING

Handlebar

- Improperly installed or bent

Steering

- Incorrect toe-in
- Bent steering stem
- Improperly installed steering stem
- Damaged bearing or bearing race
- Bent tie-rods
- Deformed steering knuckles

Tires

- Uneven tire pressures on both sides
- Incorrect tire pressure
- Uneven tire wear

Wheels

- Deformed wheel
- Loose bearing
- Bent or loose wheel axle
- Excessive wheel runout

Frame

- Bent
- Damaged frame

Swingarm

- Worn bearing or bushing
- Bent or damaged

EBS00553

LIGHTING SYSTEM

HEADLIGHT DOES NOT COME ON

- Improper bulb
- Too many electric accessories
- Hard charging (broken stator coil and/or faulty rectifier/regulator)
- Incorrect connection
- Improperly grounded
- Poor contacts (main or light switch)
- Bulb life expired

TAIL/BRAKE LIGHT DOES NOT LIGHT

- Wrong tail/brake light bulb
- Too many electrical accessories
- Hard charging (broken stator coil and/or faulty rectifier/regulator)
- Incorrect connection
- Improperly grounded
- Poor contacts (main or light switch)
- Burnt-out tail/brake light bulb

BULB BURNT OUT

- Improper bulb
- Faulty battery
- Faulty rectifier/regulator
- Improperly grounded
- Faulty main and/or light switch
- Bulb life expired

TAIL/BRAKE LIGHT BULB BURNT OUT


- Wrong tail/brake light bulb
- Faulty battery
- Faulty rectifier/regulator
- Improperly grounded
- Faulty main and/or light switch
- Incorrectly adjusted rear brake light switch
- Tail/brake light bulb life expired



YAMAHA MOTOR CO., LTD.
2500 SHINGAI IWATA SHIZUOKA JAPAN

PRINTED IN U.S.A.

YFZ450S WIRING DIAGRAM



- ① A.C. magneto
- ② Rectifier/regulator
- ③ Main switch
- ④ Battery
- ⑤ Fuse
- ⑥ Starter relay
- ⑦ Starter motor
- ⑧ Diode 1
- ⑨ Starting circuit cut-off relay
- ⑩ Clutch switch
- ⑪ C.D.I. unit
- ⑫ Ignition coil
- ⑬ Spark plug
- ⑭ Throttle position sensor
- ⑮ Throttle switch
- ⑯ Carburetor switch
- ⑰ Circuit breaker (fan motor)
- ⑱ Thermo switch 1
- ⑲ Fan motor
- ⑳ Coolant temperature warning light
- ㉑ Neutral indicator light
- ㉒ Neutral switch
- ㉓ Diode 2
- ㉔ Thermo switch 2
- ㉕ Handlebar switch
- ㉖ Light switch
- ㉗ Engine stop switch
- ㉘ Start switch
- ㉙ Headlight
- ㉚ Tail/brake light
- ㉛ Rear brake light switch
- ㉜ Front brake light switch

COLOR CODE

BBlack
BrBrown
GGreen
LBlue
OOrange
RRed
SbSky blue
WWhite

Y Yellow
B/L Black/Blue
B/Y Black/Yellow
Br/L Brown/Blue
L/B Blue/Black
R/B Red/Black
R/W Red/White
W/B White/Black

W/L White/Blue
Y/B Yellow/Black
Y/R Yellow/Red